

EUT Internal Photos

Figure 7
configuration #1: WLAN+BT Function, Internal View (Removed Cover)




Figure 8
configuration #1: WLAN+BT Function, Internal View (Removed Main Board)




Figure 9
WLAN+BT Function, Internal View (Main Board, Back View)




Figure 10
configuration #1: WLAN+BT Function, Internal View (Removed BT Module)




Figure 11
configuration #1: WLAN+BT Function, Internal View (BT Module, Back View)




Figure 12
WLAN+BT Function, Internal View (BT Module, Front View)




Figure 13
WLAN+BT Function, Internal View (Internal View)




Figure 14
WLAN+BT Function, Internal View (Control Board, Front View)




Figure 15
WLAN+BT Function, Internal View (Control Board, Back View)




Figure 16
configuration #1: WLAN+BT Function, Internal View (Removed Metal Cover)




Figure 17
WLAN+BT Function, Internal View (Main Board, Front View)




Figure 18
WLAN+BT Function, Internal View (WLAN Module View)




Figure 19
WLAN+BT Function, Internal View (WLAN Antenna View)




Figure 20
WLAN+BT Function, Internal View (WLAN Antenna View)




Figure 21
WLAN+BT Function, Internal View (WLAN Antenna, Back View)




Figure 22
WLAN+BT Function, Internal View (WLAN Antenna, Front View)

