





Photographs of EUT



Primary Antenna & Secondary Antenna with Cover




Primary Antenna





Secondary Antenna



External ports



Primary Antenna (located at Bottom of Antenna)



Secondary Antenna (located at Bottom of Antenna)