

Label location and sample

LABEL LOCATION and Drawing:

LABEL will be attached on the side edge of the Antenna Unit

[Antenna Unit]

