



Photographs of EUT



Antenna with Cover

Antenna






External ports



(located at Bottom of Antenna)

Label drawing:





CNX-BB (Customer Network Exchange)






CNX-BB (Customer Network Exchange)



Customer Network Exchange I/O port



Label

AC Adapter for CNX-BB

