



Label location: LABEL will be attached on the bottom of the Antenna Unit



Label drawing:
for Primary Antenna Unit



for Secondary Antenna Unit

