

Photographs of EUT



Antenna with Cover

Antenna





External ports




(located at Bottom of Antenna)



(located at Bottom of Antenna)



Label drawing:





CNX-Rac (Customer Network Exchange)





CNX-Rac (Customer Network Exchange)



Customer Network Exchange I/O port