




USER GUIDE


Jib True Series

Auto Pair Mode




Pairing Mode
Mode Couplage
Modo De Vinculación
Modalità Di Accoppiamento
Modo Emparelhamento
Koppelmodus
Paarmodus
Pardannelsevstilstand
Laiteparin Muodostustila
Sammenkoblingsmodus
Parningsläge
Режим Сопряжения
配对模式
ペアリングモード
페어링 모드
وضوح المزاوجة

Auto Power - On




Power - On
On
Encendido
Accensione
Ligar
Ein
Aan-
Tænd
Virta Päälle
Ström Av
Ström Av
Включить
开机
電源 - On
전원 켜기
이전 트래킹
إيقاظ التشغيل

Auto Power - Off




Power - Off
Off
Apagado
Spegnimento
Desligar
Aus
Uitzetting
Sluk For Strøm
Pois
På
På
выключить Питание
关机
電源 - Off
끄기
إيقاف التشغيل

Charge Earbuds




Charge Earbuds
Rechargez Les Écouteurs
Audífonos De Carga
Carica Gli Auricolari
Carregar Auriculares
Kopfhörer Aufladen
Opladen Oordoppen
Oplad Høretelefoner
Lataa Nappikuulokkeet
Lade Øreplugger
Ladda Öronsnäckor
Наушники С Аккумулятором
为耳机充电
イヤホン充電
이어버드를 충전하세요
ذئاء انا عيظس دئعش

Charge Case



Charge Case
Rechargez L'étui
Estuche De Carga
Carica La Custodia
Estojo De Carregamento
Hülle Aufladen
Opladetui
Opladeretui
Lataa Kotelo
Ladingseske
Laddningsfodral
Чехол-аккумулятор
充電座
充電ケース
케이스를 충전하세요
دئعش دئعش

Charge Case Battery Life




(Open case for LED to flash)

Check Battery Life
Vérifier la Batterie
Comprobar Bateria
Controlla la Batteria
Verifique a Bateria
Überprüfen Sie die Batterie
Controleer Batterij
Kontroller Batteriet
Tarkista Akku
Kontroller Batteriet
Kontrollera Batteriet
Проверьте батарею
検査電池
バッテリーを確認する
배터리 확인
دئعش انا عيظس دئعش

Pairing Mode



Left Side or Right Side
*On Mode
*Not Connected To Device




Pairing Mode
Mode Couplage
Modo De Vinculación
Modalità Di Accoppiamento
Modo Emparelhamento
Koppelmodus
Paarmodus
Pardannelsevstilstand
Laiteparin Muodostustila
Sammenkoblingsmodus
Parningsläge
Режим Сопряжения
配对模式
ペアリングモード
페어링 모드
وضوح المزاوجة

Pairing Mode




Left Side or Right Side
*Off Mode



Pairing Mode
Mode Couplage
Modo De Vinculación
Accoppia Nuovo Dispositivo
Modo Emparelhamento
Koppelmodus
Paarmodus
Pardannelsevstilstand
Laiteparin Muodostustila
Sammenkoblingsmodus
Parningsläge
Режим Сопряжения
配对模式
ペアリングモード
페어링 모드
وضوح المزاوجة

Pair New Device

"Jib True"
Left Side or Right Side




Pair New Device
Coupler Nouvel Appareil
Vincular Nuevo Dispositivo
Accoppia Nuovo Dispositivo
Emparellar Novo Dispositivo
Mit Neuem Gerät Koppeln
Nieuw Apparaat Paren
Pardan Ny Enhet
Muodosta Uusi Laiteparin
Sammenkoble Ny Enhet
Para Ny Enhet
Сопряжение Нового Устройства
配对新设备
新しいデバイスをペアリング
새 기기 짝 맞추기
دئعش انا عيظس دئعش

Power - On



Left Side and Right Side




Power - On
On/off
Encendido
Accensione
Ligar
Ein
Aan-
Tænd
Virta Päälle
Ström Av
Ström Av
Включить
开机
電源 - On
전원 켜기
이전 트래킹
إيقاظ التشغيل

Power - Off



Left Side and Right Side




Power - Off
Off
Apagado
Spegnimento
Desligar
Aus
Uitzetting
Sluk For Strøm
Pois
På
På
выключить Питание
关机
電源 - Off
끄기
إيقاف التشغيل

Play/Pause



Left Side or Right Side




Play/pause
Lecture/pause
Reproducir/pausar
Riproduci/pausa
Reproduzir/colocar Em Pausa
Wiedergabe/pause
Afspelen/pauzeren
Afspl/pause
Toisto/tauko
Spill/pause
Spela Upp/pausa
Воспроизведение/пауза
播放/暫停
再生 / 一時停止
재생/일시 정지
تؤدوم فادئعش انا عيظس دئعش

Track Forward



Right Side




Track Forward
Piste Suivante
Adelantar
Brano Successivo
Faixa Seguinte
Nächster Titel
Volgend Nummer
Skift Til Næste Musiknummer
Kelaus Eteenpäin
Neste Spor
Nästa Ljudspår
Переключение На 1 Трек Вперед
下一曲目
次のトラックを再生する
다음 트랙으로
مسار إلى الأمام

Track Back



Left Side




Track Back
Piste Précédente
Retroseder
Brano Precedente
Faixa Anterior
Vorangehender Titel
Vorig Nummer
Musiknummer Tilbage
Kelaus Taaksepäin
Förige Spor
Byta Till Föregående Spår
Переключение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로
فادئعش انا عيظس دئعش

Volume Up



Right Side




Volume Up
Volume +
Subir Volumen
Aumento Volume
Aumentar O Volume
Lautstärke Erhöhen
Volume Omhoog
Skrü Op For Lydstyrken
Äänenvoimakkuuden Lisäys
Volum Opp
Öka Volymen
Увеличение Громкости
音量増大
音量を上げる
볼륨 높이기
رفع مستوى الصوت

Volume Down



Left Side




Volume Down
Volume -
Bajar Volumen
Riduzione Volume
Diminuir O Volume
Lautstärke Senken
Volume OmLaag
Skrü Ned For Lydstyrken
Äänenvoimakkuuden Vähennys
Volum Ned
Sänka Volymen
Уменьшение Громкости
音量减小
音量を下げる
볼륨 낮추기
خفض مستوى الصوت

Answer/End




Left Side or Right Side



Answer/end
Répondre/fin
Responder/colgar
Risposta/line
Atender/desligar
Annehmen/beenden
Beantwoorden/beëindigen
Besvar/afslut
Vastaus/lopetus
Svara/avslutt
Svara/legg På
Ответить/закончить
接听/结束
応答 / 終了
전화 받기 끊기
عائنا الى دئعش انا عيظس دئعش

Activate Voice Assistant

Left Side or Right Side




Activate Voice Assistant
Activer l'assistant vocal
Activar el asistente de voz
Attivare assistente vocale
Ativar assistente de voz
Sprachassistenten aktivieren
Stemhulp activeren
Aktivér talestøtte
Aktivo äänihäin
Aktiver taleassistent
Aktivera röstassistent
Активировать голосовой помощник
激活语音助理
ボイスアシスタントを
アクティベートする
음성 인식 가동화
يتوصيلا دئعش انا عيظس دئعش

Clear Paired Device



Left Side and Right Side
*Off Mode



Reset Device
Réinitialiser l'Appareil
Reiniciar el Dispositivo
Ripristina Dispositivo
Reinicie o Dispositivo
Rückstell Einrichtung
Reset het Apparaat
Nulstil Enhet
Nollaa Laite
Nulstil Enhet
Återställ Enhet
Сброс устройства
重置设备
デバイスをリセット
기기 재설정
راجع الى طبع دئعش انا عيظس دئعش

