

Setup Photos

Front To Face View



EUT Setup Configuration 1

Body Touch View



EUT Setup Configuration 2

EUT Photos

EUT Configuration 1EUT Configuration 2



EUT Configuration 3



EUT Configuration 4



EUT Configuration 5




EUT Configuration 6



EUT Configuration 7


Battery




EUT Configuration 8




EUT Configuration 9




EUT Configuration 10




EUT Configuration 11




EUT Configuration 12





EUT Configuration 13



EUT Configuration 14










EUT Configuration 21



EUT Configuration 22

Battery

