

Gross Axle Weight Rating

The Gross Axle Weight Rating is the maximum load that can be applied at each axle of the vehicle ⇒ ⚠.

Vehicle capacity weight

The vehicle capacity weight (max. load) is listed on the driver's side B-pillar.

 **WARNING**

– The actual Gross Axle Weight Rating at the front and rear axles should not exceed the permissible weights, and their combination must not exceed the Gross Vehicle Weight Rating.

– Exceeding permissible weight ratings can result in vehicle damage, accidents and personal injury.

 **Note**

– The vehicle capacity weight figures apply when the load is distributed evenly in the vehicle (passengers and luggage). When transporting a heavy load in the luggage compartment, carry the load as near to the rear axle as possible so that the vehicle's handling is not impaired.

– Do not exceed the maximum permissible axle loads or the maximum gross vehicle weight. Always remember that the vehicle's handling will be affected by the extra load. Therefore, adjust your speed accordingly.

– Always observe local regulations.

Dimensions

	Length (in (mm))	Width (in (mm))	Width across the mirrors (in (mm))	Height at curb weight (in (mm))
Q3	172.8 (4,388)	72.0 (1,831)	79.4 (2,019)	62.5 (1,590)

Capacities

	Approximate capacities
Fuel tank	16.9 qt (64.0 L)
Windshield and headlight washer system	4.8 qt (4.5 L)

Gasoline engines

Q3 2.0, 4 cylinder

Maximum output SAE net	hp @ rpm	200 @ 5100 – 6000
Maximum torque SAE net	lb-ft @ rpm	207 @ 1700 – 5000
Displacement	CID (cm ³)	121 (1984)
Engine oil with filter change ¹⁾		
Fuel	Premium unleaded (91 AKI) ⇨ <i>page 152, Fuel</i>	

¹⁾ For specific engine oil capacities, please see the most current information for the USA at <http://www.audiusa.com/help/maintenance> or for Canada at http://www.audi.ca/ca/brand/en/your_audi/audi_services_and/Care_and_Maintenance/schedule.html or call 800-822-2834.

Consumer Information

Warranty coverages

Your Audi is covered by the following warranties:

- *New Vehicle Limited Warranty*
- *Limited Warranty Against Corrosion Perforation*
- *Emissions Control System Warranty*
- *Emissions Performance Warranty*
- *California Emissions Control Warranty (USA vehicles only)*
- *California Emissions Performance Warranty (USA vehicles only)*

Detailed information regarding your warranties can be found in your **Warranty & Maintenance booklet**.

Operating your vehicle outside the U.S.A. or Canada

Government regulations in the United States and Canada require that automobiles meet specific emission regulations and safety standards.

Therefore, vehicles built for the U.S.A. and Canada differ from vehicles sold in other countries.

If you plan to take your vehicle outside the continental limits of the United States or Canada, there is the possibility that:

- unleaded fuels for vehicles with catalytic converter may not be available;
- fuel may have a considerably lower octane rating. Improper fuel may cause engine damage;
- service may be inadequate due to lack of proper service facilities, tools or testing equipment;
- replacement parts may not be readily available.
- Navigation systems for vehicles built for the U.S.A. and Canada will not necessarily work in Europe, and may not work in other countries outside of North America.



Note

Audi cannot be responsible for mechanical damage that could result from inadequate fuel, service or parts availability.

Audi Service Repair Manuals and Literature

Audi Official Factory Service Manuals and Literature are published as soon as possible after model introduction. Service Manuals and literature are available to order from the Audi Technical Literature Ordering Center at:

www.audi.techliterature.com

Maintenance

General

Your vehicle has been designed to help keep maintenance requirements to a minimum. However, a certain amount of regular maintenance is still necessary to assure your vehicle's safety, economy and reliability. For detailed vehicle maintenance consult your Warranty & Maintenance booklet.

Under difficult operating conditions, for example at extremely low outside temperatures, in very dusty regions, when towing a trailer very frequently, etc., some service work should be performed between the intervals specified. This applies particularly to:

- oil changes, and
- cleaning or replacing the air filter.



For the sake of the environment

By regularly maintaining your vehicle, you help make sure that emission standards are maintained, thus minimizing adverse effects on the environment.

Important considerations for you and your vehicle

The increasing use of electronics, sophisticated fuel injection and emission control systems, and the generally increasing technical complexity of ►

today's automobiles, have steadily reduced the scope of maintenance and repairs which can be carried out by vehicle owners. **Also, safety and environmental** concerns place very strict limits on the nature of repairs and adjustments to engine and transmission parts which an owner can perform.

Maintenance, adjustments and repairs usually require special tools, testing devices and other equipment available to specially trained workshop personnel in order to assure proper performance, reliability and safety of the vehicle and its many systems.

Improper maintenance, adjustments and repairs can impair the operation and reliability of your vehicle and even void your vehicle warranty. Therefore, proof of servicing in accordance with the maintenance schedule may be a condition for upholding a possible warranty claim made within the warranty period.

Above all, operational safety can be adversely affected, creating unnecessary risks for you and your passengers.

If in doubt about any servicing, have it done by your authorized Audi dealer or any other properly equipped and qualified workshop. We strongly urge you to give your authorized Audi dealer the opportunity to perform all scheduled maintenance and necessary repairs. Your dealer has the facilities, original parts and trained specialists to keep your vehicle running properly.

Performing limited maintenance yourself

The following pages describe a limited number of procedures which can be performed on your vehicle with ordinary tools, should the need arise and trained personnel be unavailable. Before performing any of these procedures, always thoroughly read all of the applicable text and carefully follow the instructions given. Always rigorously observe the **WARNINGS** provided.

Before you check anything in the engine compartment, always read and heed all WARNINGS ⇨ ⚠ and ⇨ ⚠ in *Working in the engine compartment* on page 155.



WARNING

- Serious personal injury may occur as a result of improperly performed maintenance, adjustments or repairs.
- Always be extremely careful when working on the vehicle. Always follow commonly accepted safety practices and general common sense. Never risk personal injury.
- Do not attempt any of the maintenance, checks or repairs described on the following pages if you are not fully familiar with these or other procedures with respect to the vehicle, or are uncertain how to proceed.
- Do not do any work without the proper tools and equipment. Have the necessary work done by your authorized Audi dealer or another properly equipped and qualified workshop.
- The engine compartment of any motor vehicle is a potentially hazardous area. Never reach into the area around or touch the radiator fan. It is temperature controlled and can switch on suddenly - even when the engine is off and the ignition key has been removed. The radiator fan switches on automatically when the coolant reaches a certain temperature and will continue to run until the coolant temperature drops.
- Always remove the ignition key before anyone gets under the vehicle.
- Always support your vehicle with safety stands if it is necessary to work underneath the vehicle. The jack* supplied with the vehicle is not adequate for this purpose and could collapse causing serious personal injury.
- If you must work underneath the vehicle with the wheels on the ground, always make sure the vehicle is on level ground, that the wheels are always securely blocked and that the engine cannot be started.
- Always make sure the transmission selector lever (automatic transmission) is in P (Park position) and the park brake is applied.



For the sake of the environment

- Changing the engine settings will adversely affect emission levels. This is detrimental to the environment and increases fuel consumption.
- Always observe environmental regulations when disposing of old engine oil, used brake fluid, dirty engine coolant, spent batteries or worn out tires.
- Undeployed airbag modules and pretensioners might be classified as Perchlorate Material -special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate. When the vehicle or parts of the restraint system including airbag modules safety belts with pretensioners are scrapped, all applicable laws and regulations must be observed. Your authorized Audi dealer is familiar with these requirements and we recommend that you have your dealer perform this service for you.

Accessories and technical changes

Additional accessories and parts replacement

Always consult an authorized Audi dealer before purchasing accessories.

Audi vehicles that are constructed with advanced materials like Steel/Aluminum (Hybrid construction), Aluminum (Audi Space Frame), and/or Aluminum/Carbon Fiber (Ultra Advanced Light Weight Materials) are as unique as their drivers. Therefore, the availability of certain parts needed for repair, restoration, or reconstruction will be restricted, or parts will be unavailable, if the vehicle is not repaired at an authorized Audi collision repair facility. This includes but is not limited to structural parts which require specialized training and equipment to restore their crash-worthiness back to the original NHTSA and IIHS performance.

Your vehicle incorporates the latest safety design features ensuring a high standard of active and passive safety.

This safety could be compromised by non-approved changes to the vehicle. For this reason, if parts have to be replaced, please observe the following points when installing additional accessories:

Approved Audi accessories and genuine Audi parts are available from authorized Audi dealers.

These dealers also have the necessary facilities, tools and trained specialists to install the parts and accessories properly.



WARNING

Using the wrong spare parts or using non-approved accessories can cause damage to the vehicle and serious personal injury.

- Use only accessories expressly approved by Audi and genuine Audi spare parts
- These parts and accessories have been specially designed to be used on your vehicle.
- Never install accessories such as telephone cradles or beverage holders on airbag covers or within the airbag deployment zones. Doing so will increase the risk of injury if airbags are triggered in an accident!
- Before you check anything in the engine compartment, always read and heed all WARNINGS ⇒ page 155.



Note

- If items other than genuine Audi spare parts, add-on equipment and accessory items are used or if repair work is not performed according to specified methods, this can result in severe damage to your vehicle's engine and body (such as corrosion) and adversely affect your vehicle's warranty.
- If emergency repairs must be performed elsewhere, have the vehicle examined by an authorized Audi dealer as soon as possible.
- The manufacturer cannot be held liable for damage which occurs due to failure to comply with these stipulations.

Technical Modifications

Our guidelines must be complied with when technical modifications are made.

Always consult an authorized Audi dealer **before** starting work on any modifications.

This will help ensure that vehicle function, performance and safety are not impaired ⇒ ⚠.

Attempting to work on electronic components and the software used with them can cause malfunctions. Because of the way electronic components are interconnected with each other, such malfunctions can also have an adverse affect on other systems that are not directly involved. This means that you risk both a substantial reduction in the operational safety of your vehicle and an increased wear of vehicle parts ⇒ ⚠.

Authorized Audi dealers will perform this work in a professional and competent manner or, in special cases, refer you to a professional company that specializes in such modifications.

WARNING

Improper repairs and modifications can change the way vehicle systems work and cause damage to the vehicle and serious personal injury.

Note

If emergency repairs must be performed elsewhere, have the vehicle examined by an authorized Audi dealer as soon as possible.

Declaration of compliance for telecommunications equipment and electronic systems

The manufacturer is not liable for radio malfunctions that are caused by unauthorized changes to the equipment.

Equipment

The following equipment complies with FCC section 15 and RSS-Gen:

- Audi adaptive cruise control*
- Audi side assist*
- Electronic immobilizer
- Remote control key
- Cell phone package*

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-Gen

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

CNR-Gen

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage;
- 2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

- A**
- A/C (automatic climate control system) 54
 - A/C (manual climate control system) 52
 - ABS
 - refer to* Anti-lock braking system 89
 - Accessories 44, 214
 - Adaptive dampers 81
 - Adaptive light 81
 - also refer to* Audi adaptive light 16
 - Additional accessories 214
 - Adjusting the air distribution
 - Automatic climate control system 55
 - Manual climate control system 52
 - Adjusting the air vents
 - Automatic climate control system 55
 - Manual climate control system 52
 - Adjusting the center console lighting 35
 - Adjusting the temperature
 - Heating/ventilation system and manual climate control system 52
 - Advanced key
 - refer to* Convenience key 61
 - Airbag 114
 - Airbag system 129
 - Advanced Airbag System 118
 - Advanced Airbag System components . . . 120
 - Care 127
 - Children 135
 - Child restraints 136
 - Components (front airbags) 120
 - Danger of fitting a child safety seat on the front passenger seat 115
 - Disposal 127
 - Front airbags 118
 - How do the front airbags work? 122
 - How many airbags does my vehicle have? . 120
 - How the Advanced Airbag System components work together 122
 - Important information 114
 - Indicator light 124
 - Monitoring 124
 - PASSENGER AIR BAG OFF light 125
 - Repairs 127
 - Safety instructions 126
 - Side airbags 128
 - Side curtain airbags 131
 - Weight-sensing mat 136
 - When must the system be inspected? . . . 124
 - Air pressure (tires) 176
 - Air pressure (tire) 183
 - All season tires 181
 - All weather lights 33
 - All wheel drive 93
 - Anti-freeze
 - Windshield washer system 165
 - Anti-lock braking system 89
 - Anti-Slip Regulation 89
 - Armrest 43
 - ASR
 - refer to* Anti-Slip Regulation 89
 - Audi adaptive light 16
 - Audi drive select 80
 - Audi Service Repair Manuals and Literature . 212
 - Audi side assist 78
 - Adjusting the brightness 80
 - Cleaning the sensors 186
 - Sensor range 78
 - Switching on and off 80
 - AUTO
 - Automatic climate control system 54
 - Automatic headlights 33
 - Auto Lock (central locking system) 22
 - Automatic belt retractor 109
 - Automatic climate control
 - refer to* Climate control system
 - (automatic) 51, 54
 - Automatic climate control system
 - refer to* Climate control system
 - (automatic) 51, 54
 - Automatic transmission 66
 - Driving tips 69
 - Emergency mode 71
 - Hill descent control 70
 - Kick-down 71
 - Manual shifting 70
 - Selector lever emergency release 72
 - Selector lever positions 67
 - Steering wheel with shift paddles 70
 - tiptronic mode 70
 - Automatic wipe/wash system 38
 - Auto Safety Hotline 104
 - Average consumption 19

Average speed	19	Center armrest	43
B		Central locking	22
Bag/securing hooks	46	Certification	215
Bag hooks	48	Changing engine oil	161
Battery		Child restraints	
Jump starting	203	Danger of using child restraints in the front seat	115
<i>also refer to</i> Vehicle battery	163	Where can I get additional information about child restraints and their use?	151
Before driving	97	Child restraints system anchors	147
Belt tensioners	112	Child safety	134
Blended gasoline	152	Important safety instructions for using child safety seats	137
Blower		Important things to know when driving with children	134
Automatic climate control system	55	Installing a child restraint using the LATCH system	149
Heating/ventilation system and manual climate control system	52	Mounting and releasing the anchorage hook	149
Booster seats	142	Tether anchors	149
Brakes	91	Tether straps	149
Brake assist	89	Child safety lock	30
Brake booster	91	Child safety seats	140
Brake fluid	163	Booster seats	142
Electromechanical parking brake	63	Convertible child seats	141
Emergency braking function	64	Convertible locking retractor	146
New brake pads	91	Danger of using child restraints in the front seat	115
Worn brake pads	14	How do I properly install a child safety seat in my vehicle?	137
Breaking in		Infant seats	140
New brake pads	91	LATCH system	149
New engine	57	Lower anchorages	148
New tires	173	Safety instructions	137
Bulbs	201	Securing	144
C		Unused safety belts on the rear seat	139
California Proposition 65 Warning	156	Cleaning	185
Battery specific	164	Cleaning/removing ice from windows	187
Capacities		Cleaning Alcantara	188
Fuel tank	210	Cleaning artificial leather	188
Washer fluid reservoir	210	Cleaning carbon parts	187, 188
Caps for wheel bolts, removing	193	Cleaning controls	187
Care	185	Cleaning decorative parts and trim	186, 187
Cargo area		Cleaning exhaust tail pipes	186
<i>refer to</i> Loading the luggage compartment	102	Cleaning plastic parts	187
Cargo bag	47	Cleaning rims	186
Cargo floor	49	Cleaning textiles	188
Cargo mat	48		
Catalytic converter	155		

Cleaning the tail lights	186	Coolant level checking	162
Climate control system		Coolant temperature	8
Drive select	81	Crossing water	57, 66
Climate control system (automatic)	51	Cruise control system	76
AUTO (automatic mode)	54	Cup holders	45
Changing the temperature unit	55	Current consumption	19
Description	51		
Key recognition	51	D	
Operation	54	Data recorder	95
Synchronizing	54	Date	9
Climate control system (manual)		Daytime running lights	33
Description	51	Declaration of compliance	215
Operation	52	Defrosting (windows)	
Closing		Automatic climate control system	55
Hood	157	Manual climate control system	52
Panorama glass roof	31	DEF (instrument cluster)	9
Windows	30	Determining correct load limit	180
Closing/opening		Digital compass	40
<i>refer to</i> Unlocking/locking	24	Dimensions	210
Cockpit (overview)	6	Dimming the exterior mirrors	36
Coming home	34	Dimming the rearview mirror	36
Compact spare tire	197	Display	
Compartments	45, 46	Cleaning	187
Compass in the mirror	40	Distance	19
Compliance	215	Doors	
Consumer Information	104, 212	Child safety lock	30
Consumption (fuel)	19	Emergency locking	26
Contacting NHTSA	104	Driver information system	
Convenience key		Driver messages	19
Starting the engine	61	Efficiency program	20
Stopping the engine	62	On-board computer	19
Switching the ignition on	61	Operating using the multifunction steering	
Unlocking/locking	24	wheel	19
Convenience opening/closing	31	Operating using windshield wiper lever ...	18
Convertible child safety seats	141	Overview	18
Convertible locking retractor		Service interval display	165
Activating	146	Driver seat	
Deactivating	146	<i>refer to</i> Seating position	98
Using to secure a child safety seat	146	Drive select	
Cooling mode (automatic climate control sys-		<i>refer to</i> Audi drive select	80
tem)	54	Driving economically	57
Cooling mode (manual climate control sys-		Driving offroad	65
tem)	52	Driving safely	97
Cooling system		Driving through water	57, 66
Adding coolant	162	Driving time	19
Coolant	162		

Dust filter		
<i>refer to</i> Pollutant filter	51	
E		
EDL		
<i>refer to</i> Electronic Differential Lock	89	
Efficiency program		
Fuel economy messages	21	
Other equipment	20	
Overview	20	
Electromechanical parking brake	63	
Electromechanical steering	93	
Electronic Differential Lock	89	
Electronic immobilizer	23	
Electronic stabilization control	89	
Electronic Stabilization Control		
Hill descent assist	91	
Offroad mode	90	
Emergency assistance	191	
Emergency braking function	64	
Emergency flashers	34	
Emergency locking the front passenger's door	26	
Emergency operation		
Front passenger's door	26	
Fuel filler door	155	
Luggage compartment lid	29	
Panorama glass roof	32	
Sunshade (roof)	32	
Emergency release		
Selector lever	72	
Emergency starting	203	
Emergency unlocking/locking		
On lock cylinder	26	
Emissions control system		
Catalytic converter	155	
Energy management	94	
Engine		
Coolant	162	
Starting/stopping (convenience key)	61, 62	
Starting/stopping (ignition lock)	60	
Starting with jumper cables	203	
Stopping (ignition lock)	60	
Engine compartment	155	
Engine oil	158	
Adding	160	
Changing	161	
Checking the engine oil level	160	
Dipstick	160	
Economy	160	
Oil consumption	159	
Oil grades	158	
Specification and viscosity	158	
Engine speed limitation (indicator light)	15	
Environment		
Proper disposal of drained engine oil	161	
Unleaded gasoline	152	
EPC (engine control)	14	
ESC		
<i>refer to</i> Electronic stabilization control	89	
Event Data Recorder (EDR)	95	
Exterior lighting	33	
Exterior mirrors		
Adjusting	36	
Dimming	36	
Heating	36	
F		
Fastening		
Booster seats	142	
Convertible child safety seats	141	
Infant seats	140	
Federal Communications Commission (FCC)	215	
Floor mats	101	
Folding the rear seats	47	
Foot pedals	101	
For the sake of the environment		
Environmentally-friendly driving	57	
Fueling	153	
Leaks	156	
Roof rack	50	
Freeze protection		
Coolant	162	
Front airbags		
Description	118	
How they work	122	
Frontal collisions and the laws of physics	107	
Front seats	42	
Adjusting	99	
Child restraints in the front seat	115	
Fuel	152	
Additives	152	
Blended gasoline	152	

Current consumption	19
Fuel gauge	8, 9
Fuel tank capacity	210
Gasoline	152
Gasoline additives	153
Saving fuel	57, 81
Fuel economy messages (efficiency program) ..	21
Fueling	
Fuel filler door emergency release	155
Fuel gauge	9
Fuel tank capacity	210
Opening the fuel filler door	153
Fuses	199

G

Garment hooks	46
Gas discharge lamps	201
Gasoline	152
Octane rating	152
Recommendation	152
Generator (indicator light)	13
Glossary of tire and loading terminology ..	169
Glove compartment	45
Gross Vehicle Weight Rating (GVWR)	209
Ground clearance	66

H

Headlight range control	33
Headlights	
Cleaning	186
Headlight range control	33
Head restraints	100
Adjusting	43, 44, 100
Removing and installing	44
Heated	
Exterior mirrors	36
Rear window (automatic climate control system)	55
Rear window (manual climate control system)	53
Seats (automatic climate control system) ..	55
Washer nozzles	38
Heavy clothing and safety belts	108
High beams	34
Hill descent assist	91
Hill descent control	70

Hill hold assist	65
<i>also refer to</i> Hill hold assist	65
Hold assist (hill)	65
Horn	6
How are child restraint system anchors related to child safety	147
How many airbags does my vehicle have? ..	120
How safety belt pretensioners work	112

I

Ignition	
Switching on and off (convenience key) ...	61
Switching on and off (ignition lock)	60
Imbalance (wheels)	175
Immobilizer	23
Important things to do before driving	97
Improperly worn safety belts	112
Indicator lights	10
Airbag system	124, 125
PASSENGER AIR BAG OFF	125
Infant seats	140
Inspection interval	165
Installing child safety seats	
Safety belts	144
Installing the upper tether strap on the anchorage	150
Instrument cluster	8
Cleaning	187
Instruments	8
Adjusting the lighting	35
Interior lighting	35
Interior lighting	35
Interval mode (windshield wipers)	38

J

Jack	194
Jump-starting	203
Jumper cables	204

K

Key	23
Key not recognized	63
Key recognition	51
Key replacement	23
Replacing the battery	23

- Kick-down (automatic transmission) 71
- L**
- LATCH 147
 Description 148
 Installing a child restraint 149
 Location 148
 Mounting and releasing the anchorage
 hook 149
 Leather care/cleaning 188
 Leaving home 34
 Light/rain sensor
 Headlights 33
 Interval mode (windshield wipers) 38
 Lighting
 Exterior 33
 Interior 35
 Lights
 Interior/reading lights 35
 Interior lighting 35
 Loading the luggage compartment 102
 Locking/unlocking
 refer to Unlocking/locking 24
 Low-profile tires 182
 Low beam headlights 33
 Lower universal anchorages (Canada) 147
 Luggage compartment 46
 Luggage compartment lid 27
 Storing cargo correctly 102
 also refer to Loading the luggage compart-
 ment 102
 Luggage compartment net 47
 Luggage rack 49
 Lumbar support 42
- M**
- Maintenance 212
 Maintenance intervals 165
 Malfunction indicator lamp (MIL) 14, 17
 Manual climate control system
 refer to Climate control system
 (manual) 51, 52
 Mirror compass 40
 Mirrors 36
 Monitoring the Advanced Airbag System 124
- Multifunction steering wheel 19
- N**
- Natural leather care/cleaning 188
 Net 46
 NHTSA
 Contacting 104
 Number of seats 106
- O**
- Occupant seating positions 98
 Octane rating (gasoline) 152
 Odometer 9
 Oil
 refer to Engine oil 158, 160
 Oil change interval 165
 On-board computer 19
 On-Board Diagnostic System (OBD)
 Data Link Connector (DLC) 17
 Malfunction indicator lamp (MIL) 17
 Opening 22
 Fuel filler door 153
 Hood 157
 Luggage compartment lid 28
 Panorama glass roof 31
 Windows 30
 Opening/closing
 refer to Unlocking/locking 24
 Other equipment (efficiency program) 20
 Outside temperature display 9
 Overview (Cockpit) 6
- P**
- Paint damage 187
 Paint number 209
 Panorama glass roof 31
 Emergency closing 32
 also refer to Convenience opening/closing 31
 Parking brake
 refer to Electromechanical parking brake 63
 Parking lights 33
 Parking system
 Parking system plus 83
 also refer to Parking systems 83, 84

Parking systems	82
Adjusting the display/warning tone	87
Cleaning the rearview camera	85
Cleaning the sensors/camera	186
Malfunction	88
Rear parking system	83
Rearview camera	84
Trailer hitch	88
Parking (automatic transmission)	69
Parts replacement	214
Pass-through	48
PASSENGER AIR BAG OFF light	125
Pedals	101
Physical principles of a frontal collision	107
Polishing	187
Pollen filter	
<i>refer to</i> Pollutant filter	51
Pollutant filter	51
Power seat adjustment	42
Power windows	30
Child safety lock	30
Malfunction	31
Pregnant women	
Special considerations when wearing a safety belt	111
Proper safety belt position	110
Proper seating position	
Front passenger	99
Occupants	98
Rear passengers	99
Protective liner	49

Q

quattro (all wheel drive)	93
Question	
What happens to unbelted occupants?	107

R

Radio Standards Specification (RSS)	215
Rain/light sensor	
Headlights	33
Interval mode (windshield wipers)	38
Raising the vehicle	207
Range (fuel level)	19
Reading lights	35

Rear fog lights	33
Rearview camera	
<i>refer to</i> Parking systems	83, 84
Rear window defogger	
Automatic climate control system	55
Manual climate control system	53
Rear window wiper	
Replacing wiper blades	39, 40
Recirculation mode	
Automatic climate control system	55
Manual climate control system	53
Refueling	153
Remote control	
<i>refer to</i> Remote control key	23
Remote control key	23
LED	23
Personalization	23
Replacing the battery	23
Synchronization	24
Unlocking/locking	24
Repair manuals	212
Repairs	
Airbag system	127
Replacement key	23
Replacing	
Light bulbs	201
Replacing wiper blades	39, 40
Reporting Safety Defects	104
Reset button (trip odometer)	9
Resetting the trip odometer	9
Retractor	109
Rims	180
Roof load	49
Roof rack	49

S

Safe driving habits	97
Safety	
Airbag system	114
Belts	106
Cargo	102
Correct seating position	98
Pedal area	101
Safety belt position	110
Safety belt height adjustment	111
Safety belts worn by pregnant women	111

- Safety belt pretensioner
 - Service and disposal 113
- Safety belts 106, 109
 - Cleaning 187
 - Danger to passengers who do not wear a safety belt 107
 - Fastening 109
 - Height adjustment 111
 - Improperly worn 112
 - Not worn 107
 - Safety belt position 110
 - Safety instructions 108
 - Securing child safety seats 144
 - Special considerations for pregnant women 111
 - Unfastening 111
 - Warning/indicator light 106
 - Worn properly 108
- Safety instructions
 - for side curtain airbags 133
 - for using child safety seats 137
 - for using safety belts 108
 - Monitoring the Advanced Airbag System 126
- Safety systems 14
- Seat
 - Number of seats 106
- Seat adjustment
 - Head restraints 100
- Seat belts
 - refer to* Safety belts 106
- Seat heating
 - Automatic climate control system 55
 - Manual climate control system 53
- Seating capacity 106
- Seating position
 - Driver 98
 - Front passenger 99
 - How to adjust the front seats 99
 - Incorrect seat position 100
 - Occupants 98
 - Rear passengers 99
- Seats
 - Adjusting 42
 - Cleaning 188
 - Correct seating position 98
 - Folding 47
- Selective wheel torque control 89
- Selector lever (automatic transmission)
 - Emergency operation 72
 - Position 67
- Service and disposal
 - Safety belt pretensioner 113
- Service interval display 165
- Service position
 - refer to* Replacing wiper blades 39
- Setting the temperature
 - Automatic climate control system 54
- Shift paddles (automatic transmission) 70
- Side airbags
 - Description 128
 - How they work 129
- Side assist
 - refer to* Audi side assist 78
- Side curtain airbags 131
 - Description 131
 - How they work 132
 - Safety instructions 133
- Ski bag 48
- Snow chains 181
- Sockets 44
- Sources of information about child restraints and their use 151
- Space-saving spare tire (compact spare tire) 197
- Spare tire 197
- Speedometer 8
- Speed warning system 76
- Stabilization control
 - refer to* Electronic stabilization control 89
- START ENGINE STOP button 61
- Starting (engine) 60, 61
- Steering
 - Electromechanical steering 93
 - Locking (convenience key) 62
 - Locking (ignition lock) 60
 - also refer to* Electromechanical steering 93
- Steering wheel
 - Adjusting 59
 - Shift paddles (automatic transmission) 70
- Steps for determining correct load limit 180
- Stopping (engine) 60, 62
- Storage compartments 45
- Subwoofer 198

Sunroof	
<i>refer to</i> Panorama glass roof	31
Sunshade	
Emergency closing (panorama glass roof)	32
Sun visors	37
Symbols	
<i>refer to</i> Indicator lights	10

T

Tachometer	8, 9
Technical data	209
Technical modifications	215
Temperature display	
Outside temperature	9
Temperature indicator	
Coolant	8
Temporary spare tire	197
Tether anchors	149
Tether strap	149
Tie-down rings	103
Tie-downs	47
Time	9
tiptronic mode (automatic transmission)	70
tiptronic (automatic transmission)	66
Tires	166
All wheel drive	93
Low-profile tires	182
Replacing	191
Service life	175
Tire pressure	176
Tire pressure monitoring system	183
Tire pressure table	177
Tire pressure (trailer towing)	73
Treadwear Indicators	175
Unidirectional	168
Uniform tire quality grading	182
Tires and wheels	
Glossary of tire and loading terminology	169
Tires and vehicle load limits	178
Tool	191
Torn or frayed safety belts	108
Towing	
Tow trucks	205
Towing loop	205, 206
TPMS (Tire Pressure Monitoring System)	183

Trailer towing	73
Parking systems	88
Trailer load	73
Turn signals	16
Transport Canada	104
Turn signal	34

U

Unfastening safety belts	111
Uniform tire quality grading	182
Unlocking/locking	
By remote control	24
With the central locking switch	25
With the convenience key	24
Use of jumper cables	204

V

Vanity mirror	37
Vehicle	
Care/cleaning	185
Dimensions	210
Out of service	190
Specifications	209
Vehicle battery	163
Charge level	94
Charging	13, 164
Energy management	94
Vehicle control modules	95
Vehicle jack	191, 194
Vehicle key	23
Vehicle tool kit	191
VIN	209

W

Warning lights	
<i>refer to</i> Indicator lights	10
Warranty coverages	212
Washing matte finish paint	185
Weights	209
What happens if you wear your safety belt too loose?	110
What happens to unbelted occupants?	107
What impairs driving safety?	97
Wheel bolt caps	
Removing	193

Wheel bolts	180
Loosening	193
Tightening	193
Wheel covers, removing	193
Wheels	166
Cleaning	186
Glossary of tire and loading terminology .	169
Replacing	191
Tires and vehicle load limits	178
When must a safety belt be replaced?	108
When must the airbag system be inspected? ..	124
Where are lower anchorages located?	148
Window regulators	30
Child safety lock	30
Windows	
Cleaning/removing ice	187
Windshield	
Cleaning	38
<i>also refer to</i> Windshield	38
Windshield washer system	38, 165
Reservoir capacity	210
Winter operation	
Car washes	185
Cooling system	162
Defrosting windows (automatic climate control system)	55
Defrosting windows (manual climate control system)	52
Removing ice from windows	187
Seat heating (automatic climate control system)	55
Snow chains	181
Tires	181
Windshield washer system	165
Winter tires	181
X	
Xenon headlights	201

It has always been Audi's policy to continuously improve its products. AUDI AG reserves the right to make changes in design and specifications, and to make additions or improvements in its products without incurring any obligation to install them on products previously manufactured. This Owner's Manual is based on the current data available when it was printed. Text, illustrations and specifications in this owner's manual are based on the most up-to-date information available at the time of printing, and shall not constitute a basis for liability claims.

These instructions may not be reproduced or translated in whole or in part without written consent of AUDI AG. All rights reserved by AUDI AG.



For the sake of the environment

Printed on environmentally friendly paper
(bleached without chlorine, recyclable)

Owner's Manual
Englisch Nordamerika 01.2017
8U0012721BD



8U0012721BD

www.audi.com