Band User Guide

PHICOMM

CONTENTS

P1 GETTING STARTED
P6 GESTURES
P7 TILES
P9 MENU
P10 SETTINGS
P12 START A WORKOUT
P14 SPECIFICATION
P15 SAFETY WARNING!
P15 HEALTH WARNING!
P16 WORKOUT WARNING!
P17 EC CONFORMITY
P18 FCC REGULATIONS
P19 FCC RF EXPOSURE INFORMATION (SAR)
P21 SPECIFIC ABSORPTION RATE(SAR)

Inhaltsverzeichnis

P32 Grundlagen
P37 Interaktion mit Ihrem Smart Band
P38 Optionen zum Schnellzugriff
P40 Funktionsmenü
P41 Einstellungen
P43 Aktivität Starten
P45 Technische Daten
P46 Sicherheitshinweise
P46 Gesundheitshinweise/Warnungen
P47 Trainingshinweise/Warnungen
P48 EG-KONFORMITÄT
P50 FCC-Erklärung
P50 FCC-Informationen zur HF-Exposition (SAR)
P52 Spezifische Absorptionsrate (SAR)

GETTING STARTED

1. Overview



2. Power on

Connect the charging connector on the USB charging cable to the charging port on the clasp of your band, and plug the USB end of the cable into a power adapter (DC 5V). "W3" will show on the touchscreen.

3. Install PhiLink App

Scan QR code to download PhiLink App

APP download

4. Pairing your mobile phone

Scan QR code on the band touchscreen to pair the band via PhiLink when the band is powered on for the first time(if you skip this step, you may find QR code via Menu->QR code later)

The band is compatible with mobile phones that support Android4.4 or newer and IOS8.0 and above.
Note: Make sure your mobile phone has Bluetooth connection and is within 3m with the band when pairing.

5. Charge

Connect the charging connector on the USB charging cable to the charging port on the clasp of your band, and plug the USB end of the cable into a power adapter (DC 5V). If the notification of charging failed is pop-up, please try it again.

GESTURES

Double tap: start/pause workout
Long press: enter Menu
Swipe: view Tiles, Menu, Settings, Data and device information.
Tap: select
Tap ⮌ back to previous
Wrist raise: Wake screen by raising wrist and facing screen
Dark screen by facing off screen

TILES

Your band has tiles for workouts, heart rate, weather information and more.

Time and Date	Use Time and Date Tile to display time and date.
	Use Step Tile to display daily steps and goal.
	Use Heart Rate Tile to display current and last 4 hour heart rate
	Use Calories Tile to display calories burned via workout and BMR.
	Use Distance Tile to display distance traveled by walking and workout.
	Use Favorite Tile to start your favorite workout.

MENU

Switch to Menu via long press screen or tap More Tile.

	Workouts:show different workouts.
	Compass (calibration before use)
	Alarms (setting via PhiLink)
	QR code
	Settings
	Device information

SETTINGS

You may customize your with Settings Tile.

Language	Language: English, Deutsch
Time	Time: 12-hour, 24-hour
Do not disturb	Do not disturb:turn on/off notifications(default off)
Backlight	Backlight:dark or bright(default dark)
Wrist gesture	Wrist gesture:on or off (default on)
Restore factory settings	Restore factory settings
Autopause	Autopause:when the band detects that you paused a workout, it will pause stopwatch automatically.
Lane	Lane:length of lane (default 25m)
Heart rate	Heart rate monitor:on or off (default on)
Power off	Power off options: select power off or restart band

START A WORKOUT

You may start a workout and the workout data will be synchronized to PhiLink.

1. Long press to enter Menu when screen is unlocked.
2. Tap to enter workouts list.
3. Swip up/down to select a workout.
   Select to start an outside running.
   Select to start an inside running.
   Select to start a hiking.
   Select to start an outside cycling.
   Select to start an open water swimming.
   Select to start a pool swimming.
4. GPS will be turned on to ensure data accuracy. Please start a workout when GPS locating is completed, or you may start a workout skip GPS locating.
5. Double tap screen to start stopwatch.
6. Start workout.
7. The screen will be locked during workout and will be unlocked by double tap or wrist gesture.
8. Swipe up/down to see more information.
9. Double tap screen to stop stopwatch when a workout is completed.
   Tap to resume workout, tap End to end workout.

SPECIFICATION

Mode:	PHICOMM W3
Strap:	245mm*19.4mm
Screen:	0.86in
Display resolution:	144px*72px
Touchscreen:	Yes
Weight:	25g
Water resistant rating:	IP68
Bluetooth:	BT4.2

SAFETY WARNING!

Incorrect handling of the battery may result in a risk of explosion or burn, do not attempt to open, disassemble or repair the battery by yourself. The battery must not be exposed to temperatures above 60°C (140°F). Charge the battery, use only manufacturer approved Li-ion batteries.

When you are using the device, it is normal for the device to get warm. The exterior of the device functions as a cooling surface that transfers heat from inside the unit to the cooler air outside.

HEALTH WARNING!

If you wear a pacemaker, a hearing aid or other implanted medical equipment, consult your doctor before using this device. The optical heart rate sensor of W3 Band uses green light. If you are epileptic or sensitive to flashing light, consult your doctor first.

Smart devices, heart rate sensors and other relevant data are designed for fitness purpose only, not for medical purpose.

and are not suitable for diagnosis, monitoring, treatment or prevention of any disease or disease. Heart rate data are for reference only.

The heart rate sensor can provide accurate heart rate data for the user , but the user's personal physical characteristics , the wearing mode and the type and intensity of the activity may influence the heart rate data.

WORKOUT WARNING!

Before performing any workouts, a body check is required. If you have a history of illness or drug allergy, consult your doctor.

Running: running is a good option for fitness, but do not chase for speed purpose to prevent unnecessary damage to the body.

GPS:when the device is close to any broadband network similar to GPS and other satellite signals, a performance decline may be encountered on the device. In this case, it may affect the signal receiving by the device.

EC CONFORMITY

Phicomm (Shanghai) Co. Ltd
No. 3666, Sixian Rd.
Songjiang District
Shanghai
201616 China

Declares under our sole responsibility that our product PHICOMM W3 is in conformity with the appropriate standards according to the provisions of the EU directive RED (2014/53/EU).

The product contains the following marking: CE

For the Declaration of Conformity, please visit our website: www.phicomm.com

! This device may be operated in all Member States of the EU: ! Keep up to the regulations valid at the point of consumption. Use is restricted according to national law in most Member States of the European Union (EU).

This radio equipment operates with the following frequency bands: Bluetooth BR/EDR/BLE
Maximum radio-frequency power: 8dBm

FCC REGULATIONS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that
  to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

LEGAL INFORMATION ABOUT INTELLECTUAL PROPERTY

All company, product and service names mentioned herein are trademarks, registered trademarks or service marks of their respective owners.

Phicomm (Shanghai) Co. Ltd. reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photo- copying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of Phicomm (Shanghai) Co. Ltd.

DISCLAIMER

Any pre-installed software or data provided as a bundle to this device is subject to the end user license and the responsibility of the issuing software / service provider. The software provider is solely responsible for any claim or liability in connection with or arising out of the software and/or third-party software. Only the issuing party is lawfully be held responsible. Phicomm (Shanghai) Co. Ltd. does not

own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Phicomm (Shanghai) Co. Ltd. will not provide any warranty of any kind, neither expressly nor implicitly, and will assume neither will Phicomm (Shanghai) Co. Ltd. provide support to customers who use these third-party software and applications or their interfaces. Any third party's use of these third-party software and applications. Third-party software and applications may be changed, suspended or terminated at any time. Phicomm (Shanghai) Co. Ltd. does not guarantee that any content or service would be maintained for any period during its availability. Third-party service providers provide content and services through software or network tools outside the direct control of Phicomm (Shanghai) Co. Ltd. To the greatest extent permitted by applicable law, it is explicitly stated that Phicomm (Shanghai) Co. Ltd. shall not compensate or be liable for services provided by third-party service providers or the interruption or termination of third-party content or services. Phicomm (Shanghai) Co. Ltd. will not be responsible for the legality, quality or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works, such as texts, images, videos or software, etc. Phicomm (Shanghai) Co. Ltd. shall not be liable for any effects including incompatibility between the settings on this product, which result from installing software or uploading or downloading the third-party works.

LIMITATION OF DAMAGES

To the maximum extent permitted by applicable law, in no event shall Phicomm (Shanghai) Co. Ltd be liable for any special incidental, indirect or consequential damages or lost profits, business, revenue, data, goodwill or anticipated savings.
The maximum liability (this limitation shall not apply to liability for personal injury to the extent applicable law prohibits such a limitation) of Phicomm (Shanghai) Co. Ltd. Arising from the use of the product described in this document shall be limited to the amount paid by customers for the purchase of this product.

IMPORTANT HEALTH INFORMATION AND SAFETY PRECAUTIONS

When using this product, the safety precautions below must be taken to avoid possible liabilities and damages.
Retain and follow all product safety and operating instructions. Observe all warnings in the operating instructions on the product.
To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, observes the following precautions.

SAFETY PRECAUTIONS FOR PROPER INSTALLATION

CAUTION: Connecting to a weaker inappropriate charger can result in damage to your device.

SAFETY PRECAUTIONS FOR POWER SUPPLY UNIT

Use the correct power source
This product can only be charged with matching battery, standard external power source or battery, external power source appointed by Phicomm (Shanghai) Co. Ltd.
Phicomm (Shanghai) Co. Ltd. is not liable for any device damage caused by incompatibility or failure to the use of unauthorized battery or external power source.

ENVIRONMENT RESTRICTIONS

Do not use this product in gas stations, fuel depots, chemical plants or where blasting operations are in progress, or in potentially explosive atmospheres such as below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Please be aware that sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

EXPLOSIVE ATMOSPHERES

In any area with a potentially explosive atmosphere or where flammable materials exist, the product should be turned off and the user should obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised not to use the equipment at refueling areas such as service stations or near fuels or chemicals. Users are advised to observe restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. These include fueling areas, below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as dust, or metal powders.

SAFETY PRECAUTIONS FOR RF EXPOSURE

• Avoid using your device near metal structures (e. g. the steel frame of a building).
• Avoid using the device near strong electromagnetic sources, such as microwave ovens, sound speakers, TV and radio.
• Use only original manufacturer-approved accessories.
• Use of non-original manufacturer-approved accessories

may violate your local RF exposure guidelines and should be avoided.

INTERFERENCE WITH MEDICAL EQUIPMENT FUNCTIONS

This product may cause medical equipment to malfunction. The use of this device is forbidden in most hospitals and medical clinics.
If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy.

HEARING AID DEVICES

Some devices may interfere with some hearing aid devices. In the event of such interference, you may want to consult your service provider, or call customer service line to discuss alternatives.

GENERAL PRECAUTIONS

AVOID APPLYING EXCESSIVE PRESSURE TO THE DEVICE
Do not apply excessive pressure on the device to prevent damaging them.

DEVICE IS GETTING WARM AFTER PROLONGED USE

When using your device for prolonged periods the device may become warm. In most cases this condition is normal and therefore should not be interpreted as a problem with the device.

HEED SERVICE MARKING

Except as explained in the user manual, do not repair any product yourself. Service on components inside the device should be done by an authorized service outlet or provider.
PHICOMM is entitled to use new or reconditioned components in fixing a claim. Exchanged products provided they have the same functionality as the parts to be replaced.

DAMAGE REQUIRING SERVICE

Unplug the device from the electrical outlet and refer servicing to an authorized service center or provider under the following conditions:
• If liquid has been spilled or an object has fallen onto the product.
• The product has to been exposed to rain or water.

• There are noticeable signs of overheating.
• The product does not operate normally when you follow the operating instructions.

AVOID HOT AREAS

The product should be placed away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that products heat.

AVOID USING YOUR DEVICE AFTER A DRAMATIC CHANGE IN TEMPERATURE

When you move your device between environments with very different temperature and/or humidity ranges, condensation may form on or within the device. To avoid damaging the device, allow sufficient time for the moisture to evaporate before using the device.

NOTICE: When taking the device from low-temperature conditions into a warmer environment or from high-temperature conditions into a cooler environment, allow the device to acclimate to room temperature before turning on power.

AVOID PUSHING OBJECTS INTO THE DEVICE

Never push objects of any kind into cabinet slots or other openings in the product. Slots and openings are provided for ventilation. These openings must not be blocked or covered.

MOUNTING ACCESSORIES

Do not use the product on an unstable table, cart, tripod or bracket. Mount the product only as recommended by the manufacturer' s instructions, and should use a mounting accessory recommended by the manufacturer.

AVOID UNSTABLE MOUNTING

Do not place the product with an unstable base.

USE PRODUCT WITH APPROVED EQUIPMENT

This product should be used only with personal computers and options identified as suitable for use with your equipment.

CLEANING

Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning, but NEVER use water to clean the device.
Do not use harsh chemicals, cleaning solvents or treatments featuring that it could damage dirt and sweat on its surface. The device itself does not have a stain-resistant function. In case of smudginess and dyeing, please wipe it with clean damp sponge immediately. Please keep the device dry when necessary.

CAUTION

Update your operating system with caution.
• Improper operation or unforeseen external factors may cause an operating system update fails; the device will not work properly. If such a situation occurs, you need to send the unit in for repair.
• The device operating system can cause security risks. Please install only updates provided by Phicomm, if not you will void the warranty and a repair is chargeable.

For detailed product information please visit our website: www.phicomm.com/cn

Grundlagen

1. Übersicht

2. Einschalten

Ihr Smart Band schaltet sich automatisch ein, wenn Sie zunächst den USB-Anschluss des beiliegenden Ladekabels an einen Apapter (DC 5V) anschließen und dann das andere Ende an die Rückseite des Geräts. Danach wird „W3" auf dem Display angezeigt.

3. Philink installieren

Scannen Sie den QR-Code unten, um die zugehörige APP Philink herunterzuladen.

APP Download

4. Gerät mit Smartphone koppeln

Schließen Sie zunächst den USB-Anschluss des Ladekabels an einen Apapter (DC 5V) anund dann das andere Ende an die Rückseite des Geräts. (Ist Aufladen fehlgeschlagen, verbinden Sie das Ladekabel erneut)

Systemanforderung: Android 4.4 oder höher/iOS 8.0 oder höher

5. Aufladen

Schließen Sie zunächst den USB-Anschluss des Ladekabels an einen Apapter (DC 5V) anund dann das andere Ende an die Rückseite des Geräts. (Ist Aufladen fehlgeschlagen, verbinden Sie das Ladekabel erneut)

Interaktion mit Ihrem Smart Band

Doppelt tippen: Aktivität beginnen oder anhalten; Display entsperren

Gedrückt halten: Menü öffnen

Nach oben/unten wischen: zwischen verschiedenen Seiten wechseln

Tippen: eine Option wählen. Auf ⮌ tippen, um zur letzten Seite zurückzukehren

Beim Armheben Display aktivieren: Handgelenk heben und zum Körper drehen; um Display zu aktivieren. Zur Deaktivierung das Handgelenk vom Körper weg drehen

Optionen zum Schnellzugriff

Das Gerät bietet Ihnen mehrere Möglichkeiten zum Schnellzugriff

	Mehr
Zeitanzeige	Anzeige von Uhrzeit und Datum
	Anzeige von täglicher Zielschrittzahl und absolvierter Schrittzahl
Herzfrequenz	Anzeige der momentanen Herzfrequenz und drucktechn. Ruheherzfrequenz in letzten 4 Stunden
Kalorien	Anzeige des täglichen Gesamtkalorienverbrauchs, einschl. Leistungsumsatz und Grundumsatz
Distanz	Anzeige der gesamten zurückgelegten Strecke, einschl. Gehen und Training
Favoriten	Anzeige Ihrer Lieblings-Training-Aktivität. Startet tippen und die Aktivität starten

Funktionsmenü

Um Menü zu öffnen, auf „Mehr" tippen oder das Display gedrückt halten.

	Aktivitätenliste
	Kompass (vor der Verwendung kalibrieren)
	Wecker (über APP einstellen)
	QR-Code
	Einstellungen
	Geräteinformation

Einstellungen

Sie können Ihr Band einstellen

Sprache	Systemsprache einstellen: Englisch oder Deutsch
Zeitformat	12/24-Stunden-Format
Nicht stören-Modus	Bei aktiviertem Nicht-Stören-Modus werden alle Benachrichtigungen blockiert: Die Standardeinstellung ist "Ein"
Hintergrund	Bildschirmhelligkeit einstellen: Die Standardeinstellung ist "Dunkel"
Armbewegung	Beim Armheben Display aktivieren: Die Standardeinstellung ist "Ein"

Aktivität Starten

Sie können eine Aktivität starten. Bewegungsdaten werden nach dem Abschluss der Aktivität zu PhiLink übertragen

1. Nach Entsperrung des Display gedrückt halten, um Menü zu öffnen
2. Auf tippen und die Aktivitätenliste öffnen
3. Um eine Aktivität zu wählen, nach oben/unten wischen
   Outdoor Laufen
   Indoor Laufen
   Wandern
   Outdoor Radfahren
   Freiwasserschwimmen
   Beckenschwimmen
4. Bei Outdoor-Aktivitäten schaltet sich GPS automatisch ein. Um genaue Bewegungsdaten zu erfassen, starten Sie erst eine Aktivität, wenn die Positionsbestimmung mit GPS abgeschlossen ist. Sie können diesen Schritt aber auch überspringen und direkt starten.
5. Doppelt tippen, um die Stoppuhr zu starten
6. Nun kann es richtig losgehen
7. Während des Trainings wird das Display gesperrt, um versehentliche Bedienung zu verhindern. Zur Entsperrung auf das Display doppelt tippen oder Arm anheben.
8. Nach oben/unten wischen, um weitere Informationen anzuzeigen
9. Nach dem Training auf das Display doppelt tippen, um den Zeitzähler zu stoppen
   Um die Aktivität fortzusetzen, auf ⮌ tippen. Zum Beenden der Aktivität auf Beenden tippen.

Technische Daten

Modell:	PHICOMM W3
Gurtgröße:	245mm * 19.4 mm
Bildschirmgröße:	0.86 Zoll
Bildschirmauflösung:	144 px * 72 px
Touchscreen:	Ja
Gewicht:	25 g
Wasserfestigkeit:	IP 68
Bluetooth:	BT 4.2

Sicherheitshinweise

Verwenden Sie Adapter (Versorgungsspannung = DC 5v, Laststrom = 400mA) zur Aufladung Ihres Geräts.
Das Gerät benutzt integrierten Lithium-Polymer-Akku. Durch unsachgemäße Bedienung können Verletzung, Brand oder sogar Explosion verursacht werden. Versuchen Sie nicht, den Akku selbst zu öffnen, auseinanderzubauen oder zu reparieren. Da Akku darf nicht zerlegt, mechanischem Druck ausgesetzt, durchstochen, kurzgeschlossen, mit Wasser und Feuer in Berührung gebracht oder Temperaturen über 60°C ausgesetzt werden. Laden Sie den Akku in einem Temperatur-Bereich von 0 – 45°C.

Helmethoden daraus ableitbar oder gar vorgesehen.
Der Herzfrequenzsensor kann präzise Herzfrequenzdaten liefern. Jedoch können diese Daten von persönlichen physischen Eigenschaften des Benutzers, der Tragweise sowie der Art und Intensität des Trainings und anderen Faktoren beeinflussen.

Trainingshinweise/Warnungen

Vor jedem Training ist ein Körpertest erforderlich. Bei Krankheit oder Medikamenteneinnahme wenden Sie sich bitte an Ihren Arzt.
Körperliches Training fördert die Gesundheit. Jedoch streben Sie nicht einfach nach hoher Geschwindigkeit, um unnötigen körperlichen Schaden zu vermeiden.
Beim Laufen kann es vorkommen, dass Ihres Breitbandnetzes mit einer ähnlichen Frequenz wie GPS und andere Satellitensignale sie vor der Anwendung unbedingt ihren Arzt.
Bei von W3 ermittelten Herzfrequenz-Daten dienen ausschließlich als Referenz und zu Ihrer Information. Es sind keine Diagnosen, Präventivmaßnahmen, Behandlungsmöglichkeiten oder

EG-KONFORMITÄT

Wir, Phicomm (Shanghai) Co., Ltd., mit Sitz in
No. 3666, Sixian Rd.
Songjiang District
Shanghai
201616 China

erklären in alleiniger Verantwortung, dass die PHICOMM Smart Band W3 in Übereinstimmung mit den relevanten Bestimmungen der Richtlinie 2014/53/EG entspricht.

Das Produkt enthält folgende Kennzeichnung: CE

Die Konformitätserklärung finden Sie unter: www.phicomm.de

! Dieses Gerät darf in allen Mitgliedstaaten der EU betrieben werden.
! Halten Sie sich an die jeweils am Ort des Gebrauchs gültigen Bestimmungen. Die Verwendung dieses Geräts kann in einigen Mitgliedstaaten der Europäischen Union (EU) eingeschränkt sein.

Dieses Funkgerät arbeitet in folgenden Frequenzbändern: Bluetooth BR/EDR/BLE. Und die maximale Hochfrequenzleistung beträgt 8 dBm.

FCC-ERKLÄRUNG

Der Betrieb eines Gerätes im Rahmen der FCC-Bestimmungen Teil 15 unterliegt den folgenden beiden Bedingungen:(1) Dieses Gerät darf keine schädlichen Störungen verursachen. (2) Dieses Gerät muss alle empfangenen Störungen zulassen, wie die ein unerwünschtes Verhalten hervorrufen.

Diese Grenzwerte sollen einen angemessenen Schutz gegen schädliche Interferenzen in einer häuslichen Umgebung bieten. Dieses Gerät erzeugt und verwendet Funksignale und kann diese ausstrahlen. Wenn das Gerät nicht in Übereinstimmung mit den Anweisungen installiert und verwendet wird, kann es Funkstörungen verursachen.

Es kann jedoch nicht garantiert werden, dass solche Interferenzen nicht auftreten. Sollte eine Störung der Kommunikation auftreten, was durch Ein- und Ausschalten des Gerätes festgestellt werden kann, sollten Sie die folgenden Maßnahmen durchführen:
• Antennen neu ausrichten
• Abstand des Geräts zu Radio oder Fernsehgerät vergrößern
• Gerät mit einem anderen Stromkreis als das Radio oder Fernsehgerät verbinden
• den Händler / Hersteller kontaktieren

Jegliche nicht von PHICOMM ausdrücklich genehmigte Änderungen am Gerät führen zum Verlust der Betriebserlaubnis.

Gesundheitshinweise/Warnungen

Falls einen ein herzschrittmacher, Hörgeräte oder andere implantierte medizinische Geräte tragen, sollten Sie vor Verwendung dieses Geräts Ihren Arzt konsultieren.
Der optische Herzfrequenzsensor der W3 blinkt während der Messung grün. Falls Sie lichtempfindlich sind, konsultieren Sie vor der Anwendung unbedingt Ihren Arzt.
Für von W3 ermittelten Herzfrequenz-Daten dienen ausschließlich als Referenz und zu Ihrer Information. Es sind keine Diagnosen, Präventivmaßnahmen, Behandlungsmöglichkeiten oder

FCC-Informationen zur HF-Exposition (SAR)

Für detaillierte Produktinformationen besuchen Sie bitte unsere Homepage:
www.phicomm.de

HAFTUNGSAUSSCHLUSS

Sämtliche Spiele und Anwendungen einschließlich relevant-er Unterlagen oder Dateien, Inhalte, Services oder ergänzende Dokumente, einschließlich, aber nicht darauf beschränkt, Bild, Flash, Video, Audio-Inhalte, Musik oder Text sind bereits vorinstalliert oder im Gerät gebündelt und werden von Phicomm (Shanghai) Co. Ltd. Weder auf ihre Echtheit und Richtigkeit durch entsprechende Software und ServiceAnbieter und garantieren, staatliches Recht, Vorschriften, die guten Sitten oder die Rechte Dritter nicht zu verletzen.

Die Anbieter garantieren die Qualität des Service und der Software, die Sicherheit der Benutzer, anderer Informationen und die Internetsicherheit. Phicomm (Shanghai) Co. Ltd. ist nicht haftbar für Probleme, welche sich aus der Verwendung der Software oder Dienste durch den Benutzer die aus der Verwendung der Software oder Dienste resultieren. Einige Softwareanwendungen und Dienste können eine Internetverbindung verlangen und können somit entsprechende Kosten verursachen.

BESCHRÄNKUNG VON SCHÄDEN

Bis zum äußersten Grad der rechtlichen Zulässigkeit, ist die

Phicomm (Shanghai) Co. Ltd in keinem Falle haftbar für direkte, zufällige, indirekte oder Folgeschäden sowie entgangene Gewinne, Geschäftsabschlüsse, Umsätze, Daten, Firmenwert oder Einsparungen.
Außerdem speichern wir uns frei von im Vertrag klargeben Fällen, die Haftung für Personenschäden, Produkthaftung, Verlust von Zusicherungen, Fahrlässigkeit, Verletzung der Treue- und Sorgfaltspflicht, Verlust von Daten, Verstoß gegen Gesetze oder Richtlinien und Verpflichtungen.

WICHTIGE GESUNDHEITSINFORMATION UND SICHERHEITSVORSICHTSMASSNAHMEN

Um dieses Produkt zu verwenden, müssen Sie die unten stehenden Sicherheitsmaßnahmen gelesen haben, damit mögliche gesetzliche Auswirkungen und Schäden vermieden werden.

SICHERHEITSMASSNAHMEN FÜR DIE RICHTIGE INSTALLATION

ACHTUNG: Das Anschließen mit einem unpassenden schwächeren Ladegerät kann zu einem Stromschlag in Ihrem Gerät führen.

SICHERHEITSMASSNAHMEN FÜR DIE STROMVERSORGUNGSEINHEIT

Verwenden Sie richtige Stromquelle
Dieses Produkt kann nur mit der passenden Batterie, einer externen Stromquelle oder einer anderen externen Stromquelle verbunden werden, die von Phicomm (Shanghai) Co. Ltd. Zugelassen ist.
Phicomm (Shanghai) Co. Ltd. ist für Gerätschaden oder Unfälle nicht verantwortlich, welche aus der Benutzung von dem Gerät mit Verwendung von Batterien oder externer Stromquellen entstehen.

SICHERHEITSHINWEISE ZU DIREKTER SONNENEINSTRAHLUNG

Halten Sie dieses Produkt fern von Feuchtigkeit und hohen Temperaturen. Das Gerät nicht einwickeln, um bei Temperaturen zwischen 0°C und 40°C betrieben zu werden. Niedrigere oder höhere Temperaturbedingungen könnten vorübergehend die Lebensdauer der Batterie verkürzen oder dazu führen, dass sie vorübergehend nicht mehr einwandfrei funktionieren. Lassen Sie das Gerät oder die Batterie nicht innerhalb eines Fahrzeugs oder an anderen Plätzen, wo eine Temperatur von 70°C oder mehr herrscht, liegen. Schützen Sie das

Gerät vor direkter Sonneneinstrahlung, z. B. auf dem Armaturbrett oder hinter Glas, alles kann dazu führen, dass der Geräte-Betriebstemperaturbereich überschritten wird. Vermeiden Sie plötzliche Temperaturänderungen oder so hohe Luftfeuchtigkeit, da es zu Bildung von Kondenswasser im Inneren des Geräts kommen kann.
Wenn das Gerät in Betrieb ist, ist es normal, dass das Gerät warm wird. Die Hülle des Gerätes fungiert als Kühlfläche, die Wärme aus dem Inneren des Gebäuses nach außen in die kühlere Luft transportiert.

UMGEBUNGSEINSCHRÄNKUNGEN

Verwenden Sie dieses Produkt nicht an Tankstellen, Treibstoffdepots, Chemiefabriken oder wo Sprengungen im Gange sind, Bereichen, wo sich Kraftstoff befindet und Gebiete, in denen die Luft Chemikalien und Partikel wie Staub oder Metallpulver (oxiven) enthält.

Bitte beachten Sie, dass Funken in solchen Gebieten eine Explosion verursachen können und die Gefahr körperlicher Verletzungen oder sogar den Tod besteht.

EXPLOSIVE UMGEBUNGEN

In Gebieten, in welchen eine potenziell explosive Atmosphäre existiert oder leicht entzündliche Materialien gelagert werden, muss das Produkt ausgeschaltet werden. Funken in solchen Gebieten können eine Explosion verursachen. Benutzer sollten das Gerät nicht einschalten, wo Explosionen oder ein Feuer verursachen, dass auf körperliche Verletzung oder sogar Todesfälle führen können. Bereiche mit einer potenziell explosiven Atmosphäre sind häufig, aber nicht immer deutlich gekennzeichnet. Dazu gehören Bereiche unter Brennstoff-Lieferanten, unter Deck auf Booten, chemischen Lagerungseinrichtungen und Gebiete wo die Luft Chemikalien oder Partikel wie Staub oder Metallpulver enthält.

Vorsichtsmaßnahmen für die Radiofrequenz Bestrahlung

• Vermeiden Sie es, Ihr Gerät neben Stahlstrukturen zu verwenden (z.B. Stahlgerüst eines Gebäudes).
• Vermeiden Sie es, Ihr Gerät in der Nähe von starken, elektromagnetischen Quellen zu benutzen (z.B. Mikrowelle, Lautsprecher, TV und Radio).
• Verwenden Sie ausschließlich Originalteile des Herstellers.
• Der Gebrauch von nicht originalen Teilen kann zu einer Beschädigung von elektromagnetischen Geräten in der Nähe führen und sollte vermieden werden.

Interferenzen mit medizinischer Ausrüstung

Dieses Produkt kann medizinische Ausrüstung verantassen, sicht mehr einwandfrei zu funktionieren. Der Gebrauch dieses Geräts wird in den meisten Krankenhäusern und medizinischen Einrichtungen verboten.
Wenn Sie selbst ein persönliches medizinisches Gerät verwenden, konsultieren Sie den Hersteller Ihres Geräts, um festzustellen, ob dieses gegen RF Energie entsprechend abgeschirmt ist.

Hörgeräte

Einige Geräte können Hörgeräte stören. Im Falle solcher Interferenzen können Sie Ihren Händler oder den Kundendienst anrufen, um Alternativen zu besprechen.

ALLGEMEINE VORSICHTSMAßNAHMEN

VERMEIDEN SIE ÜBERMÄSSIGEN DRUCK AUF DAS GERÄT

Üben Sie keinen übermäßigen Druck auf das Display und das Gerät aus, um eine Beschädigung zu vermeiden.

DAS GERÄT WIRD BEI LÄNGERER NUTZUNG WARM

Bei Nutzung des Gerätes über einen längeren Zeitraum kann das Gerät warm werden. In den meisten Fällen ist dies normal und sollte daher nicht als ein Problem angesehen werden.

REPARATURHINWEISE BEACHTEN

Mit Ausnahme der Anweisungen in der Bedienungsanleitung, dürfen Sie das Gerät auf keinen Fall selbst reparieren. Reparaturen des Gerätes sollten nur von einem autorisierten Service-Center oder dem Hersteller durchgeführt werden.

REPARATUR BEI BESCHÄDIGUNGEN

Entfernen Sie das Gerät vom Strom und wenden Sie sich u. a. bei den folgenden Problemen an ein autorisiertes Service-Center oder den Anbieter:
• Flüssigkeit wurde über dem Gerät verschüttet oder ein Gegenstand ist in das Gerät gelangt.
• Es liegen deutliche Anzeichen einer Überhitzung vor.
• Das Gerät funktioniert nicht ordnungsgemäß, obwohl Sie der Bedienungs