



MELOMANIA APP

For optimal performance please download the Melomania app and update your earphones before use.

Téléchargez l'application Melomania et mettez à jour vos écouteurs avant utilisation

Laden Sie die Melomania App herunter und aktualisieren Sie Ihre Ohrhörer vor dem Gebrauch.

Descarga la aplicación Melomania y actualiza tus auriculares antes de usarlos

Scarica l'app Melomania e aggiorna gli auricolari prima dell'uso

Ladda ner Melomania-appen och uppdatera dina hörlurar innan användning

使用本產品前，請下載 Melomania 應用程式並更新產品

使用本产品前，请下载 Melomania 应用程序并更新产品

Melomania 앱을 다운로드하고 이어폰을 업데이트한 후 사용하세요.

Melomaniaアプリをダウンロードし、使用前にイヤホンを更新してください。



PAIRING

COUPLAGE KOPPELN EMPAREJAMIENTO ASSOCIAZIONE PARKOPPLING 配對 配对 페어링ペアリング

1.Remove from case

Retirer de l'étui

Aus der Schale nehmen.

Retirar del estuche.

Rimuovi dalla custodia.

Ta ur fodralet.

從充電座中取出耳機

从充电座中取出耳机

케이스에서 분리하세요.

ケースから取り出します。

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/r écepteur exempt de licence contenu dans le pr é sent appareil est conforme aux CNR d' Innovation, Sciences et D é veloppement é conomique Canada applicables aux appareils radio exempts de licence. L' exploitation est autoris é e aux deux conditions suivantes :

(1) L' appareil ne doit pas produire de brouillage;
(2) L' appareil doit accepter tout brouillage radio é lectrique subi, m ê me si le brouillage est susceptible d' en compromettre le fonctionnement.

2.Enable Bluetooth

Activer le Bluetooth

Bluetooth aktivieren

Activar Bluetooth.

Abilita Bluetooth.

Aktivera Bluetooth.

打開藍牙.

打开蓝牙.

블루투스 기능을 켜세요.

Bluetoothを有効にします。

3.Select Melomania and follow device's instructions

Sélectionnez Melomania et suivez les instructions de l'appareil.

Wählen Sie Melomania und folgen Sie den Anweisungen des Geräts.

Seleccionar Melomania y seguir las instrucciones del dispositivo.

Seleziona Melomania e segui le istruzioni del dispositivo.



Välj Melomania och följ enhetens instruktioner.

選擇 Melomania 並按照手機/設備說明配對您的耳機

选择 Melomania 并按照手机/设备说明配对您的耳机

Melomania를 선택하고 장치의 지침을 따르세요.

Melomaniaを選択し、デバイスの指示に従ってください。




CONTROLS

COMMANDES BEDIENELEMENTE CONTROLES CONTROLLI KONTROLLER 控制 控制 제어 컨트롤러


Left only

Gauche uniquement Nur links Solo Izquierdo Solo Sinistra Endast Vänster 僅左耳機
仅左耳机 왼쪽만 左のみ




Right only

Droite uniquement Nur rechts Solo Derecho Solo Destra Endast Höger 僅右耳機 仅右耳机
오른쪽만 右のみ



Either earbud

L'un ou l'autre écouteur Beide Ohrhörer Cualquiera de los auriculares Entrambi gli auricolari
Båda hörlurar 左右耳机 左右耳機 둘 중 한쪽 いずれかのイヤホン



LIGHT MODES

MODES DE LUMINOSITÉ LICHTMODEN MODOS DE LUZ MODALITÀ ILLUMINAZIONE LJUSLÄGEN

燈光模式 灯光模式 라이트 모드 라이트모드

Not seeing what's below? Contact support at:

Vous n'arrivez pas à voir ce qui se situe ci-dessous ? Veuillez contacter le service d'après-vente à :

Können Sie nicht lesen, was unten steht? Kontaktieren Sie den Support unter:

¿No ves lo que hay debajo? Ponte en contacto con soporte en:

Non vedi cosa c'è sotto? Contatta l'assistenza a:

Ser du inte vad som visas endan? Kontakta kundtjänst:

沒有在以下嗎？請聯繫以下支持：

没有在以下吗？请联系以下支持：

밑에 뭐가 있는지 안 보이나요? 다음 연락처로 지원을 요청하세요.

以下のものが表示されませんか？

次のサポートにお問い合わせください。

techsupport.cambridgeaudio.com

	100%	No Audio -waiting for signal
	—	

CHARGING

RECHARGE AUFLADEN CARGA RICARICA LADDAR 充電 充電 충전 充電

Charging case battery indicator 20-100%Akkuanzeige für Ladekoffer

20-100%

Indicateur de batterie du boîtier de chargement 20-100%Indicador de batería del estuche de

carga 20-100%

Indicatore batteria della custodia di ricarica 20-100%Laddningsfodral batteriindikator 20-100%

充電盒電量指示燈20-100%

充电盒电量指示灯20-100%

충전 케이스 배터리 표시 등 2 0-100%

充電ケースの充電残量表示20-100%

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NEED HELP?

BESOIN D'AIDE ? BRAUCHEN SIE HILFE? ¿NECESITAS AYUDA? HAI BISOGNO DI AIUTO? BEHÖVER DU HJÄLP? 需要幫助？ 需要幫助？ 도움이 필요하신가요? 助けが必要ですか？

For more setup instructions and videos as well as firmware updates, download the Melomania app or visit:

Pour plus d'instructions d'installation ou de vidéos, téléchargez l'application Melomania ou visitez :

Für weitere Installationsanweisungen und Videos laden Sie die Melomania-App herunter oder besuchen Sie uns:

Para obtener más instrucciones de configuración y videos, descarga la aplicación Melomania o visita:

Per ulteriori istruzioni sulla configurazione e video, scarica l'app Melomania o visita:

För mer installationsanvisningar och videor, ladda ner Melomania-appen eller besök:

更多安裝說明和視頻以及固件更新, 請下載 Melomania 應用程序或訪問：

更多安裝說明和視頻以及固件更新, 请下载 Melomania 应用程序或访问：

자세한 설정 지침 및 영상을 보시려면 Melomania 앱을 다운로드하거나 다음 사이트를 방문하세요.

詳細なセットアップ手順とビデオについては、Melomaniaアプリをダウンロードするか、次のWebサイトにアクセスしてください。

techsupport.cambridgeaudio.com

You can find the product name, model, and trademark on the first page of the manual, and the product name, model, trademark, MIC ID and LOGO on the bottom of the color box and charging box

CAMBRIDGEAUDIO.COM /CAMBRIDGEAUDIO

AP37139/B

Company name: Audio Partnership LLC

Address: Gallery Court, Hankey Place, London, SE1 4BB, United

Kingdom