








802.11a / 6535 MHz / Chain A




802.11a / 6535 MHz / Chain B



802.11a / 6535 MHz / Chain C





802.11a / 6535 MHz / Chain D




802.11a / 6695 MHz / Chain A


802.11a / 6695 MHz / Chain B




802.11a / 6695 MHz / Chain C




802.11a / 6695 MHz / Chain D



802.11a / 6855 MHz / Chain A




802.11a / 6855 MHz / Chain B




802.11a / 6855 MHz / Chain C


802.11a / 6855 MHz / Chain D




802.11a / 6875 MHz / Chain A




802.11a / 6875 MHz / Chain B




802.11a / 6875 MHz / Chain C





802.11a / 6875 MHz / Chain D




802.11a / 6895 CH189 / Chain A




802.11a / 6895 CH189 / Chain B




802.11a / 6895 MHz / Chain C




802.11a / 6895 MHz / Chain D



802.11a / 7015 MHz / Chain A




802.11a / 7015 MHz / Chain B




802.11a / 7015 MHz / Chain C


802.11a / 7015 MHz / Chain D




802.11a / 7095 MHz / Chain A




802.11a / 7095 MHz / Chain B




802.11a / 7095 MHz / Chain C



802.11a / 7095 MHz / Chain D



802.11ax20 / 5955 MHz / Chain A



802.11ax20 / 5955 MHz / Chain B