







802.11ax20 / 5955 MHz / Chain C




802.11ax20 / 6175 MHz / Chain A




802.11ax20 / 6175 MHz / Chain C




802.11ax20 / 5955 MHz / Chain D




802.11ax20 / 6175 MHz / Chain B




802.11ax20 / 6175 MHz / Chain D




802.11ax20 / 6415 MHz / Chain A




802.11ax20 / 6415 MHz / Chain B




802.11ax20 / 6415 MHz / Chain C




802.11ax20 / 6415 MHz / Chain D




802.11ax20 / 6435 MHz / Chain A




802.11ax20 / 6435 MHz / Chain B




802.11ax20 / 6435 MHz / Chain C




802.11ax20 / 6435 MHz / Chain D




802.11ax20 / 6475 MHz / Chain A




802.11ax20 / 6475 MHz / Chain B




802.11ax20 / 6475 MHz / Chain C




802.11ax20 / 6475 MHz / Chain D




802.11ax20 / 6515 MHz / Chain A




802.11ax20 / 6515 MHz / Chain B




802.11ax20 / 6515 MHz / Chain C





802.11ax20 / 6515 MHz / Chain D




802.11ax20 / 6535 MHz / Chain A




802.11ax20 / 6535 MHz / Chain B




802.11ax20 / 6535 MHz / Chain C




802.11ax20 / 6535 MHz / Chain D



802.11ax20 / 6695 MHz / Chain A



802.11ax20 / 6695 MHz / Chain B



802.11ax20 / 6695 MHz / Chain C

802.11ax20 / 6695 MHz / Chain D