

soundmatters Moment / DASH 4

Moment is in Bluetooth pairing mode upon first powering. To pair a new Bluetooth device press and hold (-) and (+) to initiate Bluetooth pairing mode — indicated by alternating flashes of blue and amber. Note: Keep Moment away from contact with credit cards, as it can *demagnetize* magnetic strips.

When connected to a charging source, a red colored LED indicates the unit is being charged; green indicating full charge. When not connected to a charging source, blue indicates normal charge; red requiring charge.

Moment is charged with the included USB cable or by the optional Energizer® charging cradle available for purchase from Soundmatters.

For any questions contact us at support@soundmatters.com or 1-800-698-SOMA.

soundmatters Moment / DASH 4

Quand **Moment** est allumé pour la première fois, l'appareil est en mode d'appariement. Pour l'apparier à un nouvel appareil Bluetooth, maintenir les boutons (-) et (+) enfoncés – l'appariement est indiqué par des voyants clignotants bleu et orange. Gardez Moment hors de tout contact avec des cartes de crédit, car il peut démagnétiser des bandes magnétiques.

Lorsque l'appareil est en charge, un voyant LED rouge indique que le chargement est en cours; il s'éclaire en vert pour signaler la pleine charge. Lorsqu'il n'est pas en charge, le voyant est bleu pour indiquer que l'appareil est chargé, et rouge pour indiquer qu'il doit être rechargé. Moment peut être rechargé avec le câble USB fourni, ou avec le socle de chargement Energizer® disponible en option auprès de Soundmatters.

Pour toute question, contactez-nous par email à support@soundmatters.com ou par téléphone au +1 800 698 7662.

FCC Notices

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

RF exposure warning:

The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. It could be removed.