

Register custom actions to the buttons.

Only the 2 buttons and the wheel can be used under the initial settings.

- Button 1: Single-Tap
- Button 2: Secondary Click

Follow the steps below to assign all other button functions.

1. Turn ON AssistiveTouch.

1) Select “Accessibility” under “Settings”.


2) Select “Touch”.



3) Select “AssistiveTouch”.




4) Select "AssistiveTouch" to turn ON.




2. Assign custom actions to the buttons.


1) Select "Devices" under "POINTER DEVICES".




2) Tap on “bitra”.



3) Select “Customize Additional Buttons...”.




4) When the “Customize Button” page loads, click on the button on the trackball to be added.



*When adding “Button 3”.

Button 3




5) A list of all assignable functions loads. Select the desired function to assign.

*When assigning "Screenshot" to "Button 3".



6) The function has been assigned to the button. To assign a function to another button, repeat the steps above.




When AssistiveTouch is OFF, the Custom Action function is disabled and only the initial right click, left click and wheel scroll functions may be used.

Change scroll direction

Change the scroll direction for when the scroll wheel on the mouse is moved.

1) Select “General” under “Settings” from the home page.



2) Tap on “Trackpad & Mouse”.



3) Tapping “Natural scrolling” to turn it on or off changes the scroll direction.



When "Natural scrolling" is turned off, the scroll direction is the same as the direction of the scroll wheel movement.

Android




Using Bluetooth connection




1. Remove the battery insulating tab.


1) Remove the battery cover.



2) Remove the battery insulating tab.




3) Put the battery cover back on.




Replacing the battery...


1) Remove the battery cover.



2) Remove the old battery.




3) Insert a new battery according to the instructions on the battery compartment.




Ensure that the battery is inserted with the positive (+) and negative (-) terminals oriented correctly.

4) Put the battery cover back on.



2. Turn the power ON

1) Slide the power switch on the underside of the product to the ON position.



The area around the wheel lights up blue for 5 seconds.

*When the battery is running low, the LED blinks white 10 times every second.

- **When turning on the power for the first time**

The device enters pairing mode, and the area around the wheel rapidly flashes blue. You can now pair it with your computer.

If you wish to pair, refer to Step 3 in ["3. Pairing with an Android Device"](#).



Power-saving mode

When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

The trackball returns from power-saving mode when it is moved.

*Trackball operation may be unstable for 2-3 seconds after returning from the power-saving mode.

3. Pairing with an Android device.


- Pairing involves registering Bluetooth devices (in this case, this product and an Android device) with each other, and authorizing a connection between them.
- Tap to operate the Android device until pairing is complete.
- Instructions for the Pixel Tablet (Android 15) are as follows. There may be differences depending on the OS version or device.

1) Slide the connection switch downward to select the Bluetooth connection.

The area around the wheel lights up blue for 5 seconds.

2) Press and hold the pairing button on the bottom of the product for 3 seconds, then release it.

The device enters pairing mode, and the area around the wheel rapidly flashes blue.



3) Select “Settings” from the home page.

4) Select “Connected devices”.



5) Select “Pair new device”



6) Tap on “bitra” under “Available devices”.



7) Select “Pair”.



Pairing begins.

8) Pairing is complete when this product is added to “Other devices”.


After the area around the wheel lights up for 5 seconds, it turns off.




You can now use the trackball.

1. Remove the battery insulating tab.


1) Remove the battery cover.



2) Remove the battery insulating tab.




3) Put the battery cover back on.




Replacing the battery...


1) Remove the battery cover.



2) Remove the old battery.




3) Insert a new battery according to the instructions on the battery compartment.




Ensure that the battery is inserted with the positive (+) and negative (-) terminals oriented correctly.

4) Put the battery cover back on.



2. Turn the power ON

1) Slide the power switch on the underside of the product to the ON position.



The area around the wheel lights up blue for 5 seconds.

*When the battery is running low, the LED blinks white 10 times every second.

- **When turning on the power for the first time**

The device enters pairing mode, and the area around the wheel rapidly flashes blue. You can now pair it with your computer.

If you wish to pair, refer to Step 3 in ["3. Pairing with a PC"](#).



Power-saving mode

When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

The trackball returns from power-saving mode when it is moved.

*Trackball operation may be unstable for 2-3 seconds after returning from the power-saving mode.

3. Pairing with a PC

- Pairing involves registering Bluetooth devices (in this case, this product and your device) with each other, and authorizing a connection between them.


- This section covers Chrome OS standard Bluetooth functions. Depending on your computer, unique Bluetooth functions may be used. Please read the respective manuals for each function.
- Use your current mouse or the touchpad on your device to operate your device until pairing is complete.
- The following instructions are for Chrome OS (130.0.6273.126).

1) Slide the connection switch downward to select the Bluetooth connection.

The area around the wheel lights up blue for 5 seconds.


2) Press and hold the pairing button on the bottom of the product for 3 seconds, then release it.

The device enters pairing mode, and the area around the wheel rapidly flashes blue.




3) Select the battery icon at the bottom right.

4) Click Bluetooth on the Quick Settings panel.



5) Under “Bluetooth”, select “Pair new device”.



6) Start scanning for devices.



7) Click on "bitra".

Pairing begins.




8) "bitra connected" is displayed at the bottom right of the screen.

After the area around the wheel lights up blue for 5 seconds, it turns off.




4) Click "Bluetooth" like in step 2. Pairing is complete when "bitra" appears under "Currently connected".




You can now use the trackball.

1. Remove the battery insulating tab.


1) Remove the battery cover.




2) Remove the battery insulating tab.



3) Remove the receiver unit.




4) Put the battery cover back on.




Replacing the battery...


1) Remove the battery cover.



2) Remove the old battery.




3) Insert a new battery according to the instructions on the battery compartment.




Ensure that the battery is inserted with the positive (+) and negative (-) terminals oriented correctly.

4) Put the battery cover back on.



2. Turn the power ON.

1) Slide the power switch on the underside of the product to the ON position.



The area around the wheel lights up white for 5 seconds.

*When the battery is running low, the LED blinks white ten times every second.



Power-saving mode

When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

The trackball returns from power-saving mode when it is moved.


*Trackball operation may be unstable for 2-3 seconds after returning from the power-saving mode.

3. Connect to a PC

1) Start up your PC.

Please wait until the PC has started up and can be operated.


2) Insert the receiver unit into the PC's USB-A port.



You may use any USB-A port.



▪ For devices that do not have a USB-A port, please use a USB Type-C hub.



▪ Ensure that the connector is correctly oriented to the port.

- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.



When removing the receiver unit

This product supports hot plugging. The receiver unit can be removed while the PC is on.

3) The driver is automatically installed, and then you are able to use the mouse.
You can now use the trackball.


Change the mouse pointer speed

Adjust the mouse pointer movement speed on your PC if the mouse pointer moves too fast or too slow.

1) Select the battery icon at the bottom right.

2) Select  (settings) on the Quick Settings panel.

The settings page appears.



3) Select “Mouse” under “Device”.