

Model/Equipment Type: M-XPT1MR


ENGLISH

Manua l

Trackball Mouse


Names of Parts

■ Trackball main unit



1 Left button
2 Right button
3 Wheel
4 "Back" button
5 "Forward" button
6 Function buttons 1 to 3
7, 8 Functions can be assigned to this button
9 Trackball
10 LED lamp
11 USB [A] connector
12 Connection mode selection switch
13 Power mode selection switch
14 Pointer speed change switch
15 Pairing button
16 Optical sensor (reverse side of ball)
17 Ball removal hole
18 Receiver unit storage section
19 Battery cover
20 Battery storage section
21 USB connector (male)


■ Receiver unit



1 Left button
2 Right button
3 Wheel
4 "Back" button
5 "Forward" button

1 Insert battery


Only when connecting 2.4 GHz wireless, Bluetooth



1 Remove the battery cover.
2 Insert battery according to instructions displayed on the bottom surface.
3 Re-attach the battery cover to its original state.

2 Turn the power ON


Only when connecting 2.4 GHz wireless, Bluetooth



1 Slide the power mode selection switch to either the H (High speed mode) or L (Low energy mode) position.
In High speed mode, tracking performance becomes greater when moving the ball quickly, but battery life is shortened.
The LED lamp is lit red for a fixed time.
* When remaining battery is low, the LED blinks red for a fixed time.

3 Connecting to a PC


For wired connection



1 Connect the attached USB cable to the USB microB port on this product.
2 Start up the PC.
3 Insert the USB connector of this product into the USB port of the PC.
When connecting by cord, 2.4 GHz wireless connection and Bluetooth connection cannot be used.
* Ensure the correct orientation and insertion location of the connector.
* If strong resistance is felt when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
* Do not directly touch the terminal area of the USB connector.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

How to clean the trackball


1 Use a finger (or a pen) to push the ball out from the reverse side.
2 Use a cotton bud or similar to remove the dust accumulated on the three contact surfaces of the red ball.
When cleaning around the optical sensor, take care not to damage the sensor.

Specifications

Count number	500/1000/1500 dpi (switchable)
Interface	USB For wired/Wireless 2.4 GHz connection mode
Connector shape	USB (A) male For wired/Wireless 2.4 GHz connection mode
Compatible OS	Windows® 10, Windows® 8.1, Windows® RT 8.1, Windows® macOS High Sierra (10.13) * Support only for models with Bluetooth 4.0 or later installed as standard (You may need to update to the latest version of each OS or install service packs)
Communication method	GFSK method
Radio frequency	2.4 GHz band
Radio wave range	Non-magnetic materials (such as wooden desks): approximately 10 m Magnetic materials (such as iron desks): approximately 3 m * These are test values in company environment and are not guaranteed.
Read method	Optical sensor method
Emitted light type	Non-visible wavelength range
Number of buttons	8 * including wheel button
External dimensions	Trackball main unit: approx. W108 mm × D135 mm × H48 mm Receiver unit: approx. W14 mm × D19 mm × H5 mm

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

How to clean the trackball


1 Use a finger (or a pen) to push the ball out from the reverse side.
2 Use a cotton bud or similar to remove the dust accumulated on the three contact surfaces of the red ball.
When cleaning around the optical sensor, take care not to damage the sensor.

Specifications

Count number	500/1000/1500 dpi (switchable)
Interface	USB For wired/Wireless 2.4 GHz connection mode
Connector shape	USB (A) male For wired/Wireless 2.4 GHz connection mode
Compatible OS	Windows® 10, Windows® 8.1, Windows® RT 8.1, Windows® macOS High Sierra (10.13) * Support only for models with Bluetooth 4.0 or later installed as standard (You may need to update to the latest version of each OS or install service packs)
Communication method	GFSK method
Radio frequency	2.4 GHz band
Radio wave range	Non-magnetic materials (such as wooden desks): approximately 10 m Magnetic materials (such as iron desks): approximately 3 m * These are test values in company environment and are not guaranteed.
Read method	Optical sensor method
Emitted light type	Non-visible wavelength range
Number of buttons	8 * including wheel button
External dimensions	Trackball main unit: approx. W108 mm × D135 mm × H48 mm Receiver unit: approx. W14 mm × D19 mm × H5 mm

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

모델명: M-XPT1MR


한국어

취급설명서

트랙볼 마우스


부품의 이름

■ 트랙볼 본체



1 좌 버튼
2 우 버튼
3 휠
4 "뒤로" 버튼
5 "앞으로" 버튼
6 기능 버튼 1~3
7, 8 기능에 할당될 수 있는 버튼
9 트랙볼
10 LED 램프
11 USB [A] 커넥터
12 연결 모드 선택 스위치
13 전원 모드 선택 스위치
14 포인터 속도 변경 스위치
15 페어링 버튼
16 광학 센서 (볼의 반대면)
17 볼 제거 구멍
18 수신기 단위 저장부
19 배터리 커버
20 배터리 저장부
21 USB 커넥터 (수)


■ 리시버 유닛



1 좌 버튼
2 우 버튼
3 휠
4 "뒤로" 버튼
5 "앞으로" 버튼

1 연결지 삽입


2.4 GHz 무선, Bluetooth 연결 시에만



1 연결지 커버를 분리합니다.
2 하단면에 표시된 안내에 따라 연결지를 삽입합니다.
3 연결지 커버를 원래 상태로 다시 장착합니다.

2 전원을 켭니다


2.4 GHz 무선, Bluetooth 연결 시에만



1 전원 모드 스위치를 H (고속 모드) 또는 L (저 에너지 모드) 위치로 밀어서 켜줍니다.
고속 모드에서는 볼이 빠르게 움직일 때 추적 성능이 높아지지만 전자기 수명은 단축됩니다.
LED 램프는 일정 시간 동안 빨간색으로 켜집니다.
* 전자기 노이즈가 발생하면 LED가 일정 시간 동안 빨간색으로 깜빡입니다.

3 PC 접속


유선 연결



1 연결된 USB 케이블을 이 제품의 USB microB 포트에 연결합니다.
2 PC를 시작합니다.
3 이 제품의 USB 커넥터를 PC의 USB 포트에 삽입합니다.
* 코드 연결 시, 2.4 GHz 무선 연결과 Bluetooth 연결을 이용할 수 없습니다.
* 커넥터 방향과 삽입 장소를 정확히 확인하십시오.
* 삽입 시 강한 저항이 느껴지면 커넥터의 모양과 방향을 확인하십시오. 커넥터를 강제로 삽입하면 커넥터가 손상될 수 있으며 삽입 성능이 저하됩니다.
* USB 커넥터의 단자 부분을 직접 만지지 마십시오.

나의 Bluetooth 연결 시


페어링 방법은 사용하는 PC에 따라 다를 수 있습니다. 이 경우, PC의 취급 설명서를 읽어주십시오.



1 연결 모드 변경 "Bluetooth"로 선택 전환.
2 화면 왼쪽 하단의 "장치" 버튼을 클릭하고 "설정" 아이콘을 클릭합니다.
3 "Windows 설정" 화면에서 "장치"를 클릭합니다.
4 "Bluetooth 및 기타 장치"를 클릭하고 "Bluetooth 또는 다른 장치 추가"를 클릭합니다.
5 "Bluetooth"를 클릭합니다.
6 장치 검색에 하단의 페어링 버튼을 2초에서 3초 동안 눌러줍니다.
7 "EX-G Pro Trackball"을 클릭하여 페어링을 시작합니다.
8 "연결됨"으로 변경되면 "완료"를 클릭합니다.
9 이 제품은 "마우스, 키보드 및 펜"에 추가되고 페어링이 완료됩니다.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection


The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

When connecting my Bluetooth connection

The pairing method may differ depending on the PC you are using. In that case, please read the instruction manual for your PC.



1 Change the connection mode selection switch to "Bluetooth".
2 Click on the "Start" button on the lower left of the screen, and click on the "Settings" icon.
3 Click on "Devices" on the "Windows Settings" screen.
4 Click on "Bluetooth & other devices", and click on "Add Bluetooth or other device".
5 Click "Bluetooth".
6 When the add device screen is displayed, click the pairing button on the bottom for two to three seconds, and then release.
7 Click on "EX-G Pro Trackball" to start pairing.
8 When it changes to "Connected", click on "Done".
9 This product is added to "Mouse, keyboard, & pen", displays "Connected" and pairing is complete.

본 회사 웹사이트에서 "Elecom Mouse Assistant"를 다운로드하고 설치하여 버튼 지정 기능과 고속 스크롤링 기능과 같은 기능을 사용할 수 있습니다. Windows®의 경우, 마우스 휠을 이용하여 좌우로 스크롤할 수 있습니다. Macintosh®의 경우, "앞으로" 버튼 "뒤로" 버튼을 이용할 수 있습니다. http://www.elecom.co.jp/global/download-list/utility/mouse_assistant/ * Windows® RT 8.1은 Elecom Mouse Assistant로 지원하지 않습니다.

