perixx

# PERIDUO-605



▸User Manual ▸Bedienungsanleitung ▸manual de instrucciones ▸Mode D'Emploi ▸Manuale Utente ▸取扱説明書 ▸产品说明书 ▸使用手冊

VALUE CREATOR

perixx

Perixx's warranty obligations are limited to the terms set forth below. Perixx warrants this hardware product against defects in materials and workmanship for a period of two (2) years from the date of original invoice.

If you discover a defect, Perixx will, at its option, repair or replace the product at no charge to you, provided you return it during the warranty period with shipping charges pre-paid to Perixx. You must contact Perixx for a Return Merchandise Authorization number (RMA) prior to returning any product. For each product returned for warranty service, please include your name, shipping address (no P.O. Box), telephone number, a copy of the bill of sale as proof of purchase and make sure that the package is clearly marked with your RMA number.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED. PERIXX SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING AND WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO PERIXX DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENTION OR ADDITION TO THIS WARRANTY.

PERIXX IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT OR PROPERTY AND ANY COST OF RECOVERING, REPROGRAMMING OR REPLRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH PERIXX PRODUCTS. PERIXX'S MAXIMUM LIABILITY FOR ANY AND ALL DAMAGES ARISING OUT OF USE OF THE PRODUCT SHALL BE LIMITED TO THE AMOUNTS PAID BY PURCHASER FOR SUCH PRODUCT.



perixx

**Caution**

- The manufacturer and re-resellers are not responsible for any malfunctions, damage, or personal injury incurred by:
  - A misuse of the product
  - Any attempt to dismantle, change or modify the product in any manner
  - You are cautioned that changes or modifications not expressly approved by the party responsible for the compliance could void your authority to operate the equipment.
  - Mandatory repair charges are required for the following conditions, within the guarantee period:
  - Malfunction or damage is due to misuse or improper alteration or repair.
  - Malfunction or damage caused by the falling after the purchase.
  - Malfunction or damage is caused by a fire, salt, gas, earthquake, lighting, wind, water, or other natural calamities, or abnormal voltage.
  - Malfunction or damage is caused by other devices connected to the keyboard.
- All brand names, trademarks and logos are the properties of their respective owners.

**Please Note:** Long-term repetitive use of any keyboard could cause injury to user. Perixx recommends users avoid excessive use of this or any keyboard.



perixx

**FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



perixx


**Product Illustration**




❶ LED Indicators (Num Lock, Caps Lock and Scroll Lock) ❷ Scroll Wheel/Middle Click ❸ Keyboard Stand ❹ Position 1: For Removable Magnet Foot & Keyboard Stand ❺ Position 2: For Removable Magnet Foot ❻ Battery ❼ On/Off switch ❽ Connect Button




perixx







perixx

**Product Illustration**




❶ Left Click Button
❷ Right Click Button
❸ Scroll Wheel/Middle Click
❹ DPI Switch: 2DPI Levels: 1000/1600
❺ Forward(Browser)
❻ Backward(Browser)
❼ Sensor
❽ Battery
❾ On/Off switch
❿ Receiver Storage





perixx

**Product Specification**


| | |
|---|---|
| Color | Black or White |
| Interface | Wireless 2.4G |
| Size | Keyboard: 463x227x66mm (with stand)<br>Keyboard: 463x227x49mm (without stand)<br>Mouse: 120x75x63mm |
| Weight | Keyboard: 845g<br>Mouse: 102g |
| Function key | 17 |
| Operation Temperature | 0°C to 45°C |
| Storage Temperature | -15°C- 60°C |
| Electrical Rating | 3V |
| Operation voltage | ≤ 5mA |
| Material | ABS |
| OS requirement | Windows XP and above |




perixx

**Installation Process**

Step 1





Step 2





perixx

Step 3






perixx

**Power Saving Mode & Battery Consumption**

Power Saving mode helps to consume minimum power (when kept on) by turning off signal connection when the mouse is in Idle Mode and increases the battery life.

**Keyboard**

| | Active Mode | Static Mode | Sleeping Mode (LED off) |
|---|---|---|---|
| Stop Working Time | - | 2 Sec | After 5 Minutes |
| Current Consumption | <3.5mA | <0.15mA | <0.1mA |

When the mouse is in power saving mode, click on any mouse button to reconnect. 2pcs of brand-new AAA battery (1100mAh) provides up to 80 days of use when you use about two hours a day.

**Low Voltage Indicator:**
Indicator (Num Lock) will flash 15 times

**Mouse**

| | Working Mode | Static Mode | Power Saving Mode | Power Saving Mode II (LED flash slowly) | Deeply Sleeping Mode (LED off) |
|---|---|---|---|---|---|
| Stop Working Time | - | 2 Sec | 10 Sec | 6 Minutes | After 8 Minutes |
| Current Consumption | 8.7mA | <5mA | <1.8mA | <0.5mA | <0.3mA |



perixx

When the mouse is in power saving mode, click on any mouse button to reconnect.
2pcs of brand-new AAA battery (1100mAh) provides up to 80 days of use when you use about two hours a day.

**Caution**

Please do not use rechargeable AAA battery with the product. The voltage spec of rechargeable battery (1.2V) is lower than the normal alkaline battery (1.5V), and your device may run out of power very soon if you use the rechargeable battery. With the optimal performance of the product, we recommend you to use the alkaline battery on the device.



perixx

**Table of Content**


ENGLISH ---------------------------------------- 13
DEUTSCH ---------------------------------------- 16
ESPAÑOL ----------------------------
FRANÇAIS ----------------------------
ITALIANO ----------------------------
日本語 ----------------------------
简中 ----------------------------
繁中 ----------------------------


e-Manual via www.perixx.com



perixx

**English(US/UK)**

**Caution**

- The manufacturer and re-resellers are not responsible for any technical malfunctions, damage, or personal injury incurred by:
  - Any attempt to dismantle, change or modify the product in any manner
  - Malfunction or damage due to misuse or improper alteration or repair.
  - Malfunction or damage caused by external influence such as falling
  - Malfunction or damage is caused by a fire, salt, gas, earthquake, lightning, wind, water, or other natural calamities, or abnormal voltage.
  - Malfunction or damage is caused by other devices connected to the products.
  - Malfunction or damage is caused by high temperature, humid, greasy, dusty and hazardous environment.

- You are cautioned that changes or modifications not expressly approved by Perixx Computer GmbH could void your authority to operate the equipment.
- All brand names, trademarks and logos are the properties of their respective owners.

**Please Note:** Long-term repetitive use of any keyboard and mouse could cause injury to user. Perixx recommends users to avoid excessive use of this or any keyboard and mouse.



perixx

**English(US/UK)**

Thank you for purchasing a Perixx product. PEIRUOD-605 is a user friendly full size keyboard. It is an ideal solution for the office or home working space. It is easy to install and use with plug and play feature. There is no need to install any driver or software. You can use it with various applications like All-in-one PC, Notebook, and your Desktop PC.

**System Requirements**
- Operating System: Microsoft Windows XP/7/8/10
- 1 x Free USB Port

**Installation Process**
The following steps initiate a connection process of the PERIDUO-605 to your PC.
1. Turn ON the PC:
2. Insert Batteries
3. Plug the USB Receiver into a free USB Port
4. The device will be automatically detected by the PC, and it should be ready to work
5. If the device is still not working, please repeat the process from step 1
6. If the device is still not working, try to reboot the connection by unplugging your receiver from port and plug it back in again. Then, press and hold the connect button for 5 seconds.



perixx

**English(US/UK)**

**Hot Keys**

Fn + F1 → Media Palyer
Fn + F2 → Volume down
Fn + F3 → Volume up
Fn + F4 → Mute
Fn + F5 → Ctrl+Z
Fn + F6 → Ctrl+Y
Fn + F7 → Search
Fn + F8 → My favorite
Fn + F9 → E-mail
Fn + F10 → Home Page
Fn + F11 → Win Lock
Fn + F12 → Calculator
→ Tab+Alt
→ Stop
→ Previous
→ Next
→ Play / Pause



perixx

**Deutsch (DE)**

**Bitte beachten Sie:**
- Der Hersteller sowie die Wiederverkäufer sind nicht verantwortlich für technische Defekte, Schäden oder mögliche Verletzungen verursacht durch:
  - Versuche, den Artikel zu demontieren oder in jeglicher Form zu verändern
  - Zweckentfremdung oder eigene Reparaturen
  - Fremdeinwirkung wie z.B. Sturz oder Schlag
  - Feuer, Gas, Erdbeben, Blitz, Wind, Wasser, Überspannung oder jede andere Form von äußerer Gewalt
  - Andere mit der Tastatur verbundene Geräte
  - Zu hohe Temperaturen oder eine feuchte, staubige oder gefährliche Umgebung

- Der Benutzer wird darauf hingewiesen, dass Änderungen oder Modifizierungen an der Gerätschaft, die von Perixx Computer GmbH nicht ausdrücklich genehmigt sind, die Erlaubnis des Benutzers zur Inbetriebnahme des Gerätes außer Kraft setzen könnte.
- Alle Markennamen, Warenzeichen und Logos sind Eigentum von Perixx.

Die übermäßige Langzeit-Verwendung jeder Tastatur und Maus kann zu Verletzungen führen. Perixx empfiehlt Benutzern den übermäßigen Gebrauch von jeglicher Tastatur und Maus zu vermeiden.



perixx

**Deutsch (DE)**

Vielen Dank für Ihren Kauf dieses Perixx Produkts. Das PERIDUO-605 zeichnet sich durch seine praktische Größe und seinem ausgezeichnetem Design aus, welches sich in jede Arbeitsumgebung einpasst. Es bietet somit die ideale Lösung für Büro-, Heim-und Gaming-Bedürfnisse. Durch die Plug & Play Funktion ist es leicht zu verwenden, einfach anschließen, es benötigt keine weitere Treiber- oder Softwareinstallation.

**System Voraussetzungen:**
- Betriebssysteme: Microsoft Windows XP/7/8/10
- 1 x freier USB Port

**Tastatur Installation**
1. Schalten Sie Ihren PC ein.
2. Legen Sie die Batterien ein.
3. Stecken sie den USB Receiver in einen freien USB-Anschluss.
4. Das Gerät sollte nun automatisch vom PC erkannt werden und funktionsbereit sein. Sollte das Gerät nicht funktionieren, wiederholen Sie bitte die Installation mit Schritt 1
5. Wenn Ihr Gerät immer noch nicht funktioniert, schließen Sie den Empfänger erneut an und drücken Sie die "Connect" -Taste für 5 Sekunden.



perixx

**Deutsch (DE)**

**Hot Keys**

Fn + F1 → Media Player
Fn + F2 → öffnen
Fn + F3 → - Volume
Fn + F4 → + Volume
Fn + F5 → Ctrl+Z
Fn + F6 → Ctrl+Y
Fn + F7 → Suche
Fn + F8 → Favoriten
Fn + F9 → E-Mail öffnen
Fn + F10 → Startseite
Fn + F11 → Tastatur sperren
Fn + F12 → Rechner öffnen
→ Tab+Alt
→ Stop
→ Vorheriges Lied
→ Nächstes Lied
→ Play / Pause



perixx

VALUE CREATOR