





TOUCHSECURE READER 8800




TOUCHSECURE READER / PROGRAMMER 8805




TOUCHSECURE READER 8800




TOUCHSECURE READER / PROGRAMMER 8805



TOUCHSECURE READER 8800: 0.09 – 30MHz



TOUCHSECURE READER 8800: 30-1000MHz



TOUCHSECURE READER / PROGRAMMER: 0.09 - 30MHz



TOUCHSECURE READER / PROGRAMMER: 30-1000MHz

