Size: 70*93mm

Wireless Headphone
MINELAB



Model No.: ML85

Shenzhen Rambo Weiye Electronic Co., Ltd
3A03, Block 1, 182 Design Park, NO 182, Bulan Rd, Buji Longgang district, Shenzhen China

Instruction Manual

The wireless headphones with its stylish design and ergonomic construction, powered with stereo sound drivers and the latest nRF5340 chip-set provides a high quality low-latency wireless audio experience.


Package Contents

- Headphones
- 3.5mm Detachable Auxiliary cable
- USB-C Charging Cable
- Hard Shell Case
- Detachable Mesh Bag
- Instruction Manual

Product Specification

- Chipset: Nordic nRF5340
- Operating Range: up to 10m
- Charging Time: 3 hours
- Operating Time: 35-40 hours
- Dimensions: 21.0 (L) x 16.0 (W) x 8 (H) cm (unfolded)
 21.0 (L) x 16.0 (W) x 5 (H) cm (folded)
- Weight: 221g
- Operating frequency: 2.4-2.485GHz
- Audio output power: 15mW x 2
- Power of supply: 0.1W

Buttons and Indications



1. LED
2. Volume +
3. Multi-Function Button (MFB) (Power ON / OFF, Pairing and Factory Reset)
4. Volume -
5. 3.5mm audio jack
6. USB-C charging port

Getting Started

To use your ML85 stereo wireless headphones, follow the steps below:
1. Ensure the wireless headphones are fully charged.
2. Pair the charged wireless headphones with a Minelab wireless enabled device

Charging the Headphones

Connect the USB-C charging cable to USB-C socket (6) of the headphones. The LED will remain solid red during charging.

Turning on the Headphones

Press and hold the MFB (3) until the LED (1) flashes solid blue for 1 second and then flashes red and blue. The headphones enter pairing mode automatically when no device is paired.

Turning off the Headphones

Press and hold the MFB (3) for 2 seconds until the headphones turn off.

Pairing the Headphones

1. Place the headphones and the detector no more than one metre apart.
2. Ensure the headphones are turned off.
3. Press and hold the MFB (3) until the LED (1) flashes red and blue.
4. Press and hold the wireless button on the detector for 2 seconds. All of the wireless symbols will flash.
5. When the pairing is complete, the LED (1) will flash blue once every 3 seconds and will be connected to the detector.

Note: If the pairing cannot be completed the headphones will continue to attempt to pair until a connection is made.

Connect with the Last Paired Device

The headphones will connect with the last paired device. If the pairing is successful the LED (1) will flash blue every 3 seconds. If the pairing cannot be completed, the headphones will continue to attempt to pair until a connection is made.

Changing the volume

Press the Volume – button (4) once to decrease the volume.
Press the Volume + button (2) once to increase or the volume.

Reset to factory defaults (including unpairing)

Make sure the headphones are turned off. Press the MFB (3) for approximately 10 seconds until the LED (1) flashes red and blue twice then release the button. The headphones will now be in pairing mode with the LED indicator (1) flashing red and blue. All previously paired devices will be unpaired.

Using supplied 3.5mm headphone cable

A 3.5mm audio cable is included for use if the headphones battery is flat. You may also use the audio cable with devices that do not have wireless audio capability.

Troubleshooting

If you are unable to connect your headphones to your device, try the following:

- Ensure your headphones are turned on and properly charged.
- Ensure the headphones are paired with your device.
- Ensure your devices wireless audio feature is activated. Refer to your devices user guide for specific instructions.
- Ensure the headphones are within a 10 metre range of your device and there are no obstructions, such as walls or other electronic devices in between.
- If the above steps do not solve your problem, recharge the headphones and turn the device off and on again.

Safety Information

- Never allow children to play with the headphones, small parts are a choking hazard.
- Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive environments.
- Turn off your headphones prior to boarding an aircraft.
- Never mount or store your headphones over any air bag deployment area as serious injury may result if the air bag deploys.
- Do not open or mutilate the built-in battery.
- Dispose of batteries according to local regulations. Do not dispose as household waste.
- Only charge the headphones built-in battery in accordance with the instructions contained in the user guide.
- Avoid charging the headphones in extreme temperature conditions.

Care and Maintenance Headphone

- Turn the headphones off before placing in a pocket or bag.
- Do not expose the headphones to liquid, moisture or humidity, as the headphones are not waterproof.
- Do not use abrasive cleaning solvents to clean the headphones.
- Do not expose the headphones to extreme temperature conditions. The storage temperature range is from -0 to +60 Celsius.
- Do not dispose the headphones in a fire as this may result in an explosion.
- Do not bring the headphones into contact with sharp objects as this will cause scratches and damage.
- Do not attempt to disassemble the headphones, as they do not contain serviceable components.
- If the headphones are not used for long periods, store in a dry place free from extreme temperature conditions and dust.

Software Upgradeable

The ML85 headphones can be updated via the USB-C connection. Please refer to www.minelab.com/support for more details.

Wireless Compatibility

The wireless technology used in the ML85 headphones is only compatible with certain Minelab metal detectors. Please refer to www.minelab.com/support for more details.

Minelab reserves the right to introduce changes in design, equipment and technical features at any time without notice and Minelab™ is a trademark of Minelab Electronics Pty. Limited.

LED indications

Condition	LED state
Pairing state	Alternating red blue
Charging	Solid red
Connected	Blue flash every 3 seconds
Not connected	Blue flash 3 times every second

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada' s licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :
(1) L' appareil ne doit pas produire de brouillage;
(2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

Audífonos con inalambricos



N.° de modelo: ML85

Manual de instrucciones

Los auriculares inalámbricos con su diseño elegante y ergonómico construcción, alimentado con controladores de sonido estéreo y el último conjunto de chips nRF5340 proporciona una experiencia de audio inalámbrico de alta calidad y baja latencia.


Contenidos del paquete

- Audífonos
- Cable auxiliar desmontable de 3.5 mm
- Cable USB-C de carga
- Funda rígida
- Bolsa de malla desmontable
- Manual de instrucciones

Especificaciones del producto

- Chipset: Nordic nRF5340
- Rango operativo de: hasta 10m
- Tiempo de carga: 3horas
- Tiempo de funcionamiento: 35-40 horas
- Dimensiones: 21.0 (L) x 16.0 (A) x 8 (Alt.) cm (sin plegar)
 21.0 (L) x 16.0 (A) x 5 (Alt.) cm (plegado)
- Peso: 221g
- Potencia de salida de audio: 15mW x 2
- Suministro de energía: 0.1W

Botones e indicaciones



1. LED
2. Volumen +
3. Botón multifunción (MFB) (Encendido / Apagado, Emparejamiento y Restauración de fábrica)
4. Volumen -
5. Conector de audio de 3.5 mm
6. Puerto de carga USB-C

Introducción

Para usar sus auriculares estéreo inalambricos ML85, siga los pasos debajo:
1) Asegúrese de que los audífonos con inalambricos estén totalmente cargados.
2) Empareje los audífonos con inalambricos previamente cargados con otro dispositivo con inalambricos

Cargar los audífonos

Conecte el cable USB-C de carga al puerto USB-C de carga (7) en los audífonos. La luz LED (1) será roja mientras se carga y se apagará cuando la carga haya finalizado.

Encender los audífonos

Mantenga presionado el botón MFB (3) hasta que la luz LED (1) parpadee en azul durante 1 segundo, luego en rojo y luego en azul. Los audífonos entran en modo de emparejamiento automáticamente cuando no hay dispositivos emparejados.

Apagar los audífonos

Mantenga presionado el botón (3) durante 2 segundos hasta que la luz LED (1) parpadee en rojo y luego se apague.

Emparejar los audífonos

1. Coloque los auriculares y el detector a una distancia inferior a un metro.
2. Asegúrese de que los auriculares estén apagados.
3. Mantenga presionado el botón MFB (3) hasta que la luz LED (1) parpadee en rojo y azul.
4. Mantenga presionado el botón inalámbrico en el detector durante 2 segundos. Todos los símbolos inalámbricos parpadearán.
5. Cuando se complete el emparejamiento, la luz LED (1) parpadeará en azul una vez cada 3 segundos. Los auriculares se conectarán al detector.

Nota: Si no se puede completar el emparejamiento, los auriculares seguirán intentando emparejarse hasta que se realice una conexión.

Conectar con el último dispositivo emparejado

Los audífonos se conectarán al último dispositivo emparejado. Si el emparejamiento es exitoso, la luz LED (1) parpadeará color azul cada 3 segundos. Si no se puede completar el emparejamiento, los auriculares seguirán intentando emparejarse hasta que se establezca una conexión.

Cambiar el nivel de volumen

Presione una vez el botón Volumen + (2) para aumentar el volumen.
Presione una vez el botón Volumen – (4) para reducir el volumen.

Restaurar a valores predeterminados de fábrica (incluso desemparejar)

Asegúrese de que los audífonos están apagados. Presione el botón MFB (3) durante unos 10 segundos hasta que la luz LED (1) parpadee en color rojo y azul dos veces, luego suelte el botón. Los auriculares estarán ahora en modo de emparejamiento con el indicador LED (1) parpadeando en azul y rojo. Todos los dispositivos vinculados previamente se desvincularán.

Usar el cable para audífonos de 3.5 mm incluido

Se incluye un cable de audio de 3.5 mm para usar si la batería de los audífonos está descargada. También puede usar el cable de audio con dispositivos que no tengan capacidad inalambricos.

Resolución de problemas

Si no puede conectar sus audífonos al dispositivo, intente lo siguiente:

- Asegúrese de que los audífonos están apagados y debidamente cargados.
- Asegúrese de que los audífonos están emparejados con su dispositivo.
- Asegúrese de que la función inalambricos de los dispositivos está activada. Consulte la guía de usuario de sus dispositivos para instrucciones específicas.

- Asegúrese de que los audífonos se encuentran dentro de un rango de 10 metros de su dispositivo y que no hay obstrucciones entre ellos, como paredes o dispositivos electrónicos.
- Si los pasos anteriores no solucionaron el problema, recargue los audífonos, luego apague y encienda nuevamente el dispositivo.

Información de seguridad

- Nunca permita que los niños jueguen con los audífonos ya las piezas pequeñas presentan peligro de asfixia.
- Está atento a cualquier señalamiento que le solicite apagar un dispositivo eléctrico o de radio RF en áreas designadas. Estos se pueden encontrar en hospitales, áreas de detonación y entornos potencialmente explosivos.
- Apague sus audífonos antes de abordar un avión. Evite colocar o almacenar sus audífonos sobre cualquier área de despliegue de bolsas de aire, ya que podrían ocasionarse lesiones severas en caso de despliegue.
- No abra ni dañe la batería integrada.
- Deseche las baterías de acuerdo con sus reglamentos locales. No las deseche como residuos domiciliarios.
- Cargue la batería integrada de los audífonos únicamente de la forma en que indican las instrucciones incluidas en la guía de usuario.
- Evite cargar los audífonos en condiciones de temperaturas extremas.

Cuidado y mantenimiento de los audífonos

- No exponga los audífonos a líquidos o humedad, ya que no son a prueba de agua.
- No utilice solventes limpiadores abrasivos para limpiar los audífonos.

- No exponga los audífonos a condiciones de temperaturas extremas. El rango de temperatura de almacenamiento es de -0 a +60 °C
- No deseche los audífonos en el fuego ya que esto podría ocasionar una explosión.
- Asegúrese de que los audífonos no entren en contacto con objetos afilados, ya que estos podrían ocasionar rayones y daños.
- No intenten desarmar los audífonos ya que no contienen componentes utilizables.
- Si los audífonos no se utilizarán por largos periodos, deberán guardarse en lugares secos sin condiciones de temperaturas extremas ni polvo.

Software actualizable

Los auriculares ML85 se pueden actualizar a través de la conexión USB-C.
Consulte www.minelab.com/support para obtener más detalles.

Compatibilidad inalámbrica

La tecnología inalámbrica utilizada en los auriculares ML85 es solo compatible con ciertos detectores de metales Minelab.
Consulte www.minelab.com/support para obtener más detalles.

Minelab se reserva el derecho de introducir cambios en el diseño, equipamiento y características técnicas en cualquier momento sin previo aviso.
Minelab™ es una marca registrada de Minelab Electronics Pty. Limited.

Indicaciones LED

Condición	Estado de LED
Estado de emparejamiento	Alterna entre rojo y azul
Estado de carga	Rojo
Conectado	Destello azul cada 3 segundos
No conectado	Destello azul 3 veces cada segundo