


12.4 Setup Photographs:


X-axis, 30-1000 MHz




Y-axis, 30-1000 MHz




Z-axis, 30-1000 MHz




X-axis, 30-1000 MHz, with water proof plastic enclosure




Y-axis, 30-1000 MHz




Z-axis, 30-1000 MHz




X-axis, 1-10 GHz




Y-axis, 1-10 GHz




Z-axis, 1-10 GHz



X-axis, 1-10 GHz, with water proof plastic enclosure



Y-axis, 1-10 GHz, with water proof plastic enclosure



Z-axis, 1-10 GHz

