



BLUETOOTH® 4.0 STEREO HEADPHONES

BASSLINE

8037606

Thanks for purchasing the HeadRush Bluetooth® Stereo Headphones. BASSLINE is an over-the-ear Bluetooth® Stereo Headphone. We hope you enjoy HeadRush's superior acoustic performance. Please read the information below before proceeding.

WHAT'S IN THE BOX:

1. 1 x Bluetooth® stereo headphones
2. 1 x micro USB charging cable
3. 1 x 3.5mm audio cable
4. 1 x Quick Start guide
5. 1 x Carry Pouch

CAUTION:

1. Heed all warnings on the product and in the operation instructions.
2. Do not open the product. Repair has to be performed by a qualified technician.
3. The product has a wireless transmission distance up to 10m (33'), but wireless performance may be affected in different operating environments.
4. Do not use accessories that are not recommended by the product manufacturer.
5. Do not place the device on unstable surfaces (i.e. cart, stand, tripod, bracket, table, etc.).
6. Do not use the device near water, such as sinks, bathtubs or swimming pools.
7. Keep the product out of extreme heat and humidity. Do not install it near heaters, stoves or any other source of heat.
8. To avoid causing damage to your eyes, do not stare directly at the light source for long time periods of time.
9. Barriers and other wireless devices may affect the performance of speaker.
10. Permanent hearing damage or hearing loss may occur if headphones are used at a high volume. Hearing experts suggest not continuously listening to music at a high volume. If you hear a hissing noise in your ears, or if you experience discomfort, lower the volume or temporarily discontinue use of this product until discomfort subsides.

STRUCTURE OF HEADSET:



A. VOLUME UP button/next track

Button function

- Short press VOLUME UP button to turn up volume
- Long press VOLUME UP button to go to the next track

B. MULTI-FUNCTION button (Power ON/OFF, Pairing, Answer Call/End Call/Reject Call, Play/Pause)

Button function

- Long press the MULTI-FUNCTION button for about 1.5 seconds to turn on the headset
- Long press the MULTI-FUNCTION button for about 4.5 seconds to enter into pairing status
- Long press the MULTI-FUNCTION button for about 2.5 seconds to turn off the headset
- Short press the MULTI-FUNCTION button to play/pause music
- Long press the MULTI-FUNCTION button to reject an incoming call
- Short press the MULTI-FUNCTION button to receive an incoming call and then short press to end it
- Double click on the MULTI-FUNCTION button to call the last number dialled

C. VOLUME DOWN button/last track

Button function

- Short press the VOLUME DOWN button to turn down the volume
- Long press the VOLUME DOWN button to replay the last track

D. Blue/Red LED for power and Bluetooth® indication

LED function

- Bluetooth® Pairing: The LED will blink blue/red alternately every 3 seconds
- Bluetooth® Connected: The LED will blink slowly in blue (approx. every 2 seconds)
- Bluetooth® reconnecting: The LED blink slowly in blue (approx. every 2 seconds)
- Battery needs to be charged: The Red LED will blink slowly
- During Charging: The Red LED will remain on
- Fully Charged: The Blue LED will remain on

E. Micro USB jack for charging

F. 3.5mm AUX jack port

G. Dual microphones for superior performance

H. Adjustable headband

I. Foldable design

BASIC OPERATION:

Charging the battery

The LED will continually blink slowly in red when battery power is low. When the battery is completely drained, no indicator light will work. Before using, allow the battery to charge for at least 2.5 hours. The red LED will light up during charging. When fully charged, the red LED will go off and blue LED keeps original status.

1. Connect the micro USB cable to the USB jack on your headset.

2. Connect the USB end to a USB port on your computer or laptop.

Power On/Off

To switch the headset on, press and hold the MULTI-FUNCTION button for about 1.5 seconds and then release. Blue LED will blink slowly.

Note: If your Bluetooth® device (smartphone, tablet, etc.) has previously connected with this Bluetooth® headset, it will reconnect without pairing. If there is no Bluetooth® connection for more than 30 minutes, it will shut down automatically.

To turn the power off, press and hold the MULTI-FUNCTION button for about 2.5 seconds and then release. The red LED will light temporarily, and then all LED lights will go off.

Pairing Headset with Bluetooth®-enabled devices

- (1) If the headset has not been previously paired with a device, press and hold the MULTI-FUNCTION button for about 4.5 seconds until the blue/red LED blinks fast in an alternating pattern, indicating that the device is in pairing mode.
- (2) If the headset has been previously paired with the device, press and hold the MULTI-FUNCTION button for about 1.5 seconds until the blue indicator light is on and blinks slowly, which indicates standby mode. The headset should connect to the device (its Bluetooth® function should be turned on) automatically.
- (3) Turn on the device's Bluetooth® function and set it to search for Bluetooth® devices.
- (4) Once the device is discovered, make the connection by selecting "HR 8037606".
- (5) Enter 0000 if a password is requested.

Note: If you have paired and connected the headset with one of your Bluetooth® devices, disconnect the headset from it before pairing the headset with another Bluetooth® device. Follow the instructions in the section above to pair and connect again.

USING THE HEADSET:

Place headset on your ears by matching the L/R markers to your ears accordingly. Adjust the length of the headband until the ear pad covers your ears comfortably.

Listening to music

- (1) Pair and connect the headset to a Bluetooth® device such as a mobile phone or music player. The music player must support the A2DP Bluetooth® profile. The music functions available depend on your mobile phone or music player.
- (2) To adjust the headset volume, single press the VOLUME UP or DOWN button to adjust volume during a call or while listening to music.
- (3) Long press VOLUME UP or DOWN button to switch to the next track or replay the last track.
- (4) To listen to music from a wired audio source, connect a 3.5mm stereo cable from the AUX jack to a music player such as MP3, PC, CD player, etc. You will be able to adjust the volume or track on the player only.

Note: Audio connection via 3.5mm stereo cable will override wireless audio via Bluetooth®.

Placing/answering phone calls

- (1) To make a call while connected to the headset, use your mobile phone and dial as you normally would. Double press the MULTI-

FUNCTION button on the headset to call the last number dialed.

- (2) To answer a call, press the MULTI-FUNCTION button or use the keys on the phone.
- (3) To reject a call, press and hold the MULTI-FUNCTION button.
- (4) To end a call, press the MULTI-FUNCTION button or use the keys on the phone.

Note: If you receive or make a call while listening to music, the music will stop automatically until the call ends. To pause or resume playing, short press the MULTI-FUNCTION button.

TROUBLESHOOTING:

See below for solutions to common problems.

Symptom: Bluetooth® indicator LED not on

Solution: Make sure your headset has been powered on.

Charge your headset.

Symptom: Speaker does not produce sound

Solution: Make sure your headset has been powered on.

Make sure the volume is turned up to audible listening level for both headset and your Bluetooth® device (smartphone, tablet, etc.).

Make sure the Bluetooth® is successfully connected.

Symptom: Bluetooth® cannot be connected

Solution: Confirm your phone/music player is Bluetooth®-compatible and make sure the device's Bluetooth® is turned on.

Make sure correct Bluetooth® pairing password has been entered if required.

During Bluetooth® pairing, please do not operate too many Bluetooth® devices to avoid interference with Bluetooth® connection.

If pairing fails, long press the VOLUME DOWN and VOLUME UP button at the same time for about 2.5 seconds to enter into pairing mode again, or try to pair the headset with another Bluetooth® device.

Clear the pairing list on your Bluetooth® device and try again.

Symptom: Sound distortion

Solution: WAV and MID files are often poor quality, meaning distortion and noise are easily noticed with powered speakers.

Check the volume level and decrease if necessary.

Check whether the red LED is blinking slowly (indicating the battery is low). If yes, please charge the battery.

SPECIFICATIONS:

Bluetooth® Version: Bluetooth® 4.0

Bluetooth® Profiles: Handsfree Profile for talking and operating the phone
Advance Audio Distribution Profile (A2DP) for audio streaming
Audio Video Remote Control Profile (AVRCP) for music control

Battery life: Call time up to 12 hours, music playback time up to 10 hours (varies by volume level and content)

Charging Time: Approx. 2.5 hrs from empty to full charge

Bluetooth® Range: 10m (33 ft.)

Microphone: Dual microphone provides a noise-free calling experience

Battery Type: Lithium-Ion Polymer (240mAh capacity)

Driver: 40mm NdFeB drivers, 2pcs

Dimensions: 180 x 165 x 72 mm (WxDxH)



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.

The FCC Wants You To Know

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1) reorient or relocate the receiving antenna;
- 2) increase the separation between the equipment and the receiver;
- 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected;
- 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

Industry Canada RSS-247 Notice:

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Category II radio communication device complies with all the requirements of Industry Canada Standard RSS-247.

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source,
Barrie, Ontario, Canada, L4M 4W5
Manufactured in China
www.headrushaudio.com



Please Recycle

© 2015 The Source
All rights reserved.