

9.36W" x 7.37H" x 7.37D"



THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

DRIVER SWITCH

ON/OFF SWITCH

SEE ALKALINE BATTERIES FOR BEST PERFORMANCE

BATTERY DIAGRAM

SEE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

Reverse: Press both control sticks backward.

Forward: Press both control sticks forward.

Spinning Action: Press and hold the control sticks in opposite directions to make the car spin.

Action Button: Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Adult supervision and use only when operating car.
- Do not submerge car or controller in water.
- Never operate your car in the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals in obstacles.
- Do not use your car on lawns, objects or hard surfaces, as this will cause damage to both the device and the car.
- Keep fingers, hair and loose clothing away from the front, gears and motor while the car is running.
- Do not leave car or transmitter outside overnight. Damages to harmful to human consumption.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING

Do not use the car if the battery is damaged or if the battery is not properly inserted. Do not use the car if the battery is not properly inserted. Do not use the car if the battery is not properly inserted.

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

EXCITING RC DRIVING ACTION!

Spinning Stunt Vehicle with LED Lights

Rotates 360 Degrees on a Single Wheel

Full-Function Wireless Radio Control

Available in 2 Frequencies for Competitive Racing

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

WIRELESS RC CONTROL

Spinning Stunt Vehicle with LED Lights

Rotates 360 Degrees on a Single Wheel

Full-Function Wireless Radio Control

Available in 2 Frequencies for Competitive Racing

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

OPERATING INSTRUCTIONS

Operation requires 4 "AA" 1.5 (or alkaline) batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from front package.

2. Locate the battery compartments on the back of each item (see diagram on right).

3. Insert batteries on bottom of car to release battery pack and insert batteries.

4. Switch both car and remote buttons to "ON" position.

5. For best result use the car on hard surfaces such as wood or tile.

GENERAL CONTROLS

Reverse: Press both control sticks backward.

Forward: Press both control sticks forward.

Spinning Action: Press and hold the control sticks in opposite directions to make the car spin.

Action Button: Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Adult supervision and use only when operating car.
- Do not submerge car or controller in water.
- Never operate your car in the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals in obstacles.
- Do not use your car on lawns, objects or hard surfaces, as this will cause damage to both the device and the car.
- Keep fingers, hair and loose clothing away from the front, gears and motor while the car is running.
- Do not leave car or transmitter outside overnight. Damages to harmful to human consumption.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING

Do not use the car if the battery is damaged or if the battery is not properly inserted. Do not use the car if the battery is not properly inserted. Do not use the car if the battery is not properly inserted.

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

EXCITING RC DRIVING ACTION!

Spinning Stunt Vehicle with LED Lights

Rotates 360 Degrees on a Single Wheel

Full-Function Wireless Radio Control

Available in 2 Frequencies for Competitive Racing

BLUE HAT

TWO FREQUENCIES

360 DEGREE SPINS

WIRELESS RC ACTION!

BATTERY OPERATED BY 9V BATTERY

AGES 6+

REAL LED LIGHTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR