




Google Home
Gemini built in

QUICK START GUIDE


onn Smart Speaker




IN THE BOX



onn Smart Speaker





AC Adapter




Quick Start Guide

DETAILS



USB Type-C Power Port



Privacy Switch

SETUP

1. Get the Google Home app.



2. Plug the onn Smart Speaker into a power outlet.
3. Press the + button to add a new device.
4. Scan the QR code on the bottom of the onn Smart Speaker.
5. Follow the steps in the app.



STATUS LIGHT GUIDE

Setup

Solid white

Device is powered on.

Pulsing white

Ready for setup.

Spinning white

Device connecting to app.

Pulsing purple

Device connected to app.

Reset

Blinking yellow

Reset countdown has begun and audio announcement played.

Errors

Slow blinking yellow

Using an adapter with incorrect wattage.

Fast blinking yellow

Can't find Wi-Fi network.

Usage

Multi-color to solid white

Device is listening.

Pink and purple

Gemini is thinking and responding.

Fast blinking white

Timer or alarm is playing.

ALL IN ONE FEATURES

This device does more than play music—it's an advanced, multi-purpose speaker powered by the Google Home Platform.

Matter-enabled Hub

Connect and control any Matter-enabled device right from the Google Home app, ensuring your devices all work together seamlessly.

Thread Border Router

Easily add Thread-enabled devices to your network. Enjoy a secure, low-power mesh network for extended range and faster response times.


Look for the Badges

Look for the Matter and Thread logos when buying new accessories to ensure seamless compatibility with your speaker.

RESET

Factory Reset

1. Switch the mic off. The lights will turn orange.
2. Press and hold the top center of the speaker. After 5 seconds, the speaker will begin the factory reset process.
3. Continue to hold for about 10 seconds more, until a sound confirms that it's resetting.



TROUBLESHOOTING

Why can't I find my device?

1. Your network signal may be too weak, or the device is added by another person.
Solution: Reset your device and try adding it again. Make sure your phone's Bluetooth is on during the entire process.
2. This device may not be available in your region.

Why can't my device connect to the network?

1. Make sure your router's connection is password protected and the router you're trying to connect to is yours. The devices can't connect to unencrypted public networks (e.g., in offices, hotels, etc.).
2. Your router's encryption method should be WPA/WPA2. WEP and WAPI encryption methods aren't currently supported.
3. If the info above didn't help, check your network settings or reboot the router.

The WiFi network is not found when adding the device?

1. Ensure the router is encrypted. The devices will not connect to unencrypted networks.
2. Make sure current router doesn't require a second ID or password verification.
3. Make sure no hidden SSID is set for the router. Routers with a hidden SSID won't appear in the list. In that case, please modify router settings and reconnect.

Does it work with Google Home?

Yes, the device works with Google Home. It requires the Google Home app and a Google account.

COMPLIANCE

FCC Statement :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
- Shielded cables must be used with this unit to ensure compliance with the Class FCC limits.



WARNING

- No parts should be repaired by users.
- Place the device on a flat, firm and stable surface. And do not put it on a carpet or rug.
- Protect the device from high temperatures, humidity, water and dust.
- Do not place any objects near the device that may damage it (e.g., liquid-filled objects or candles).
- Place the device in a well-ventilated location to prevent the accumulation of device internal heat.
- Presence of live parts inside the device! Do not open. Risk of electric shock!
- Use the included accessories for best performance.
If using a different USB-C cable or adapter, make sure it supports 5V/3A (15 W)
- Working temperature: 0°C to 45°C
Working voltage: 5V $\pm$ 10%
- The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile/satellite systems

COMPLIANCE

WARRANTY INFORMATION

Your onn product is covered by a one-year limited warranty. You can contact our support team for the limited warranty terms period.

Apple logo and App Store are trademark of Apple Inc. registered in the U.S. and other countries and regions. Google, Google Play and the Google Play logo are trademark of Google LLC.

For product assistance & missing or replacement parts:

WE CAN HELP

1-888-516-2630

7 DAYS/WEEK 7 a.m. - 9 p.m. CST

Find more at **Walmart.com**



**SCAN HERE FOR MORE
PRODUCT INFORMATION
AND LEAVE US A REVIEW!**

Manufactured in Vietnam for: Walmart, Inc.
2101 SE 8th Street Bentonville, AR. 72716
Mail Stop # 0585
BENTONVILLE AR 72716
United States Of America