

Label on the host

The label affixed to Lumenis laser system and shown in page 24 of the Operator's Manual, file User_manual_laser_28528

