Manual Edition 13, Oct. 2021
BL350-S0350D-03

EDIFIER

@Edifier_Global @Edifier_Global @Edifier_Global

Hereby, Edifier International Limited declares that the radio equipment type S3P 1350AC is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.edifier.com/emea-eu/cen

Model: S3P 1350AC

Input: 100-240V~
0 - 1500W 50/60 Hz

Declaration No 01
Frequency Band 1: 2412Hz~2.4835Hz
Maximum RF power: 20.00dBm (EIRP)
There is no restriction of use.

Edifier International Limited
Room 1901, 19/F
General Post Office
Hong Kong

Tel: +852 2522 4389
Fax: +852 2522 4389
www.edifier.com

© 2021 Edifier International Limited. All rights reserved.

Printed in China

NOTE

Due to continuous product improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Please note that illustrations are recommended for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

S350DB
Active Speaker

User manual | Manuel d'utilisateur | Manual de usuario | Bedienungsanleitung |
Manuale dell'utente | Manual do utilizador

名　　称：	S350DB 21版（英法西德意葡文）说明书	东莞市漫步者科技有限公司	
材　　质：	80g米黄色胶推斯纸，对折，胶装		
尺　　寸：	127×127（MM）	校　　对：	
版本号及料号：	V1.0/IB-200-S0350D-03	批　　准：	

IB-200-S0350D-03 说明书S350DB 21版/英法西德意葡文

Important safety instruction

1. Please read the instructions carefully. Keep it in safe place for future reference.
2. Use only accessories approved by the manufacturer.
3. Install the instrument properly by following the instructions in the device connection section.
4. Keep away from heat sources such as radiators, heaters, stoves.
5. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
7. Do not install or use this product near any heat source (e.g. radiator, heater, stove, or other devices that generate heat).
8. Do not use this product near water. Do not expose this product to liquids, such as rain or the product's drain should any open fire, such as lighted candles be placed on the product.
9. Do not block any ventilation openings. Do not insert any object into ventilation openings or slots. It may cause fire or electric shock.
10. Only a professional should repair this product. Repair should be carried out after the service provider can repair do it.
11. Unplug the power cord during lightning storms or when unused for long periods of time.
12. Do not pull or remove the Supply Cord from the mains plug by pulling on the cord. Pull the mains plug before You pull and it is unsafe to the Cord direction.
13. Keep the product away from children. Supply Cord, as connect, keep from children to prevent from being swallowed by mistake.
14. Do not open or remove the housing yourself. It may expose you to dangerous voltage or other hazardous risks. Regardless the cause of damage (such as damaged cover or jack), attempts to repair (glued or foreign object falling in, exposure to rain or moisture, normal operation not to follow the instructions, dropped, etc.), will void your warranty. Only qualified service personnel should be allowed to open the device.
15. Avoid using the product with dry cloth, damp cloth or liquid cleaners, and/or spray cleaners.
16. Never use strong acid, alkali, gasoline, alcohol, or other chemical solvents to clean the product surface. Use only neutral cleaners or clean water for cleaning.

Excessively loud music may lead to hearing loss. Please keep the volume in a safe range.

Le symbole d'un éclair à l'intérieur d'un triangle équilatéral est destiné à alerter l'utilisateur de la présence d'une « tension dangereuse » non isolée à l'intérieur du produit, qui peut être d'une ampleur suffisante pour constituer un risque de choc électrique pour les personnes.

Le point d'exclamation à l'intérieur d'un triangle équilatéral est destiné à alerter l'utilisateur de la présence d'instructions importantes d'utilisation et de maintenance (entretien) dans la documentation qui accompagne l'appareil.

Pour éviter un risque de choc électrique, ne pas retirer le capot ou le panneau arrière. Aucune pièce réparable par l'utilisateur à l'intérieur. Confier l'entretien à un personnel qualifié.

Pour éviter un risque d'incendie ou de choc électrique, ne pas exposer cet appareil à la pluie ou à l'humidité. Cet appareil ne doit pas être exposé à des gouttes ou éclaboussures et aucun objet rempli de liquide, tel que des vases, ne doit être placé sur l'appareil.

Ce produit ne doit être utilisé que dans un climat tempéré.

Ce produit ne doit pas être utilisé sous les tropiques.

Ce produit ne doit pas être utilisé dans des endroits très poussiéreux.

Ce produit ne doit pas être utilisé dans des endroits très humides (ne pas mettre de récipients contenant des liquides sur l'appareil, tels que des vases).

Ce produit ne doit pas être utilisé dans des endroits très froids.

Ce produit ne doit pas être utilisé en présence d'une flamme nue.

Ce produit ne doit pas être utilisé dans des endroits très ventilés.

Ce produit ne doit pas être utilisé à des altitudes supérieures à 2000 m au-dessus du niveau de la mer