IB-200-S0355D-00 说明书S355DB 26版A版英法西德意葡荷波捷斯丹希腊瑞保罗俄V1.0

成型尺寸：105x146mm 展开尺寸：584x420mm
材质：80g书纸；单黑印刷；

保 密
Confidential

EDIFIER®

S355DB
Active Speaker



Quick Start Guide

Model: EDF100121

EN	What's in the box?
FR	Contenu de la boîte
ES	Contenido de la caja
DE	Lieferumfang
IT	Contenuto della confezione
PT	Conteúdo da Embalagem
NL	Wat zit er in de doos?
PL	Zawartość pudełka
CZ	Co je v krabičce?
SK	Čo je v krabici?
DK	Kassens indhold
GR	Περιεχόμενα συσκευασίας
SV	Vad finns i boxen?
BG	Какво има в кутията?
RO	Ce se află în cutie?
RU	дополнительный контент



EN	Cable connection
FR	Connexion par câble
ES	Conexión de cable
DE	Kabelverbindung
IT	Collegamento cavo
PT	Conexão dos cabos
NL	Kabelverbinding
PL	Połączenie kablowe
CZ	Připojení kabelu
SK	Káblové pripojenie
DK	Kabeltilslutning
GR	Σύνδεση καλωδίου
SV	Kabelanslutning
BG	Кабелна връзка
RO	Conexiune cablu
RU	Подключение по кабелю



EN	Bluetooth connection
FR	Connexion Bluetooth
ES	Conexión Bluetooth
DE	Bluetooth-Kopplung
IT	Connessione Bluetooth
PT	Ligação Bluetooth
NL	Bluetoothverbinding
PL	Połączenie Bluetooth
CZ	Připojení Bluetooth
SK	Pripojenie k Bluetooth
DK	Bluetooth-forbindelse
GR	Σύνδεση Bluetooth
SV	Bluetooth-anslutning
BG	Bluetooth връзка
RO	Conexiune Bluetooth
RU	Соединение по Bluetooth



EN	USB connection
FR	Connexion USB
ES	Conexión USB
DE	USB-Anschluss
IT	Collegamento USB
PT	Conexão USB
NL	USB-aansluiting
PL	Złącze USB
CZ	Připojení USB
SK	Pripojenie cez rozhranie USB
DK	USB-tilslutning
GR	Σύνδεση USB
SV	USB-anslutning
BG	Връзка USB
RO	Conexiune USB
RU	USB-подключение



EN	Play control
FR	Contrôle de lecture
ES	Control de reproducción
DE	Abspielsteuerung
IT	Controllo riproduzione
PT	Controle de reprodução
NL	Afspeelbediening
PL	Sterowanie odtwarzania
CZ	Ovladač přehrávání
SK	Ovládanie prehrávania
DK	Afspilningskontrol
GR	Έλεγχος αναπαραγωγής
SV	Uppspelningskontroll
BG	Управление на възпроизвеждането
RO	Control redare
RU	Управление воспроизведением



EN	Source selection
FR	Sélection de la source
ES	Selección de fuente
DE	Quellenauswahl
IT	Selezione sorgente
PT	Seleção de entrada
NL	Bron selectie
PL	Wybór źródła
CZ	Výběr zdroje
SK	Výber zdroja
DK	Kildevalg
GR	Επιλογή πηγής
SV	Källval
BG	Избор на източник
RO	Selectare sursă
RU	Выбор источника



EN	Standby & wake-up
FR	Veille et réactivation
ES	Espera y activación
DE	Standby & Reaktivierung
IT	Standby e riattivazione
PT	Standby e ativação
NL	Stand-by en activeren
PL	Tryb gotowości i aktywacja
CZ	Pohotovostní režim a aktivace
SK	Pohotovostný režim a aktivácia
DK	Standby og aktivering
GR	Αναμονή και ενεργοποίηση
SV	Standby och aktivering
BG	Режим на готовност и активиране
RO	În așteptare și activare
RU	Режим ожидания и активизация



EN	Battery replacement
FR	Remplacement de la pile
ES	Sustitución de batería
DE	Batterieaustausch
IT	Sostituzione della batteria
PT	Substituição da bateria
NL	De batterij vervangen
PL	Wymiana baterii
CZ	Výměna baterie
SK	Výmena batérie
DK	Udskiftning af batteri
GR	Αντικατάσταση μπαταρίας
SV	Batteribyte
BG	Смяна на батерията
RO	Înlocuirea bateriei
RU	Замена батарейки



EC REP For the bundled battery
Name: Apex CE Specialists GmbH
Address/Zip Code: Grafenberger Allee 277, 40237 Düsseldorf, DE/40237
Contact Person: Wells Yan Email: Info@apex-ce.de

CE

This equipment complies with European Commission Regulation (EU) 2023/826.
Off mode: ≤ 0.50W
Standby mode (when all wireless connections are deactivated): ≤ 0.50W
Networked standby mode for the speaker: ≤ 2W
The period of time after which the power management function switches the equipment automatically into: 15 minutes

Edition 1.0, January 2026
IB-200-S0355D-00

For more information, please visit our website:
www.edifier.com

@Edifierglobal @Edifier_Global @Edifier_Global

EDIFIER ConneX app

Download on the App Store
GET IT ON Google Play

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

Tel: +852 2522 6989
Fax: +852 2522 1989
www.edifier.com
© 2026 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

EN

What's in the box?

Note:
- Images are for illustrative purpose only and may differ from the actual product.
- The bundled USB connecting cable is for audio streaming only. Do not use it for device charging.
- For the need of technical improvement and system upgrade, information and specifications contained herein may be slightly different from actual product. If any difference is found, the actual product prevails.

Cable connection

Note:
- Power input: 100-240 V~ 50/60 Hz 600 mA (Satellite speakers), 100-240 V 50/60 Hz 1 A (Subwoofer)
- HDMI eARC Connection: Use an Ultra High Speed HDMI™ cable (not included) to connect the speaker's HDMI eARC port to the HDMI eARC or ARC port on your TV or source device.
- Refer to the user manual of your TV or source device for HDMI settings: (1) Enable the HDMI eARC or ARC function. (2) Set the digital audio output format to PCM. (3) Enable the HDMI CEC function to control the speaker with your TV or source device remote (e.g., standby/wake-up, mute, volume).

* This plug type is meant for illustrative purpose only.

Power on/off

- Power on: Switch the main power buttons on the rear panels to "ON".
- Power off: Switch the main power buttons to "OFF".

Power saving function

1. In Bluetooth (or HDMI) input mode, the speaker will enter power saving mode after 15 minutes of inactivity (no audio playback and operation) if any Bluetooth device (or HDMI source device) is connected. When playback resumes, it will return to working mode in about 1 second.
2. In Bluetooth (or HDMI) input mode, the speaker will automatically power off after 15 minutes of inactivity (no operation) if no Bluetooth device (or HDMI source device) is connected.
3. In Line In, USB, Optical, or Coaxial input mode, the speaker will automatically power off after 15 minutes of inactivity (no audio playback and operation).

Note: This function is enabled by default. To disable or re-enable this function, lower the volume to 0, and then press and hold the "▸II" button on the remote control for 2 seconds. "ECO OFF" will be displayed on the screen to confirm the function has been disabled. Otherwise, "ECO ON" will be displayed. You can disable this feature in the menu of "My Device" > "Power Saving Mode" on EDIFIER ConneX App.

Bluetooth connection

This speaker supports the simultaneous connection of two Bluetooth devices.

Connect to a device
1. Press the "VOLUME/SOURCE" knob on the active satellite speaker or the " ᛒ " button on the remote control to switch to Bluetooth input mode. If no device is connected, the speaker will auto-enter Bluetooth pairing mode (" ᛒ " blinking on the screen). If not, double-press the "VOLUME/SOURCE" knob on the active speaker or press and hold the " ᛒ " button on the remote control for 1.5 seconds.
2. On your device, select "EDIFIER S355DB" in its Bluetooth device list to connect, and " ᛒ " will be steady displayed on the screen when the connection is established.
- To disconnect from the current Bluetooth device, double-press the "VOLUME/SOURCE" knob on the active speaker or press and hold the " ᛒ " button on the remote control for 1.5 seconds.

Connect to two devices
1. Connect to a device, and then double-press the "VOLUME/SOURCE" knob on the active speaker or press and hold the " ᛒ " button on the remote control for 1.5 seconds (" ᛒ " blinking on the screen).
2. On the second device, select "EDIFIER S355DB" in its Bluetooth device list to connect, and " ᛒ " will be steady displayed on the screen when the connection is established.
3. On the first device, select "EDIFIER S355DB" in its Bluetooth device list to reconnect.
- Pause or stop playback on the current Bluetooth device before streaming audio from the second one.

Note:
- If no device is connected in 10 minutes, the speaker will switch to Bluetooth hidden mode (" ᛒ " displayed in breathing pattern on the screen). In this mode, (1) new devices cannot find the speaker, but (2) for a device that exists in the pairing record of this speaker, you can select "EDIFIER S355DB" from its Bluetooth device list to reconnect. To exit from Bluetooth hidden mode, press the "VOLUME/SOURCE" knob on the active satellite speaker or the " ᛒ " button on the remote control.
- After switched to Bluetooth input, the speaker will reconnect to the last connected devices automatically.

Play control

Note: Volume sync is not supported. To adjust the volume, adjust on the speaker and your device separately.

EDIFIER ConneX app

1. With your smart device, scan the QR code on the quick start guide or the packaging.
- You can also search for "EDIFIER ConneX" in Apple App Store (iOS devices) or Google Play (Android devices).
2. Download and install the app.
3. Connect your smart device with the speaker via Bluetooth.
4. Open EDIFIER ConneX App on your smart device.
5. Tap the menu for settings and playback control.

Specifications

Total output power (RMS): 15 W+15 W (Treble), 25 W+25 W (Mid), 70 W (Bass)
Frequency response: 98 Hz - 40 kHz (Satellite speakers), 44 Hz - 125 Hz (Subwoofer)

Declaration for EU

Frequency Band (Bluetooth): 2.402 GHz ~ 2.480 GHz
Frequency Band (Wi-Fi): 5.729 GHz ~ 5.845 GHz
RF Power Output (Bluetooth): ≤ 13 dBm (EIRP)
RF Power Output (Wi-Fi): ≤ 13 dBm (EIRP)
There is no restriction of use.

To learn more about EDIFIER, please visit www.edifier.com
For EDIFIER warranty queries, please visit the relevant country page on www.edifier.com and review the section titled Warranty Terms. USA and Canada: service@edifier.ca
South America: Please visit www.edifier.com (English) or www.edifierla.com (Spanish/Portuguese) for local contact information.

FR

Contenu de la boîte

Remarque :
- Les images utilisées servent de référence uniquement, et peuvent ne pas correspondre au produit.
- Le câble de raccordement USB fourni sert uniquement à la diffusion audio. Ne pas l'utiliser pour charger l'appareil.
- Les informations et spécifications contenues dans ce document peuvent varier légèrement par rapport au produit réel, car nous apportons constamment des améliorations techniques et système à nos produits. En cas de différence, le produit réel prévaut.

Connexion par câble

Remarque :
- Alimentation secteur : 100-240 V~ 50/60 Hz 600 mA (Enceintes satellites), 100-240 V~ 50/60 Hz 1 A (Caisson de basses)
- Connexion HDMI eARC : Utilisez un câble HDMI Ultra Haute Vitesse (non fourni) pour connecter le port HDMI eARC de l'enceinte au port HDMI eARC ou ARC de votre téléviseur ou appareil source.
- Reportez-vous au Manuel d'utilisation de votre téléviseur ou appareil source pour voir les paramètres HDMI : (1) Activez la fonction HDMI eARC ou ARC. (2) Réglez la sortie audio numérique sur PCM. (3) Activez la fonction HDMI CEC pour contrôler l'enceinte avec la télécommande de votre téléviseur ou appareil source (par ex. : mise en veille/réveil, sourdine, volume).