


 TWS1 Truly Wireless Stereo Earbuds www.edifier.com 	■ Product Description and Accessories   There are different size of earmuffs attached in the package, please select the suitable ones to wear.	■ Operational Guide ● Headphones Charging During using, if only red light flashes, it indicates the headphone is at low battery level, please use it after fully charged. Place headphones into charging case for charging. Red light lit in a breathing pattern = charging Red light off = fully charged Charging time: about 1.5 hours for a full charging ● Charging Case Charging If indicator light flashes slowly, its flashing times mean the times that the headphones can be charged; if the indicator light flashes rapidly, it means the charging case is at low battery level, please charge it in time. Indicator light steady lit = charging Indicator light off = fully charged  Rated input: 5V=60mA(headphone) 5V=500mA(charging case) Warning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion. If not used for long periods of time, please charge the product with lithium battery at least once per 3 months.	EDIFIER International Limited www.edifier.com ©2019 Edifier International Limited. All rights reserved. Printed in China NOTICE: For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice. Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. Picture for reference only, actual product prevails. V1.0 IB-200-T00010-XX
--	--	---	---

● Power ON/OFF 1. Power on automatically when took out from the charging case; 2. Power off automatically after placed into the charging case; ● Bluetooth Connection 1. Two Headphones Mode • Open the charging case to take two headphones out, press and hold the touch button of the left headphone to enter pairing state, red and blue light flashing rapidly; • Set mobile phone to search for and connect to "EDIFIER TWS1", after pairing is successful, blue light will flash slowly. 2. One Headphone Mode If use one headphone only, please take the left or right headphone out from the charging case, and refer to the procedures mentioned in "Two Headphones Mode" to pair it with mobile phone. ● TWS (true wireless stereo) Pairing and Connection of the Left and Right Headphones The left and right headphones have finished TWS pairing before leaving the factory. If the wireless connection fails to resume, please follow the steps below to re-pair: • When there is no TWS connection and connected with Bluetooth, double press the touch button to enter TWS pairing state, blue light flashing rapidly; • After pairing is done, blue lights of the left and right headphones will flash slowly.	■ Functional Operation Instructions ● Music Playback Mode  - Previous track: touch three times - Next track: double press - Pause playing: press once - Resume playing: press once ● Call Mode  - Answer incoming call: press once - Hang up call: press once - Reject incoming call: press and hold • Clear pairing records with mobile phone: when without Bluetooth and TWS connection, press and hold the touch button for 8 seconds. • Disconnect connection with mobile phone: when the phone is connected, no music is played and with no call, press and hold the touch button for 5 seconds.	■ FAQs Red light instead of blue light flashes. • The headphones are at low battery level, please recharge the headphones. Red light is off during charging. • Please ensure the headphones are correctly placed into the charging case. • When the headphones are not used for long periods of time, the battery will enter sleep state, it needs to charge about 30 minutes and then the red light will be lit. No sound • Check if the headphones are operating. • Check if the headphones volume is at an appropriate level. • Check if the headphones are correctly connected with mobile phone. • Check if the headphones are operating within a normal working range. Call effect of the headphones is bad. • Check if mobile phone is in an area with strong signal. • Please ensure the headphones are within effective distance (10m) and no obstacle between the headphones and mobile phone. When playing music, cannot control pause/play/previous track/next track via headphones. • Please ensure the paired device support AVRCP (Audio/Video Remote Control Profile) profile.	■ Maintenance During using, please read the following advices carefully. • Keep the product away from humid places to avoid affecting internal circuit. Do not use the product during intense exercise or with much sweat to prevent sweat from dropping into the product to make damage. • Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and deform plastic components. • Do not put the product in cold places to avoid damaging internal circuit board. • Do not dismantle the product. Non-professional personnel may damage the product. • Do not drop, strongly vibrate, strike the product with hard object to avoid damaging internal circuit. • Do not use drastic chemicals or cleaner to clean the product. • Do not use sharp objects to scratch product surface to avoid damaging shell and affecting looking. If the product cannot operate properly, please send it to your qualified maintenance agency.
---	---	---	---