





● **LMH4**


2140 MHz






2350 MHz











2450 MHz























2600 MHz






● **LMH4**













● **MH1**





— 3300MHz
— 3600MHz
— 3800MHz




— 3900MHz
— 4000MHz
— 4200MHz



— 4400MHz
— 4700MHz
— 5000MHz





— 5150MHz
— 5500MHz
— 6000MHz





● **MH2**



1440 MHz





1740 MHz



1880 MHz




1950 MHz






● **MH2**


2140 MHz






2350 MHz



2450 MHz




2600 MHz








● **MH2**


3600 MHz








4000 MHz



4700 MHz




5500 MHz






● **MH3**


1440 MHz






1740 MHz



1880 MHz




1950 MHz







● **MH3**



2140 MHz







2350 MHz



2450 MHz




2600 MHz






● **MH3**


3600 MHz






4000 MHz



4700 MHz





5500 MHz







● **MH4**



1440 MHz







1740 MHz



1880 MHz




1950 MHz






● **MH4**


2140 MHz



2350 MHz



2450 MHz



2600 MHz

