

SAR Test Setup



Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 2: Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 3: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 4: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 5: Top Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 6: Bottom Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 7: Back Side, the distance from EUT to the bottom of the Phantom is 25mm



Picture 8: Right Edge, the distance from EUT to the bottom of the Phantom is 17mm



Picture 9: Bottom Edge, the distance from EUT to the bottom of the Phantom is 21mm