




11A_Ant2_5240




11A_Ant1_5260




11A_Ant2_5260




11A_Ant1_5280




11A_Ant2_5280




11A_Ant1_5320




11A_Ant2_5320




11A_Ant1_5500



11A_Ant2_5500



11A_Ant1_5580



The screenshot displays a Spectrum Analyzer 1 interface. The main display area shows a frequency sweep from 5.58 GHz to 5.60 GHz. The signal trace is a yellow line on a black background, showing a peak at 5.58 GHz. The interface includes various settings and controls:

- Top Bar:** Spectrum Analyzer 1, Sweep SA, Frequency, Settings.
- KEYSIGHT:** Input RF (Coupling DC), Input Z (50 Ω), Attenuation (30 dB), PNO (Fast), Gate (Off), IF Gain (Low), Sig Track (Off), #Avg Type (Power (RMS)), Trng Video, Trng Delay (-2.000 ms), W (1 2 3 4 5 6), P (P P P P P P).
- Center Frequency:** 5.580000000 GHz.
- Span:** 0.00000000 Hz.
- Start Freq:** 5.580000000 GHz.
- Stop Freq:** 5.580000000 GHz.
- AUTO TUNE:** Button.
- CF Step:** 8.000000 MHz.
- Freq Offset:** 0 Hz.
- X Axis Scale:** Log.
- Signal Track:** Span Zoom.
- Marker Table:**

Mode	Trace	Scale	X	Y	Function	Function Width	Function Value
1							
2							
3							
4							
5							
6							
- Bottom Bar:** Windows, Navigation, Help, Date/Time (Oct 11, 2023, 9:46:19 AM), and various icons.

Spectrum Analyzer 1
Swept SA

KEYSIGHT Input: RF **Coupling DC** Input Z: 50 Ω #Atten: 30 dB PNO: Fast Gate: Off #Avg Type: Power (RMS) 1 2 3 4 5 6
RL → Align: Auto Corrections: Off Freq Ref: Int (S) IF Gain: Low Trng: Video Trng Delay: -2.000 ms WWWWWW
LW P P P P P P

1 Spectrum Ref Lvl Offset 10.62 dB
Scale/Div 10 dB Ref Level 25.00 dBm

Log
15.0
5.00
-15.0
-25.0
-35.0
-45.0
-55.0
-65.0

Center 5.700000000 GHz #Video BW 8.0 MHz Span 0 Hz
Res BW 8 MHz Sweep 27.00 ms (1001 pts)

5 Marker Table

	Mode	Trace	Scale	X	Y	Function	Function Width	Function Value
1								
2								
3								
4								
5								
6								

Windows Oct 10, 2023 2:42:31 PM

Frequency Settings

Center Frequency
5.700000000 GHz

Span
0.00000000 Hz
Swept Span
Zero Span
Full Span

Start Freq
5.700000000 GHz

Stop Freq
5.700000000 GHz

AUTO TUNE


CF Step
8.000000 MHz
Auto
Man

Freq Offset
0 Hz


X Axis Scale
Log
Lin

Signal Track
(Span Zoom)

11A_Ant2_5700



11A_Ant1_5745



11A_Ant2_5745

