

Test Setup photographs (DSS & DTS)


EUT Position: X-axis



EUT Position: Y-axis



EUT Position: Z-axis



Test Setup photographs (DSS & DTS)

EUT with Dual Display: 0 degree



EUT with Dual Display: 90 degree




EUT with Dual Display: 180 degree




EUT with Dual Display: 360 degree




Test Setup Photo of Radiated Measurement (0.009 ~ 30MHz)



Test Setup Photo of Radiated Measurement (below 1000MHz)



Test Setup Photo of Radiated Measurement (Above 1GHz)



Test Setup photo of Conducted Emissions (DSS & DTS)

