


## Antenna and Device Information



## Antenna

| Antenna | Mode       | Band                                     |
|---------|------------|------------------------------------------|
| ANT1    | Main LB/HB | LTE B5/7/12/17/41<br>W5, GSM850<br>TX,RX |
| ANT2    | Main MB    | LTE B2/4<br>W2/4, GSM1900<br>TX,RX       |
| ANT3    | LB/HB MRD  | LTE B5/7/12/17/41<br>W5, GSM850<br>RX    |
| ANT4    | WIFI/GPS   | BT/WiFi(2.4G&5G)<br>GPS                  |
| ANT5    | MB MRD     | LTE B2/4<br>W2, GSM1900<br>RX            |
| ANT6    | NFC        | -                                        |

## SAR Test Setup Photographs

■ Test Setup Photo (Left All)



■ Test Setup Photo (Left Touch/Tilt)




■ Test Setup Photo (Right All)



■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**



**[Distance of 1.0 cm from the EUT]**

■ Test Setup Photo (Front)



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Right)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo(Top)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo(Bottom)**



**[Distance of 1.0 cm from the EUT]**

■ Test Setup Photo (Rear for Extremity SAR)



[Distance of **0 cm** from the EUT]

■ Test Setup Photo (Front for Extremity SAR)



[Distance of **0 cm** from the EUT]

■ **Test Setup Photo (Right for Extremity SAR)**



[Distance of 0 cm from the EUT]

■ Test Setup Photo (Top for Extremity SAR)



[Distance of 0 cm from the EUT]