

How to Use

Equalizer

- While playing music, press and hold VOLUME UP and VOLUME DOWN buttons simultaneously for 1 second to switch between EQ's (Bass Boost(Default) → Normal → Treble Boost).
- The bass coming from the speakers can vary as a result of the size of the Earbud that is being used.

aptX®

- HBS-750 features aptX® technology that ensures audio content transmitted over Bluetooth is instant and crystal-clear.
- aptX® is automatically enabled as long as the source device supports it.

Vibrate Control

- To activate or deactivate the 'Vibrate' function, press and hold VOLUME UP button for 3 seconds. You will hear "Vibrate on" or "Vibrate off" when it is activated or deactivated.
- When HBS-750 is set to vibrate off, and HBS-750 will not vibrate when receiving 'incoming call' and being 'out of range'.
- By powering the unit off and then powering the unit back on, the vibration functionality will be activated.

SMS Reader

The HBS-750 Bluetooth headset supports SMS reading on Android™ based devices.

In Google Play™ Store search for the LG 'BT Reader' application and install on your device to use this function.

* The 2D barcode shown below helps you download the LG 'BT Reader' application from Google Play™ Store. Google Play is a trademark of Google, Inc.



Function	HBS-750 Status	Action
Operating	Power on	The blue LED light flickers 4 times.
	Power off	The blue LED light flickers 4 times and then turns off.
	Pairing mode	The blue LED light stays on.
	Headset / hands-free profile connected	The blue LED light flickers 2 times every 5 seconds.
	Call connected	The blue LED light flickers 2 times every 5 seconds.
Charging	Charging	The red LED stays on and changes to violet when charged 80% and above.
	Charging complete	The blue LED stays on.

Troubleshooting

Issue	Possible problem	Resolution
Does not turn on	Check whether the battery of the HBS-750 is fully charged.	Charge the battery.
Unable to communicate with the LG Bluetooth® Headset HBS-750	Check whether the handset supports the headset or hands-free Bluetooth profiles.	Determine whether your handset supports the headset or hands-free Bluetooth profiles.
	Check whether the battery of the HBS-750 is low.	Charge the battery.
Unable to pair the HBS-750 with the Bluetooth® device	Check and make sure the headset is on.	Slide the Power switch to the 'ON' side to turn on the headset.
	Check and make sure the headset is placed in pairing mode.	With the power off, press the CALL button and move the Power switch to the 'ON' side at the same time for 1 second to manually place the headset in pairing mode.
Low sound (speaker)	Check the speaker volume.	Increase the volume level.

Precautions

Do not drop the unit from high places.

Do not modify, repair, or take apart.

Do not expose directly to water, alcohol, benzene, etc. for cleaning.

Do not expose directly to flammables.

Do not place or keep the unit near flammables.

Keep unit away from humidity & dust.

Do not place heavy objects on the unit.

Only use the headset with an original LG charger, otherwise it may be damaged.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- There is a risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- The neck strap is made of a shape memory alloy. However, bending the neck strap repeatedly is not recommended.

Declaration of Confirmation

FCC NOTICE TO USERS :

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE :

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

CE NOTICE TO USERS :

Hereby, LG Electronics Inc. declares that this HBS-750 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



Bluetooth®

CE 1177

FCC ID: BEJHBS750



1. Radio frequency exposure

This Bluetooth® Headset, HBS-750, is a radio transmitter and receiver. When in operation, it communicates with a Bluetooth® equipped mobile device by receiving and transmitting radio frequency (RF) electromagnetic fields (microwaves) in the frequency range 2.4 to 2.4835 GHz.

Your Bluetooth® Headset is designed to operate in compliance with the RF exposure guidelines and limits set by national authorities and international health agencies when used any compatible LG Electronics mobile phone.

2. Potentially explosive atmosphere

Turn off your electronic device when in any area with a potentially explosive atmosphere. It is rare, but your electronic device could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive atmosphere are often, but not always, clearly marked.

3. Battery information

A rechargeable battery has a long service life if treated properly. A new battery or one that has not been used for a long period of time could have reduced capacity the first few times it is used. Do not expose the battery to extreme temperatures, never above +60°(+140°F) or under -20°(-4°F). For maximum battery capacity, use the battery in room temperature. If the battery is used in low temperatures, the battery capacity will be reduced. The battery can only be charged in temperatures between +10°(+50°F) and +45°(+113°F). For your safety, do not remove the battery incorporated in the product.

If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.

4. Recycling the battery in your Bluetooth® Headset

The battery in your Bluetooth® Headset must be disposed of properly and should never be placed in municipal waste. The LG Electronics service partner removing battery will dispose of it according to local regulations.



Disposal of waste batteries/accumulators

- 1 This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 2 All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3 The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 4 For more detailed information about disposal of your old batteries/accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.

5. Conditions

- The warranty is valid only if the original receipt issued to the original purchaser by the dealer, specifying the date of purchase and serial number, is presented with the product to be repaired or replaced. LG Electronics reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the product from the dealer.
- If LG Electronics repairs or replaces the product, the repaired or replaced product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of LG Electronics.
- This Warranty does not cover any failure of the product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with instructions for use and maintenance of the product. Nor does this warranty cover any failure of the product due to accident, modification or adjustment, acts of God or damage resulting from liquid.
- This warranty does not cover product failures due to improper repair installations, modifications or service performed by a non-LG Electronics authorized person. Tampering with any of the seals on the product will void the warranty.

Limited Warranty

SUBJECT TO THE CONDITIONS OF THIS LIMITED WARRANTY, LG ELECTRONICS WARRANTS THIS PRODUCT TO BE FREE FROM DEFECTS IN DESIGN, MATERIAL AND WORKMANSHIP AT THE TIME OF ITS ORIGINAL PURCHASE BY A CONSUMER, AND FOR A SUBSEQUENT PERIOD OF ONE (1) YEAR. SHOULD YOUR PRODUCT NEED WARRANTY SERVICE, PLEASE RETURN IT TO THE DEALER FROM WHOM IT WAS PURCHASED OR CONTACT YOUR LOCAL LG ELECTRONICS CONTACT CENTER TO GET FURTHER INFORMATION.

Avoiding hearing damage

Permanent hearing loss may occur if you use your Handsfree car kit at a high volume. Set the volume to a safe level. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing.

If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing:

- Limit the amount of time you use Headset at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.



Please refer to your handset user guide for more information on how to adjust listening levels on your handset.

Using Headset safely

Use of Headset to listen to music while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop using this device if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.

MEMO