


## Antenna and Device Information

Front



### E1\_LTE Antenna

| Antenna | Mode    | Band                           |
|---------|---------|--------------------------------|
| ANT1    | Main LB | B17/28/20/5/8/7<br>GSM850/EGSM |
| ANT2    | Main HB | B1/2/3/4<br>DCS1800/PCS1900    |
| ANT3    | GPS     | GPS                            |
| ANT4    | WiFi    | WiFi2.4GHz                     |
| ANT5    | HB MRD  | B1/2/3/4/7                     |
| ANT6    | LB MRD  | B5/8/17/20/28                  |

Right

## **SAR Test Setup Photographs**

■ **Test Setup Photo (Left All)**



■ **Test Setup Photo(Left Touch/Tilt)**



■ **Test Setup Photo (Right All)**



■ **Test Setup Photo (Right Touch/Tilt)**



■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Front)**



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo (Right)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo(Top)**



**[Distance of 1.0 cm from the EUT]**

■ **Test Setup Photo(Bottom)**



**[Distance of 1.0 cm from the EUT]**