

SAR Test Setup Photographs

■ Test Setup Photo Rear

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo Front

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo bottom

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo Left

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo Right

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo Top

[Distance of 0.5 cm from the EUT]

■ Test Setup Photo (Rear, Front)

■ Test Setup Photo (Left, Right, Top, Bottom)