




RECEPTOR DE AUDIO INALÁMBRICO DE TRANSMISIÓN DE MÚSICA

AP-BTM-1200



- Blue/White Stripe - Remote Out / Raya azul/blanca - Salida remota**
- + Red- (B-) -12V / Roja- (B-) -12V**
- Black- (B-) - Ground / Negra- (B-) - Tierra**
- White RCA - Left Output / RCA blanca - Salida izquierda**
- Red RCA - Right Output / RCA rojo - Salida derecha**

Wiring options:

Red ---- (+12V) Power

Black ---- (-12V) Ground

Blue/White Strip ---- Remote Turn on (Output to Amp)

RCA ---- (3.5mm) Audio output (Amp)

Unit installation

- 1. Connect Red (+12V) wire to constant power (battery)**
- 2. Connect Black (-12V) wire to chassis ground**
- 3. Connect the Blue/White Strip wire (remote out) to the amplifier**
- 4. Connect RCA output to amplifier**

Pairing your device (required for operation):

- 1. Ensure your streaming device has wireless music stream enabled and that the power is turned on the AP-BTM-1200. (The blue LED on the AP-BTM-1200 will blink to indicate it is in pairing mode.)**
- 2. Within your streaming device's wireless music stream setup menu, select "AP-BTM-1200" from the list of pairable devices.**
- 3. When successfully connected, the blue LED on the AP-BTM-1200 will stop blinking and remain lit. A single beep will be heard through the connected audio system.**

Opciones de Cableado:

Roja ---- (+12V) Potencia

Negra ---- (-12V) Tierra

Franja azul/blanca ---- Encendido Remoto (Salida a Amplificador)

RCA ---- (3.5mm) Salida de Audio (Amplificador)

Instalación de la Unidad

- 1. Conecte el cable rojo (+12V) a la energía constante (Batería)**
- 2. Conecte el cable negro (-12V) a la tierra del chasis**
- 3. Conecte el cable de la tira azul/blanca (Salida Remota) al Amplificador**
- 4. Conecte la salida RCA al Amplificador.**

Emparejar su dispositivo (requerido para la operación):

- 1. Asegúrese de que su dispositivo de transmisión tenga transmisión de música inalámbrica habilitada y que la energía se aplique al AP-BTM-1200. (El LED azul en el AP-BTM-1200 parpadeará para indicar que está en modo de emparejamiento).**
- 2. Dentro del menú de configuración de transmisión de música inalámbrica de su dispositivo de transmisión, seleccione "AP-BTM-1200" de la lista de dispositivos compatibles.**
- 3. Cuando se conecta correctamente, el LED azul en el AP-BTM-1200 dejará de parpadear y permanecerá encendido. Se escuchará un solo pitido a través del sistema de audio conectado.**



FCC compliance statement:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- [1] this device may not cause harmful interference, and
- [2] this device must accept any interference received, including interference that may cause undesired operation.

This device and its antennas must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

To maintain compliance with FCC's R F Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.

Declaración de cumplimiento de la FCC:

Nota: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la Parte 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y, si no se instala y usa de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- Reorientar o reubicar la antena receptora.
- Aumente la separación entre el equipo y el receptor.
- Conectar el equipo a una toma de corriente de un circuito diferente al cual el receptor está conectado.
- Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda.

Los cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.

Este dispositivo cumple con la Parte 15 de las normas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes.

- [1] Es posible que este dispositivo no cause interferencias dañinas y
- [2] Este dispositivo debe aceptar cualquier interferencia recibida, incluida la interferencia que pueda causar un funcionamiento no deseado.