

BLUETOOTH® VANITY MIRROR

CONTENTS

Mirror
Power Adapter
Auxiliary Cable
Cleaning Cloth

Note: The mirror can rotate 270 degrees, not 360 degrees.
1 side of the mirror is 1x and the other side is 7x magnification.

Fully charge before first use

CONNECTING:

1. Make sure Bluetooth® is enabled on your device.
2. Press the power button to turn on the unit. You will hear a beep.
3. Press and hold the power button, you will hear voice prompt "Waiting for device".
4. On your device, search for Bluetooth® devices and select "VANITY MIRROR". You will hear a beep and the Bluetooth® Indicator light will remain on when a device is successfully paired.


Note: Volume is controlled by both your device and the BT Vanity Mirror. Check your device's volume if volume is too low.

FRONT PANEL FUNCTIONS:

- Bluetooth® Power – Press to turn speaker on (BT Indicator LED light will blink slowly) and press again to turn off (BT Indicator LED light will turn off). Long press to enter pair mode (BT Indicator LED light will blink quickly). BT Indicator Light will turn blue and remain constant when device is paired to mirror.
- Bluetooth® Indicator – light flashes quicker when in pairing mode.
- Play/Pause/Answer – Press to pause/play music. Music will pause automatically when a call is incoming. Press to answer call and press again to end call and resume music.
- Plus Volume/Skip – Long press to increase volume. Press to skip to the next song
- Minus Volume/Skip – Long press to decrease volume. Press to skip to the previous song
- Charge Indicator – Light will turn red when mirror has 10% battery life. While charging, LED will be on until mirror is fully charged
- Light Power – Press to turn light on, press again to dim, press again to turn light off. Note: light will time out after 25 minutes

SIDE PANEL FUNCTIONS:

- A. Auxiliary – Use to play music through your auxiliary supported devices. Auxiliary input only
- B. USB – Charge your cell phone or other USB powered devices. Provided Power Adapter is needed to use this function.
- C. Micro USB port – Use to plug in your Power Adapter



SAFETY WARNINGS: PLEASE READ ALL SAFETY WARNINGS BEFORE USE

- Not intended for children under 14 years of age.
- Keep out of reach of children.
- Use this product only for its intended use. Do not use attachments of any kind.
- This item has no user serviceable components. Do not disassemble.
- Do not expose to extreme temperatures or moisture
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

RECHARGEABLE BATTERY WARNING:

- This product contains batteries that are non-replaceable.
- There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- Rechargeable battery is only to be charged by an adult.
- Adult Supervision of the battery while it is charging is required.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products
- Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong odor.
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts, and in the event of such damage, they must not be used until the damage has been repaired.
- Recycle or dispose of battery according to federal, state, and local laws
- Keep these instructions for future reference.

©2018 MerchSource, LLC. Irvine, CA 92618. All rights reserved.

BC

For technical support, please call 1-800-374-2744.

Model No. 1005839

Printed in China.

Use 5V DC UL-certified adapter only (5V, 2A). Adapter included. Never leave the unit plugged in unattended for extended periods of time.

KEEP THIS INSTRUCTION MANUAL AS IT CONTAINS IMPORTANT INFORMATION FOR FUTURE REFERENCE.

Due to continuous product improvements, the picture on the manual may differ slightly from the actual product.