


1. External Photograph of the Host

Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



2. Photograph of Accessory for the Host

Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)

List of Accessory for Host (Tablet):

Specification of Accessory		
AC Adapter 2	Brand Name	FSP
	Model Name	FSP065-RBBN3
Battery 2	Brand Name	Getac
	Model Name	BP3S1P2290 A

Remark:


1. For accessories equipped with this EUT, please refer to the following photos.
2. The EP391803-69 report reuses SKU E setup photo from the EP391803-56 report.

Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)

AC Adapter 2



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)




Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)

Battery 2



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)



Host: Tablet (Brand Name: Getac / Model Name: F110, F110G5, F110-Ex)

