














































































































NTNV 11AX20SISO Ant1 5700 30~5460



NTNV 11AX20SISO Ant1 5700 5460~5470



NTNV 11AX20SISO Ant1 5700 5745~5765






































NTLV 11A Ant1 5180 30~5142



NTLV 11A Ant1 5180 5142~5150



NTLV 11A Ant1 5180 5250~5251







NTLV 11A Ant1 5200 5251~5260




NTLV 11A Ant1 5200 5260~5266.7



NTLV 11A Ant1 5200 5266.7~26000








NTLV 11A Ant1 5260 30~5233.3



NTLV 11A Ant1 5260 5233.3~5240



NTLV 11A Ant1 5260 5240~5249



































NTLV 11N20SISO Ant1 5260 5249~5250



NTLV 11N20SISO Ant1 5260 5350~26000



NTLV 11N20SISO Ant1 5280 30~5233.3





















































































