


1	"+" Button
2	MFB Button
3	"-" Button
4	LED
5	USB C - Charging Port
6	Mic

YY2958 부품LIST

CRESYN



PART LIST			
NO	PART NAME	Q'ty	SPEC / COLOR
1	HEAD BAND	1	PP2300, BLACK
2	BAND CORD	1	Ø1.2, 2P, BLACK
3	HEAD PAD	1	PU005+ PC SHEET+ Y28+ DY15, BLACK
4	PLATE CLICK	2	POM M90
5	SLIDER	2	ABS, GAR-011(H85), BLACK
6	HANGER L	1	ABS, GAR-011(H85), BLACK
7	C-RING	2	SUS304
8	CUSHION TWIST	6	SILICONE 70A
9	HANGER R	1	ABS, GAR-011(H85), BLACK
10	LID SLIDER	2	ABS, GAR-011(H85), BLACK
11	HOUSING L	1	ABS, GAR-011(H85), BLACK
12	HOUSING DAMPER L	1	#330+ PET
13	HOUSING R	1	ABS, GAR-011(H85), BLACK
14	HOUSING DAMPER R	1	#330+ PET
15	MF BUTTON	1	ABS, GAR-011(H85), BLACK
16	VOL BUTTON	1	ABS, GAR-011(H85), BLACK
17	Li-ion Polymer Battery Pack	1	-
18	CUSHION_BATTERY	1	PORON SR-S15P(T=0.5)+ 日东500(t0.10)
19	R-MAIN PCB ASS'Y	1	-
20	LED LENS	1	PC110
21	Electret Condenser MIC Ass'y	1	-
22	SHEET BATTERY	1	PET SG00(t0.30) + 日东500(t0.15)
23	PLATE DRIVER L	1	ABS, GAR-011(H85), BLACK
24	FRONT DAMPER A	2	SA30B + SK800
25	FRONT DAMPER B	4	C4000
26	UNIT ASSY	1	
27	PLATE DRIVER R	1	ABS, GAR-011(H85), BLACK
28	UNIT ASSY	1	
29	UNIT CORD R	1	TPE(83A)
30	SCREW	11	BLACK
31	EAR PAD	2	PU005+ DE7+ EV130+ TPU+ SPONGE