Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 15/25 1805-1845MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 6/25 2010-2025MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 18/25 2330-2370MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 23/25 3590.3-3600MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 24/25 3600-4100MHz Limit:-30



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV 25/25 4500-4900MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 2/25 0.15-30MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 9/25 770-773MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 10/25 773-803MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 11/25 860-890MHz Limit:-40



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 12/25 945-960MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 15/25 1805-1845MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 24/25 3600-4100MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_0_NTNV 25/25 4500-4900MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 1/25 0.009-0.15MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 2/25 0.15-30MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 3/25 30-1000MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 8/25 470-710MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 9/25 770-773MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 10/25 773-803MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 11/25 860-890MHz Limit:-40



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 12/25 945-960MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 4/25 1000-12750MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 15/25 1805-1845MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 5/25 1845-1880MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 6/25 2010-2025MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 17/25 2114.4-2170MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 18/25 2330-2370MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 19/25 3400-3419.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 24/25 3600-4100MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_1_49_NTNV 25/25 4500-4900MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 2/25 0.15-30MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 9/25 770-773MHz Limit:-36



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 10/25 773-803MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 11/25 860-890MHz Limit:-40



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 12/25 945-960MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 15/25 1805-1845MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 24/25 3600-4100MHz Limit:-30



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV 25/25 4500-4900MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

6.2.4 B26_15MHz

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 2/25 0.15-30MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 9/25 770-773MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 10/25 773-803MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 12/25 945-960MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 15/25 1805-1845MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 24/25 3600-4100MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_0_NTNV 25/25 4500-4900MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 1/25 0.009-0.15MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 2/25 0.15-30MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 3/25 30-1000MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 8/25 470-710MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 9/25 770-773MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 10/25 773-803MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 12/25 945-960MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 4/25 1000-12750MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 15/25 1805-1845MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 5/25 1845-1880MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 6/25 2010-2025MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 17/25 2114.4-2170MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 18/25 2330-2370MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 23/25 3590.3-3600MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 24/25 3600-4100MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_1_74_NTNV 25/25 4500-4900MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 2/25 0.15-30MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 9/25 770-773MHz Limit:-36



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 10/25 773-803MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 12/25 945-960MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 15/25 1805-1845MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 24/25 3600-4100MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV 25/25 4500-4900MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 2/25 0.15-30MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 3/25 30-1000MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 8/25 470-710MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 9/25 770-773MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 10/25 773-803MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 11/25 860-890MHz Limit:-40



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 12/25 945-960MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 15/25 1805-1845MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 5/25 1845-1880MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 6/25 2010-2025MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 17/25 2114.4-2170MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 18/25 2330-2370MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 19/25 3400-3419.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 24/25 3600-4100MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_0_NTNV 25/25 4500-4900MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 2/25 0.15-30MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 3/25 30-1000MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 8/25 470-710MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 9/25 770-773MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 10/25 773-803MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 12/25 945-960MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 13/25 1475.9-1496.7MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 15/25 1805-1845MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 5/25 1845-1880MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 6/25 2010-2025MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 20/25 3419.3-3500.7MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 22/25 3574.7-3590.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 24/25 3600-4100MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_1_74_NTNV 25/25 4500-4900MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 2/25 0.15-30MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 3/25 30-1000MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 8/25 470-710MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 9/25 770-773MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 10/25 773-803MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 11/25 860-890MHz Limit:-40



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 12/25 945-960MHz Limit:-36



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 4/25 1000-12750MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 15/25 1805-1845MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 5/25 1845-1880MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 6/25 2010-2025MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 17/25 2114.4-2170MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 18/25 2330-2370MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 19/25 3400-3419.3MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 23/25 3590.3-3600MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 24/25 3600-4100MHz Limit:-30



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV 25/25 4500-4900MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 2/25 0.15-30MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 9/25 770-773MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 10/25 773-803MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 12/25 945-960MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 15/25 1805-1845MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 7/25 2110-2144.4MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 24/25 3600-4100MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_0_NTNV 25/25 4500-4900MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 1/25 0.009-0.15MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 2/25 0.15-30MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 3/25 30-1000MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 8/25 470-710MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 9/25 770-773MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 10/25 773-803MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 12/25 945-960MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 14/25 1496.7-1510.9MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 15/25 1805-1845MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 5/25 1845-1880MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 6/25 2010-2025MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 7/25 2110-2144.4MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 17/25 2114.4-2170MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 18/25 2330-2370MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 19/25 3400-3419.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 23/25 3590.3-3600MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 24/25 3600-4100MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_1_74_NTNV 25/25 4500-4900MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 1/25 0.009-0.15MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 2/25 0.15-30MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 3/25 30-1000MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 8/25 470-710MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 9/25 770-773MHz Limit:-36



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 10/25 773-803MHz Limit:-36



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 11/25 860-890MHz Limit:-40



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 12/25 945-960MHz Limit:-36



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 4/25 1000-12750MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 13/25 1475.9-1496.7MHz Limit:-50



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 14/25 1496.7-1510.9MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 15/25 1805-1845MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 5/25 1845-1880MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 16/25 1906.6-1915.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 6/25 2010-2025MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 7/25 2110-2144.4MHz Limit:-50



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 17/25 2114.4-2170MHz Limit:-50



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 18/25 2330-2370MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.
BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 19/25 3400-3419.3MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 20/25 3419.3-3500.7MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 21/25 3500.7-3574.7MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 22/25 3574.7-3590.3MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.
BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 23/25 3590.3-3600MHz Limit:-30



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 24/25 3600-4100MHz Limit:-30



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV 25/25 4500-4900MHz Limit:-30



Total or partial reproduction of this document without permission of the Laboratory is not allowed.
BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

7. Leakage Power at No-carrier Transmission

7.1 Test Result

7.1.1 B26

Band: 26						
BW(MHz)	Low Ch	Mid. Ch	High Ch	Unit	Limit	Result
3	-73.52	-74.38	-74.47	dBm/2.7MHz	<=-48.5	Pass
5	-71.60	-71.97	-72.48	dBm/4.5MHz	<=-48.5	Pass
10	-69.29	-69.79	-69.22	dBm/9MHz	<=-48.5	Pass
15	-66.94	-66.67	-67.86	dBm/13.5MHz	<=-48.5	Pass

Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

7.2 Test Graph

7.2.1 B26

Band26_3MHz_QPSK_LCH_816.5MHz_RB_15_0_NTNV



Band26_3MHz_QPSK_MCH_830MHz_RB_15_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_3MHz_QPSK_HCH_843.5MHz_RB_15_0_NTNV



Band26_5MHz_QPSK_LCH_817.5MHz_RB_25_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_5MHz_QPSK_MCH_830MHz_RB_25_0_NTNV



Band26_5MHz_QPSK_HCH_842.5MHz_RB_25_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_LCH_820MHz_RB_50_0_NTNV



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

8. Limit of Secondary Radiated Emissions

8.1 Test Result

8.1.1 B26_3MHz

Band: 26 / Bandwidth: 3MHz										
Ant	Channel Number	26715		26850		26985		Unit	Limit	Result
	Frequency Center (MHz)	816.5		830		843.5				
	Measured Value	Freq. (MHz)	Level	Freq. (MHz)	Level	Freq. (MHz)	Level			
RX1	30MHz ~ 1000MHz	150.400	-58.73	150.400	-61.51	85.950	-62.99	dBm/100kHz	<=-57	Pass
	1000MHz ~ 12.75GHz	1830.500	-64.87	1951.000	-47.91	1830.500	-64.94	dBm/MHz	<=-47	Pass

8.1.2 B26_5MHz

Band: 26 / Bandwidth: 5MHz										
Ant	Channel Number	26725		26850		26975		Unit	Limit	Result
	Frequency Center (MHz)	817.5		830		842.5				
	Measured Value	Freq. (MHz)	Level	Freq. (MHz)	Level	Freq. (MHz)	Level			
RX1	30MHz ~ 1000MHz	85.950	-62.53	85.950	-60.99	85.950	-61.72	dBm/100kHz	<=-57	Pass
	1000MHz ~ 12.75GHz	1924.000	-59.54	1710.500	-58.86	1710.500	-58.85	dBm/MHz	<=-47	Pass

8.1.3 B26_10MHz

Band: 26 / Bandwidth: 10MHz										
Ant	Channel Number	26750		26850		26950		Unit	Limit	Result
	Frequency Center (MHz)	820		830		840				
	Measured Value	Freq. (MHz)	Level	Freq. (MHz)	Level	Freq. (MHz)	Level			
RX1	30MHz ~ 1000MHz	85.950	-61.16	85.950	-62.15	85.950	-61.54	dBm/100kHz	<=-57	Pass
	1000MHz ~ 12.75GHz	1710.500	-56.07	1710.500	-57.21	3595.500	-51.11	dBm/MHz	<=-47	Pass

8.1.4 B26_15MHz

Band: 26 / Bandwidth: 15MHz										
Ant	Channel Number	26775		26850		26925		Unit	Limit	Result
	Frequency Center (MHz)	822.5		830		837.5				
	Measured Value	Freq. (MHz)	Level	Freq. (MHz)	Level	Freq. (MHz)	Level			
RX1	30MHz ~ 1000MHz	85.950	-61.66	85.950	-62.01	85.900	-64.43	dBm/100kHz	<=-57	Pass
	1000MHz ~ 12.75GHz	1710.500	-54.00	1830.500	-58.79	1747.500	-57.84	dBm/MHz	<=-47	Pass

Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

8.2 Test Graph

8.2.1 B26_3MHz

Band26_3MHz_QPSK_LCH_816.5MHz_RB_15_0_NTNV



Band26_3MHz_QPSK_LCH_816.5MHz_RB_15_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_3MHz_QPSK_MCH_830MHz_RB_15_0_NTNV



Band26_3MHz_QPSK_MCH_830MHz_RB_15_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_3MHz_QPSK_HCH_843.5MHz_RB_15_0_NTNV



Band26_3MHz_QPSK_HCH_843.5MHz_RB_15_0_NTNV



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

8.2.2 B26_5MHz

Band26_5MHz_QPSK_LCH_817.5MHz_RB_25_0_NTNV



Band26_5MHz_QPSK_LCH_817.5MHz_RB_25_0_NTNV



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_5MHz_QPSK_MCH_830MHz_RB_25_0_NTNV



Band26_5MHz_QPSK_MCH_830MHz_RB_25_0_NTNV



Band26_5MHz_QPSK_HCH_842.5MHz_RB_25_0_NTNV



Band26_5MHz_QPSK_HCH_842.5MHz_RB_25_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

8.2.3 B26_10MHz

Band26_10MHz_QPSK_LCH_820MHz_RB_50_0_NTNV



Band26_10MHz_QPSK_LCH_820MHz_RB_50_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV



Band26_10MHz_QPSK_MCH_830MHz_RB_50_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV



Band26_10MHz_QPSK_HCH_840MHz_RB_50_0_NTNV



8.2.4 B26_15MHz

Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV



Band26_15MHz_QPSK_LCH_822.5MHz_RB_75_0_NTNV



Total or partial reproduction of this document without permission of the Laboratory is not allowed.

BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV



Band26_15MHz_QPSK_MCH_830MHz_RB_75_0_NTNV



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com

Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV



Band26_15MHz_QPSK_HCH_837.5MHz_RB_75_0_NTNV



BTF Testing Lab (Shenzhen) Co., Ltd.
Plant 101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street, Bao'an District, Shenzhen, Guangdong, China
Email: info@btf-lab.com Tel: +86-755-23146130 http://www.btf-lab.com