








NTNV-11A-Ant1-5220-PASS



NTNV-11A-Ant1-5240-PASS












複製





NTNV-11AC20SISO











Appendix H: Carrier Sense Function**Test Result**

Test Item	Test mode	Test Result
Carrier Sensing Function	11A	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	N20	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	AC20	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	AX20	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	N40	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	AC40	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)
	AX40	Good (EUT Stop RF transmission signal after carrier inject to EUT. Stop carrier inject, EUT will transmitting normal.)

Appendix I: INTERFERENCE PREVENTION FUNCTION

Test Result

Test Item	Test Result
Transmitting Function of Identification Code	Good
Receiving Function of Identification Code	Good

Identification Code	54:EF:44:90:B8:92
---------------------	-------------------

Appendix J: Out band Emission Power**Test Result**


TestCondition	TestMode	Antenna	Channel	FreRang [MHz]	Verdict
NTNV	11A	Ant1	5180	5140~5142	PASS
NTNV	11A	Ant1	5180	5142~5150	PASS
NTNV	11A	Ant1	5180	5250~5251	PASS
NTNV	11A	Ant1	5180	5251~5260	PASS
NTNV	11A	Ant1	5180	5260~5266.7	PASS
NTNV	11A	Ant1	5180	5266.7~5360	PASS
NTNV	11A	Ant1	5200	5140~5142	PASS
NTNV	11A	Ant1	5200	5142~5150	PASS
NTNV	11A	Ant1	5200	5250~5251	PASS
NTNV	11A	Ant1	5200	5251~5260	PASS
NTNV	11A	Ant1	5200	5260~5266.7	PASS
NTNV	11A	Ant1	5200	5266.7~5360	PASS
NTNV	11A	Ant1	5220	5140~5142	PASS
NTNV	11A	Ant1	5220	5142~5150	PASS
NTNV	11A	Ant1	5220	5250~5251	PASS
NTNV	11A	Ant1	5220	5251~5260	PASS
NTNV	11A	Ant1	5220	5260~5266.7	PASS
NTNV	11A	Ant1	5220	5266.7~5360	PASS
NTNV	11A	Ant1	5240	5140~5142	PASS
NTNV	11A	Ant1	5240	5142~5150	PASS
NTNV	11A	Ant1	5240	5250~5251	PASS
NTNV	11A	Ant1	5240	5251~5260	PASS
NTNV	11A	Ant1	5240	5260~5266.7	PASS
NTNV	11A	Ant1	5240	5266.7~5360	PASS
NTNV	11N20SISO	Ant1	5180	5140~5142	PASS
NTNV	11N20SISO	Ant1	5180	5142~5150	PASS
NTNV	11N20SISO	Ant1	5180	5250~5251	PASS
NTNV	11N20SISO	Ant1	5180	5251~5260	PASS
NTNV	11N20SISO	Ant1	5180	5260~5266.7	PASS
NTNV	11N20SISO	Ant1	5180	5266.7~5360	PASS
NTNV	11N20SISO	Ant1	5200	5140~5142	PASS
NTNV	11N20SISO	Ant1	5200	5142~5150	PASS
NTNV	11N20SISO	Ant1	5200	5250~5251	PASS
NTNV	11N20SISO	Ant1	5200	5251~5260	PASS
NTNV	11N20SISO	Ant1	5200	5260~5266.7	PASS
NTNV	11N20SISO	Ant1	5200	5266.7~5360	PASS
NTNV	11N20SISO	Ant1	5220	5140~5142	PASS
NTNV	11N20SISO	Ant1	5220	5142~5150	PASS


NTNV	11N20SISO	Ant1	5220	5250~5251	PASS
NTNV	11N20SISO	Ant1	5220	5251~5260	PASS
NTNV	11N20SISO	Ant1	5220	5260~5266.7	PASS
NTNV	11N20SISO	Ant1	5220	5266.7~5360	PASS
NTNV	11N20SISO	Ant1	5240	5140~5142	PASS
NTNV	11N20SISO	Ant1	5240	5142~5150	PASS
NTNV	11N20SISO	Ant1	5240	5250~5251	PASS
NTNV	11N20SISO	Ant1	5240	5251~5260	PASS
NTNV	11N20SISO	Ant1	5240	5260~5266.7	PASS
NTNV	11N20SISO	Ant1	5240	5266.7~5360	PASS
NTNV	11N40SISO	Ant1	5190	5100~5141.6	PASS
NTNV	11N40SISO	Ant1	5190	5141.6~5150	PASS
NTNV	11N40SISO	Ant1	5190	5250~5251	PASS
NTNV	11N40SISO	Ant1	5190	5251~5270	PASS
NTNV	11N40SISO	Ant1	5190	5270~5278.4	PASS
NTNV	11N40SISO	Ant1	5190	5278.4~5400	PASS
NTNV	11N40SISO	Ant1	5230	5100~5141.6	PASS
NTNV	11N40SISO	Ant1	5230	5141.6~5150	PASS
NTNV	11N40SISO	Ant1	5230	5250~5251	PASS
NTNV	11N40SISO	Ant1	5230	5251~5270	PASS
NTNV	11N40SISO	Ant1	5230	5270~5278.4	PASS
NTNV	11N40SISO	Ant1	5230	5278.4~5400	PASS
NTNV	11AC20SISO	Ant1	5180	5140~5142	PASS
NTNV	11AC20SISO	Ant1	5180	5142~5150	PASS
NTNV	11AC20SISO	Ant1	5180	5250~5251	PASS
NTNV	11AC20SISO	Ant1	5180	5251~5260	PASS
NTNV	11AC20SISO	Ant1	5180	5260~5266.7	PASS
NTNV	11AC20SISO	Ant1	5180	5266.7~5360	PASS
NTNV	11AC20SISO	Ant1	5200	5140~5142	PASS
NTNV	11AC20SISO	Ant1	5200	5142~5150	PASS
NTNV	11AC20SISO	Ant1	5200	5250~5251	PASS
NTNV	11AC20SISO	Ant1	5200	5251~5260	PASS
NTNV	11AC20SISO	Ant1	5200	5260~5266.7	PASS
NTNV	11AC20SISO	Ant1	5200	5266.7~5360	PASS
NTNV	11AC20SISO	Ant1	5220	5140~5142	PASS
NTNV	11AC20SISO	Ant1	5220	5142~5150	PASS
NTNV	11AC20SISO	Ant1	5220	5250~5251	PASS
NTNV	11AC20SISO	Ant1	5220	5251~5260	PASS
NTNV	11AC20SISO	Ant1	5220	5260~5266.7	PASS
NTNV	11AC20SISO	Ant1	5220	5266.7~5360	PASS
NTNV	11AC20SISO	Ant1	5240	5140~5142	PASS
NTNV	11AC20SISO	Ant1	5240	5142~5150	PASS

NTNV	11AC20SISO	Ant1	5240	5250~5251	PASS
NTNV	11AC20SISO	Ant1	5240	5251~5260	PASS
NTNV	11AC20SISO	Ant1	5240	5260~5266.7	PASS
NTNV	11AC20SISO	Ant1	5240	5266.7~5360	PASS
NTNV	11AC40SISO	Ant1	5190	5100~5141.6	PASS
NTNV	11AC40SISO	Ant1	5190	5141.6~5150	PASS
NTNV	11AC40SISO	Ant1	5190	5250~5251	PASS
NTNV	11AC40SISO	Ant1	5190	5251~5270	PASS
NTNV	11AC40SISO	Ant1	5190	5270~5278.4	PASS
NTNV	11AC40SISO	Ant1	5190	5278.4~5400	PASS
NTNV	11AC40SISO	Ant1	5230	5100~5141.6	PASS
NTNV	11AC40SISO	Ant1	5230	5141.6~5150	PASS
NTNV	11AC40SISO	Ant1	5230	5250~5251	PASS
NTNV	11AC40SISO	Ant1	5230	5251~5270	PASS
NTNV	11AC40SISO	Ant1	5230	5270~5278.4	PASS
NTNV	11AC40SISO	Ant1	5230	5278.4~5400	PASS
NTNV	11AX20SISO	Ant1	5180	5135~5142	PASS
NTNV	11AX20SISO	Ant1	5180	5142~5150	PASS
NTNV	11AX20SISO	Ant1	5180	5250~5250.2	PASS
NTNV	11AX20SISO	Ant1	5180	5250.2~5251	PASS
NTNV	11AX20SISO	Ant1	5180	5251~5260	PASS
NTNV	11AX20SISO	Ant1	5180	5260~5266.7	PASS
NTNV	11AX20SISO	Ant1	5180	5266.7~5365	PASS
NTNV	11AX20SISO	Ant1	5200	5135~5142	PASS
NTNV	11AX20SISO	Ant1	5200	5142~5150	PASS
NTNV	11AX20SISO	Ant1	5200	5250~5250.2	PASS
NTNV	11AX20SISO	Ant1	5200	5250.2~5251	PASS
NTNV	11AX20SISO	Ant1	5200	5251~5260	PASS
NTNV	11AX20SISO	Ant1	5200	5260~5266.7	PASS
NTNV	11AX20SISO	Ant1	5200	5266.7~5365	PASS
NTNV	11AX20SISO	Ant1	5220	5135~5142	PASS
NTNV	11AX20SISO	Ant1	5220	5142~5150	PASS
NTNV	11AX20SISO	Ant1	5220	5250~5250.2	PASS
NTNV	11AX20SISO	Ant1	5220	5250.2~5251	PASS
NTNV	11AX20SISO	Ant1	5220	5251~5260	PASS
NTNV	11AX20SISO	Ant1	5220	5260~5266.7	PASS
NTNV	11AX20SISO	Ant1	5220	5266.7~5365	PASS
NTNV	11AX20SISO	Ant1	5240	5135~5142	PASS
NTNV	11AX20SISO	Ant1	5240	5142~5150	PASS
NTNV	11AX20SISO	Ant1	5240	5250~5250.2	PASS
NTNV	11AX20SISO	Ant1	5240	5250.2~5251	PASS
NTNV	11AX20SISO	Ant1	5240	5251~5260	PASS


NTNV	11AX20SISO	Ant1	5240	5260~5266.7	PASS
NTNV	11AX20SISO	Ant1	5240	5266.7~5365	PASS
NTNV	11AX40SISO	Ant1	5190	5100~5141.6	PASS
NTNV	11AX40SISO	Ant1	5190	5141.6~5150	PASS
NTNV	11AX40SISO	Ant1	5190	5250~5251	PASS
NTNV	11AX40SISO	Ant1	5190	5251~5270	PASS
NTNV	11AX40SISO	Ant1	5190	5270~5278.4	PASS
NTNV	11AX40SISO	Ant1	5190	5278.4~5400	PASS
NTNV	11AX40SISO	Ant1	5230	5100~5141.6	PASS
NTNV	11AX40SISO	Ant1	5230	5141.6~5150	PASS
NTNV	11AX40SISO	Ant1	5230	5250~5251	PASS
NTNV	11AX40SISO	Ant1	5230	5251~5270	PASS
NTNV	11AX40SISO	Ant1	5230	5270~5278.4	PASS
NTNV	11AX40SISO	Ant1	5230	5278.4~5400	PASS

Test Graphs







NTNV-11A-Ant1-5220-5140~5142-PASS




NTNV-11A-Ant1-5240-5140~5142-PASS




NTNV-11N20SISO-Ant1-5180-5140~5142-PASS




NTNV-11N20SISO-Ant1-5200-5140~5142-PASS




NTNV-11N20SISO-Ant1-5220-5140~5142-PASS





NTNV-11N20SISO-Ant1-5240-5140~5142-PASS




NTNV-11N40SISO-Ant1-5190-5100~5141.6-PASS




NTNV-11N40SISO-Ant1-5230-5100~5141.6-PASS







NTNV-11AC20SISO-Ant1-5220-5140~5142-PASS




NTNV-11AC20SISO-Ant1-5240-5140~5142-PASS




NTNV-11AC40SISO-Ant1-5190-5100~5141.6-PASS




NTNV-11AC40SISO-Ant1-5230-5100~5141.6-PASS




NTNV-11AX20SISO-Ant1-5180-5135~5142-PASS




NTNV-11AX20SISO-Ant1-5200-5135~5142-PASS




NTNV-11AX20SISO-Ant1-5220-5135~5142-PASS



NTNV-11AX20SISO-Ant1-5240-5135~5142-PASS



NTNV-11AX40SISO-Ant1-5190-5100~5141.6-PASS



NTNV-11AX40SISO-Ant1-5230-5100~5141.6-PASS

APPENDIX PHOTOGRAPHS

Please refer to “ANNEX”

***** END OF REPORT *****