


1. External Photograph of EUT**Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)**

Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)




2. Photograph of Accessory

Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)

Specification of Accessory		
AC Adapter 1	Model Name	UCH20
	Manufacturer	飛宏
AC Adapter 2	Model Name	UCH20
	Manufacturer	群閔
Battery	Model Name	LIP1641ERPXC
Earphone 1	Model Name	MH410c
	Manufacturer	Foster
Earphone 2	Model Name	MH410c
	Manufacturer	Merry
USB Cable	Model Name	UCB20

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)



Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)

AC Adapter 1



Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)

AC Adapter 2



Brand Name: Sony / Model Name: Xperia XA1 Ultra (G3226)

Battery

