

1. External Photograph of EUT

Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND

Numeric Keypad with Camera





Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND

Numeric_DSD Keypad with Camera





Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND

PIM Keypad with Camera





Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND**Qwerty Keypad without Camera**



Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND

Numeric Keypad without Camera



Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND

Numeric_DSD Keypad without Camera



Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND

PIM Keypad without Camera





Brand Name: Zebra / Model Name: MC67ND



**2. Photograph of Accessory****Brand Name: Zebra / Model Name: MC67ND****List of Accessory:**

Specification of Accessory		
AC Adapter	Brand Name	MOTOROLA
	Model Name	86-14000-249R
Battery	Brand Name	MOTOROLA
	Model Name	82-111094-01
USB Cable	Brand Name	MOTOROLA
	Model Name	25-108022-02R
Holster-Rigid	Brand Name	MOTOROLA
	Model Name	SG-MC5511110-01R
Holster-Soft	Brand Name	MOTOROLA
	Model Name	SG-MC5521110-01R

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: MC67ND**AC Adapter**


Brand Name: Zebra / Model Name: MC67ND

Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND





Brand Name: Zebra / Model Name: MC67ND

Holster Rigid



Brand Name: Zebra / Model Name: MC67ND



Brand Name: Zebra / Model Name: MC67ND

Holster Soft



Brand Name: Zebra / Model Name: MC67ND