

Product description – Explanation of variation
DENSO / 14FGA

Appearance of 3-button type (Lock, Unlock, and Trunk buttons)



“Lock” button


“Unlock” button

“Trunk” button

Front side



Back side



“Lock” button

“Unlock” button

“Trunk” button

Front side



Back side