







■ Antenna 1. 2118562-1(Main), 2118562-1(Aux), TE Connectivity, 2016/12/21

Main



Aux



■ Antenna 2. A30724-30(Main), A30724-30(Aux), Auden, 2016/12/21

Main



Aux



■ Antenna 3. A30725-00(Main), A30725-00(Aux), Auden, 2016/12/21

Main




Aux




■ Antenna 4. 260-27099(Main), 260-27099(Aux), Hong-Bo, 2016/12/21

Main




Aux




■ Antenna 5. 260-27100(Main), 260-27100(Aux), Hong-Bo, 2016/12/21

Main




Aux



■ Antenna 6. 81EAA515.G31(Main), 81EAA515.G31(Aux), WNC, 2016/12/21

Main




Aux




■ Antenna 7. 81EAA515.G30(Main), 81EAA515.G30(Aux), WNC, 2016/12/21

Main




Aux



- Antenna 8. ANP6Y-200038(Main), ANP6Y-200038(Aux), ACON, 2016/12/21

Main




Aux




- Antenna 9. F.0G.FS-6036-001-00(Main), F.0G.FS-6036-001-00(Aux), Speed, 2016/12/21

Main




Aux




- Antenna 10. 0ACCN016023N(Main), 0ACCN016024N(Aux), High-Tek, 2016/12/21

Main




Aux




- Antenna 11. ADM6Y-200002(Main), ADM6Y-200002(Aux), ACON, 2016/12/21


Main




Aux



- Antenna 12. 1415-05H80DE(290-30450)(Main), 1415-05H80DE(290-30450)(Aux),
Hong-bo, 2016/12/21




- Antenna 13. ADM6Y-200004(Main), ADM6Y-200004(Aux), ACON, 2016/12/21




- Antenna 14. 1415-057S0DE(290-30401)(Main), 1415-057S0DE(290-30401)(Aux),
Hong-bo, 2016/12/21

Main




Aux



- Antenna 15. F.0G.FS-6043-001-00(Main), F.0G.FS-6043-001-00(Aux), Speed, 2016/12/21


Main




Aux




- Antenna 16. F.0G.FS-6043-002-00(Main), F.0G.FS-6043-002-00(Aux), Speed, 2016/12/21




- Antenna 17. F.0G.FS-6037-002-00(Main), F.0G.FS-6037-002-00(Aux), Speed, 2016/12/21



- Antenna 18. F.0G.FS-6037-001-00(Main), F.0G.FS-6037-001-00(Aux), Speed, 2016/12/21



- Antenna 19. 81EAA515.G38(Main), 81EAA515.G38(Aux), WNC, 2016/12/21




■ Antenna 20. 81EAA515.G39(Main), 81EAA515.G39(Aux), WNC, 2016/12/21

Main



Aux




■ Antenna 21. ANP6Y-200057(Main), ANP6Y-200057(Aux), ACON, 2016/12/21

Main




Aux



- Antenna 22. ANP6Y-400006(Main), ANP6Y-400006(Aux), ACON, 2016/12/21

Main




Aux



- Antenna 23. 81EAA515.G40(Main), 81EAA515.G40(Aux), WNC, 2016/12/21

Main




Aux



■ Antenna 24. 81EAA515.G41(Main), 81EAA515.G41(Aux), WNC, 2016/12/21

Main



Aux



■ Antenna 25. 5002680(Main), 5002680(Aux), Ethertronics, 2016/12/21

Main




Aux



- Antenna 26. NB mode: 5002440(DC33001XO5L)(Main), 5002446(DC33001XO4L)(Aux),
Ethertronics Inc., 2016/12/21

Main




Aux



- Antenna 27. Tablet mode: 5002440(DC33001XO5L)(Main), 5002446(DC33001XO4L)(Aux),
Ethertronics Inc., 2016/12/21

Main




Aux




- Antenna 28. NB mode: 5002345(DC33001XO1L)(Main), 5002359(DC33001XO2L)(Aux), Ethertronics Inc., 2016/12/21

Main




Aux




- Antenna 29. Tablet mode: 5002345(DC33001XO1L)(Main), 5002359(DC33001XO2L)(Aux), Ethertronics Inc., 2016/12/21

Main




Aux




- Antenna 30. NB mode: 260-24120(DC33001W52L)(Main), 260-24118(DC33001W51L)(Aux), Hong-Bo, 2016/12/21

Main




Aux




- Antenna 31. Tablet mode: 260-24119(DC33001W50L)(Main), 260-24118(DC33001W51L)(Aux), Hong-Bo, 2016/12/21


Main




Aux



- Antenna 32. NB mode: 81EAA515.G53(DC33001Z81L)(Main), 81EAA515.G54(DC33001Z82L)(Aux), Wistron Neweb Corporation, 2016/12/21




- Antenna 33. Tablet mode: 81EAA515.G53(DC33001Z81L)(Main), 81EAA515.G54(DC33001Z82L)(Aux), Wistron Neweb Corporation, 2016/12/21



- Antenna 34. NB mode: 5002663(DC33001XO3L)(Main), 5002446(DC33001XO4L)(Aux),
Ethertronics Inc., 2016/12/21

Main




Aux



- Antenna 35. Tablet mode: 5002663(DC33001XO3L)(Main),5002446(DC33001XO4L)(Aux),
Ethertronics Inc., 2016/12/21


Main



Aux



- Antenna 36. Tablet mode: 260-24120(DC33001W52L)(Main),
260-24118(DC33001W51L)(Aux), Hong-Bo, 2016/12/21



- Antenna 37. NB mode: 260-24119(DC33001W50L)(Main),
260-24118(DC33001W51L)(Aux), Hong-Bo, 2016/12/21

