

MODEL NO:

ZE-NC510

ZE-NC520

**CAR DVD-NAVICIEIVER WITH
MOTORIZED LCD DISPLAY**

BT COMPATIBILITY LIST (Version 1.9)



APPLE

							
		i-phone					
Features							
Caller ID		√					
RSSI Signal		√					
Battery life		√					
A2DP/AVRCP		X					
Paring		√					
Ringing	In-Band Ring Tone	X					
	Talk	√					
	Reject	√					
Talking	Audio Transfer	√					
	Volume up/down	√					

	Hang up	√					
Dialing	Audio Transfer	√					
	Volume up/down	√					
	Voice dial	X					
	Redial last call	√					
3-way Talk	Reject line2 incoming call	√					
	Terminate line1 and accept line2	√					
	Switch between line1 and line2	√					
	3-way talk	√					
Phonebook	ME	√					
	SIM	X					
	Dialed	√					
	Received	√					
	Missed call	√					
Stereo Control	Stop/Pause/Play	Not Supported this function					
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

ASUS

							
		ASUS P535					
Features							
Caller ID		√					
RSSI Signal		X					
Battery life		√					
A2DP/AVRCP		√					
Paring		√					
Ringing	In-Band Ring Tone	X					
	Talk	√					
	Reject	√					
Talking	Audio Transfer	√					
	Volume up/down	√					

	Hang up	√					
Dialing	Audio Transfer	√					
	Volume up/down	√					
	Voice dial	√					
	Redial last call	√					
3-way Talk	Reject line2 incoming call	√					
	Terminate line1 and accept line2	√					
	Switch between line1 and line2	√					
	3-way talk	X					
Phonebook	ME	√					
	SIM	X					
	Dialed	√					
	Received	√					
	Missed call	√					
Stereo Control	Stop/Pause/Play	√					
	Volume control	√					
	Forward/Backward	X					
	Next/Previous	√					

√: means supported, x: means unsupported

BlackBerry

							
		BlackBerry					
Features							
Caller ID		√					
RSSI Signal		√					
Battery life		√					
A2DP/AVRCP		X					
Paring		√					
Ringing	In-Band Ring Tone	X					
	Talk	√					
	Reject	√					
Talking	Audio Transfer	√					
	Volume up/down	√					

	Hang up	√					
Dialing	Audio Transfer	√					
	Volume up/down	√					
	Voice dial	X					
	Redial last call	√					
3-way Talk	Reject line2 incoming call	√					
	Terminate line1 and accept line2	√					
	Switch between line1 and line2	√					
	3-way talk	√					
Phonebook	ME	√					
	SIM	X					
	Dialed	X					
	Received	X					
	Missed call	X					
Stereo Control	Stop/Pause/Play	Not Supported this function					
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

DOPOD

							
		818	565				
Features							
Caller ID		√	√				
RSSI Signal		X	X				
Battery life		X	X				
A2DP/AVRCP		X	X				
Paring		√	√				
Ringing	In-Band Ring Tone	X	X				
	Talk	√	√				
	Reject	√	√				
Talking	Audio Transfer	√	√				
	Volume up/down	√	√				

	Hang up	√	√				
Dialing	Audio Transfer	√	√				
	Volume up/down	√	√				
	Voice dial	X	√				
	Redial last call	√	√				
3-way Talk	Reject line2 incoming call	X	X				
	Terminate line1 and accept line2	√	X				
	Switch between line1 and line2	√	√				
	3-way talk	X	X				
Phonebook	ME	X	X				
	SIM	X	X				
	Dialed	X	X				
	Received	X	X				
	Missed call	X	X				
Stereo Control	Stop/Pause/Play	Not Supported this function	Not Supported this function				
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

HTC

							
		P3470	HTC TyTNII	HTC Touch			
Features							
Caller ID		√	√	√			
RSSI Signal		√	√	√			
Battery life		√	√	√			
A2DP/AVRCP		√	√	√			
Paring		√	√	√			
Ringing	In-Band Ring Tone	√	X	X			
	Talk	√	√	√			
	Reject	√	√	√			
Talking	Audio Transfer	√	√	√			
	Volume up/down	√	√	√			

	Hang up	√	√	√			
Dialing	Audio Transfer	√	√	√			
	Volume up/down	√	√	√			
	Voice dial	√	√	√			
	Redial last call	√	√	√			
3-way Talk	Reject line2 incoming call	√	√	√			
	Terminate line1 and accept line2	√	√	√			
	Switch between line1 and line2	√	√	√			
	3-way talk	√	√	√			
Phonebook	ME	√	√	√			
	SIM	√	√	√			
	Dialed	√	√	√			
	Received	√	√	√			
	Missed call	√	√	√			
Stereo Control	Stop/Pause/Play	√	√	√			
	Volume control	√	√	√			
	Forward/Backward	X	X	X			
	Next/Previous	√	√	√			

√: means supported, x: means unsupported

LG

							
		LG Viewty	KG320	Shine KE970			
				354963019205278			
Features							
Caller ID		√	√	√			
RSSI Signal		√	X	√			
Battery life		√	X	√			
A2DP/AVRCP		√	X	√			
Paring		√	√	√			
Ringing	In-Band Ring Tone	X	X	X			
	Talk	√	√	√			
	Reject	√	√	√			
Talking	Audio Transfer	√	√	√			
	Volume up/down	√	√	√			

	Hang up	√	√	√			
Dialing	Audio Transfer	X	√	√			
	Volume up/down	√	√	√			
	Voice dial	X	X	X			
	Redial last call	√	X	√			
3-way Talk	Reject line2 incoming call	√	X	√			
	Terminate line1 and accept line2	√	√	√			
	Switch between line1 and line2	√	√	√			
	3-way talk	√	X	√			
Phonebook	ME	X	X	√			
	SIM	X	X	√			
	Dialed	X	X	X			
	Received	X	X	X			
	Missed call	X	X	X			
Stereo Control	Stop/Pause/Play	√	Not Supported this function	√			
	Volume control	√		X			
	Forward/Backward	X		X			
	Next/Previous	√		√			

√: means supported, x: means unsupported

MOTOROLA

							
		Q9h	Z6	E6	V8	K1	明 (A1200)
Features							
Caller ID		√	√	√	X	√	√
RSSI Signal		√	√	X	√	√	X
Battery life		√	√	X	√	√	X
A2DP/AVRCP		√	√	√	√	√	√
Paring	Paring	√	√	√	√	√	√
Ringing	In-Band Ring Tone	√	X	X	√	√	√
	Talk	√	√	√	√	√	√
	Reject	√	√	√	√	√	√
Talking	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Hang up	√	√	√	√	√	√

Dialing	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Voice dial	√	√	X	√	√	√
	Redial last call	√	√	√	√	√	√
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	X	√	√	√	X
Phonebook	ME	√	√	X	√	√	X
	SIM	√	√	X	√	√	X
	Dialed	√	X	X	X	√	X
	Received	√	X	X	X	√	X
	Missed call	√	X	X	X	√	X
Stereo Control	Stop/Pause/Play	√	√	√	√	√	√
	Volume control	√	√	√	√	√	√
	Forward/Backward	X	X	X	X	√	X
	Next/Previous	√	√	√	√	√	√

√: means supported, x: means unsupported

							
		V3x	V3	V600	V501	E398	
Features							
Caller ID		✓	✓	✓	✓	✓	
RSSI Signal		✓	✓	✓	✓	✓	
Battery life		✓	✓	✓	✓	✓	
A2DP/AVRCP		✓	X	X	X	X	
Paring		✓	✓	✓	✓	✓	
Ringing	In-Band Ring Tone	✓	✓	✓	✓	✓	
	Talk	✓	✓	✓	✓	✓	
	Reject	✓	✓	✓	✓	✓	
Talking	Audio Transfer	✓	✓	✓	✓	✓	
	Volume up/down	✓	✓	✓	✓	✓	
	Hang up	✓	✓	✓	✓	✓	

Dialing	Audio Transfer	√	√	√	√	√	
	Volume up/down	√	√	√	√	√	
	Voice dial	√	√	√	√	√	
	Redial last call	√	√	√	√	√	
3-way Talk	Reject line2 incoming call	√	√	√	√	√	
	Terminate line1 and accept line2	√	√	√	√	√	
	Switch between line1 and line2	√	√	√	√	√	
	3-way talk	X	X	X	X	√	
Phonebook	ME	√	√	√	√	√	
	SIM	√	√	√	√	√	
	Dialed	√	√	√	√	√	
	Received	√	√	√	√	√	
	Missed call	√	√	√	√	√	
Stereo Control	Stop/Pause/Play	√	Not Supported this function	Not Supported this function	Not Supported this function	Not Supported this function	
	Volume control	√					
	Forward/Backward	√					
	Next/Previous	√					

√: means supported, x: means unsupported

NOKIA

							
		N95	N81	5610	6110	6300	5700
Features							
Caller ID		✓	✓	✓	✓	✓	✓
RSSI Signal		✓	✓	✓	✓	✓	✓
Battery life		✓	✓	✓	✓	✓	✓
A2DP/AVRCP		✓	✓	✓	✓	✓	✓
Paring		✓	✓	✓	✓	✓	✓
Ringing	In-Band Ring Tone	✓	✓	✓	✓	✓	✓
	Talk	✓	✓	✓	✓	✓	✓
	Reject	✓	✓	✓	✓	✓	✓
Talking	Audio Transfer	✓	✓	✓	✓	✓	✓
	Volume up/down	✓	✓	✓	✓	✓	✓
	Hang up	✓	✓	✓	✓	✓	✓

Dialing	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Voice dial	√	√	√	√	√	√
	Redial last call	√	√	√	√	√	√
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	√	√	√	√	√
Phonebook	ME	X	X	√	X	√	X
	SIM	X	X	√	X	√	X
	Dialed	X	X	√	X	√	X
	Received	X	X	√	X	√	X
	Missed call	X	X	√	X	√	X
Stereo Control	Stop/Pause/Play	√	√	√	√	√	√
	Volume control	√	√	√	√	√	√
	Forward/Backward	X	X	X	X	X	X
	Next/Previous	√	√	√	√	√	√

√: means supported, x: means unsupported

							
		6233	5300	7500	6085	N91	N73
Features							
Caller ID		✓	✓	✓	✓	✓	✓
RSSI Signal		✓	✓	✓	✓	✓	✓
Battery life		✓	✓	✓	✓	✓	✓
A2DP/AVRCP		✓	✓	✓	✓	✓	X
Paring		✓	✓	✓	✓	✓	✓
Ringing	In-Band Ring Tone	✓	✓	✓	✓	✓	✓
	Talk	✓	✓	✓	✓	✓	✓
	Reject	✓	✓	✓	✓	✓	✓
Talking	Audio Transfer	✓	✓	✓	✓	✓	✓
	Volume up/down	✓	✓	✓	✓	✓	✓
	Hang up	✓	✓	✓	✓	✓	✓
Dialing	Audio Transfer	✓	✓	✓	✓	✓	✓

	Volume up/down	√	√	√	√	√	√
	Voice dial	√	√	√	√	√	√
	Redial last call	√	√	√	√	√	√
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	√	√	√	√	√
Phonebook	ME	√	√	√	√	√	√
	SIM	√	√	√	√	√	√
	Dialed	√	√	√	√	√	√
	Received	√	√	√	√	√	√
	Missed call	√	√	√	√	√	√
Stereo Control	Stop/Pause/Play	√	√	√	√	Not Supported this function	Not Supported this function
	Volume control	√	√	√	√		
	Forward/Backward	X	X	X	X		
	Next/Previous	√	√	√	√		

√: means supported, x: means unsupported

							
		6111	6270	6600	6230		
Features							
Caller ID		✓	✓	✓	✓		
RSSI Signal		✓	X	✓	✓		
Battery life		✓	X	✓	✓		
A2DP/AVRCP		X	X	X	X		
Paring		✓	✓	✓	✓		
Ringing	In-Band Ring Tone	✓	✓	✓	✓		
	Talk	✓	✓	✓	✓		
	Reject	✓	✓	✓	✓		
Talking	Audio Transfer	✓	✓	✓	✓		
	Volume up/down	✓	✓	✓	✓		
	Hang up	✓	✓	✓	✓		
Dialing	Audio Transfer	✓	✓	✓	✓		

	Volume up/down	√	√	√	√		
	Voice dial	√	√	√	√		
	Redial last call	√	√	√	√		
3-way Talk	Reject line2 incoming call	√	√	√	√		
	Terminate line1 and accept line2	√	√	√	X		
	Switch between line1 and line2	√	√	√	√		
	3-way talk	X	X	√	√		
Phonebook	ME	X	X	X	X		
	SIM	X	X	X	X		
	Dialed	X	X	X	X		
	Received	X	X	X	X		
	Missed call	X	X	X	X		
Stereo Control	Stop/Pause/Play						
	Volume control	Not Supported this function	Not Supported this function	Not Supported this function	Not Supported this function		
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

SAMSUNG

							
		I458	F338	U708	Z728	D820	D528
Features							
Caller ID		✓	✓	✓	✓	✓	✓
RSSI Signal		✓	✓	✓	✓	X	X
Battery life		✓	✓	✓	✓	X	X
A2DP/AVRCP		✓	✓	✓	✓	✓	✓
Paring		✓	✓	✓	✓	✓	✓
Ringing	In-Band Ring Tone	✓	X	X	X	X	X
	Talk	✓	✓	✓	✓	✓	✓
	Reject	✓	✓	✓	✓	✓	✓
Talking	Audio Transfer	✓	✓	✓	✓	✓	✓
	Volume up/down	✓	✓	✓	✓	✓	✓
	Hang up	✓	✓	✓	✓	✓	✓

Dialing	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Voice dial	X	√	X	X	X	X
	Redial last call	√	√	√	√	√	X
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	√	√	√	X	X
Phonebook	ME	X	√	√	√	X	√
	SIM	X	√	√	√	X	√
	Dialed	X	√	√	X	X	X
	Received	X	√	X	X	X	X
	Missed call	X	√	X	X	X	X
Stereo Control	Stop/Pause/Play	√	√	√	√	√	√
	Volume control	√	√	√	√	X	√
	Forward/Backward	X	X	X	X	X	√
	Next/Previous	√	√	√	√	√	√

√: means supported, x: means unsupported

							
		E568	D508				
Features							
Caller ID		√	√				
RSSI Signal		X	X				
Battery life		√	X				
A2DP/AVRCP		X	X				
Paring		√	√				
Ringing	In-Band Ring Tone	X	X				
	Talk	√	√				
	Reject	√	√				
Talking	Audio Transfer	√	√				
	Volume up/down	√	√				
	Hang up	√	√				
Dialing	Audio Transfer	X	√				

	Volume up/down	√	√				
	Voice dial	X	X				
	Redial last call	X	X				
3-way Talk	Reject line2 incoming call	√	√				
	Terminate line1 and accept line2	X	√				
	Switch between line1 and line2	√	√				
	3-way talk	X	X				
Phonebook	ME	√	X				
	SIM	√	X				
	Dialed	X	X				
	Received	X	X				
	Missed call	X	X				
Stereo Control	Stop/Pause/Play	Not Supported this function	Not Supported this function				
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

SHARP

							
		WX-T82	WX-T71	GX-T15			
Features							
Caller ID		✓	✓	✓			
RSSI Signal		✓	✓	X			
Battery life		✓	✓	X			
A2DP/AVRCP		✓	X	X			
Paring		✓	✓	✓			
Ringing	In-Band Ring Tone	X	✓	✓			
	Talk	✓	✓	✓			
	Reject	✓	✓	✓			
Talking	Audio Transfer	✓	✓	✓			
	Volume up/down	✓	✓	✓			
	Hang up	✓	✓	✓			

Dialing	Audio Transfer	√	√	√			
	Volume up/down	√	√	√			
	Voice dial	X	√	X			
	Redial last call	√	√	√			
3-way Talk	Reject line2 incoming call	√	√	√			
	Terminate line1 and accept line2	√	√	√			
	Switch between line1 and line2	√	√	√			
	3-way talk	√	√	√			
Phonebook	ME	X	√	√			
	SIM	X	√	√			
	Dialed	X	√	√			
	Received	X	√	√			
	Missed call	X	√	√			
Stereo Control	Stop/Pause/Play	√	Not Supported this function	Not Supported this function			
	Volume control	√					
	Forward/Backward	X					
	Next/Previous	√					

√: means supported, x: means unsupported

SIEMENS

							
		S55	BenQ S88				
Features							
Caller ID		✓	✓				
RSSI Signal		✓	X				
Battery life		✓	X				
A2DP/AVRCP		X	X				
Paring		✓	✓				
Ringing	In-Band Ring Tone	✓	X				
	Talk	✓	✓				
	Reject	✓	✓				
Talking	Audio Transfer	✓	✓				
	Volume up/down	✓	✓				
	Hang up	✓	✓				

Dialing	Audio Transfer	√	√				
	Volume up/down	√	√				
	Voice dial	√	X				
	Redial last call	√	√				
3-way Talk	Reject line2 incoming call	√	√				
	Terminate line1 and accept line2	√	√				
	Switch between line1 and line2	√	√				
	3-way talk	√	X				
Phonebook	ME	√	X				
	SIM	√	X				
	Dialed	√	X				
	Received	√	X				
	Missed call	√	X				
Stereo Control	Stop/Pause/Play	Not Supported this function	Not Supported this function				
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported

SONYERICSSON

							
		Z750i	W580i	P1i	S500i	K610i	K618i
Features							
Caller ID		√	√	√	√	√	√
RSSI Signal		√	√	√	√	√	√
Battery life		√	√	√	√	√	√
A2DP/AVRCP		√	√	√	√	√	√
Paring		√	√	√	√	√	√
Ringing	In-Band Ring Tone	X	X	X	X	X	X
	Talk	√	√	√	√	√	√
	Reject	√	√	√	√	√	√
Talking	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Hang up	√	√	√	√	√	√

Dialing	Audio Transfer	√	√	√	√	√	√
	Volume up/down	√	√	√	√	√	√
	Voice dial	X	√	X	√	√	√
	Redial last call	√	√	√	√	√	√
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	√	√	√	√	√
Phonebook	ME	√	√	√	√	√	√
	SIM	√	√	√	√	√	√
	Dialed	√	√	√	√	√	√
	Received	√	√	√	√	√	√
	Missed call	√	√	√	√	√	√
Stereo Control	Stop/Pause/Play	√	√	√	√	√	√
	Volume control	√	√	√	√	√	√
	Forward/Backward	X	X	X	√	X	X
	Next/Previous	√	√	√	√	√	√

√: means supported, x: means unsupported

							
		W880i	K800i	M600i	K700i	Z800i	S700i
Features							
Caller ID		✓	✓	✓	✓	✓	✓
RSSI Signal		✓	✓	✓	✓	✓	✓
Battery life		✓	✓	✓	✓	✓	✓
A2DP/AVRCP		✓	✓	✓	X	X	X
Paring		✓	✓	✓	✓	✓	✓
Ringing	In-Band Ring Tone	X	X	X	X	X	X
	Talk	✓	✓	✓	✓	✓	✓
	Reject	✓	✓	✓	✓	✓	✓
Talking	Audio Transfer	✓	✓	✓	✓	✓	✓
	Volume up/down	✓	✓	✓	✓	✓	✓
	Hang up	✓	✓	✓	✓	✓	✓
Dialing	Audio Transfer	✓	✓	✓	X	X	X

	Volume up/down	√	√	√	√	√	√
	Voice dial	√	√	√	√	√	√
	Redial last call	√	√	√	√	√	√
3-way Talk	Reject line2 incoming call	√	√	√	√	√	√
	Terminate line1 and accept line2	√	√	√	√	√	√
	Switch between line1 and line2	√	√	√	√	√	√
	3-way talk	√	√	√	√	X	√
Phonebook	ME	√	√	√	√	√	√
	SIM	√	√	√	√	√	√
	Dialed	√	√	√	√	√	√
	Received	√	√	√	√	√	√
	Missed call	√	√	√	√	√	√
Stereo Control	Stop/Pause/Play	√	√	√	Not Supported this function	Not Supported this function	Not Supported this function
	Volume control	√	√	X			
	Forward/Backward	X	X	X			
	Next/Previous	√	√	√			

√: means supported, x: means unsupported

							
		W550i	Z600	T68	T68i	T610	
Features							
Caller ID		✓	✓	✓	✓	✓	
RSSI Signal		✓	✓	✓	✓	✓	
Battery life		✓	✓	✓	✓	✓	
A2DP/AVRCP		X	X	X	X	X	
Paring		✓	✓	✓	✓	✓	
Ringing	In-Band Ring Tone	X	X	X	X	X	
	Talk	✓	✓	✓	✓	✓	
	Reject	✓	✓	✓	✓	✓	
Talking	Audio Transfer	✓	✓	✓	✓	✓	
	Volume up/down	✓	✓	✓	✓	✓	
	Hang up	✓	✓	✓	✓	✓	
Dialing	Audio Transfer	X	✓	✓	✓	✓	

	Volume up/down	√	√	√	√	√	
	Voice dial	√	√	√	√	√	
	Redial last call	√	√	√	√	√	
3-way Talk	Reject line2 incoming call	√	√	√	√	√	
	Terminate line1 and accept line2	√	√	√	√	√	
	Switch between line1 and line2	√	√	√	√	√	
	3-way talk	√	X	X	√	√	
Phonebook	ME	√	√	√	√	√	
	SIM	√	√	√	√	√	
	Dialed	√	√	√	√	√	
	Received	√	√	√	√	√	
	Missed call	√	√	√	√	√	
Stereo Control	Stop/Pause/Play	Not Supported this function	Not Supported this function	Not Supported this function	Not Supported this function	Not Supported this function	
	Volume control						
	Forward/Backward						
	Next/Previous						

√: means supported, x: means unsupported



ZENEC · 2F, 343, SEC. 2 · Fu Hsing S. Road · Taipei, Taiwan R.O.C.