











NTNV-11AC40SISO-Ant1-5510-30~1000-PASS




NTNV-11AC40SISO-Ant1-5510-1000~26500-See table below













NTNV-11AC80SISO-Ant1-5210-30~1000-PASS




NTNV-11AC80SISO-Ant1-5210-1000~26500-See table below







NTNV-11AC80SISO-Ant1-5530-30~1000-PASS



NTNV-11AC80SISO-Ant1-5530-1000~26500-See table below



