



1. External Photograph of EUT**Brand Name: Sony / Model Name: Xperia XA1 (G3125)**



Brand Name: Sony / Model Name: Xperia XA1 (G3125)




**2. Photograph of Accessory****Brand Name: Sony / Model Name: Xperia XA1 (G3125)**

Specification of Accessory		
AC Adapter 1	Model Name	UCH20
AC Adapter 2	Model Name	UCH20
Battery	Model Name	LIP1635ERPCS
Earphone 1	Model Name	MH410c
Earphone 2	Model Name	MH410c
USB Cable	Model Name	UCB20

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Sony / Model Name: Xperia XA1 (G3125)



Brand Name: Sony / Model Name: Xperia XA1 (G3125)

AC Adapter 1



Brand Name: Sony / Model Name: Xperia XA1 (G3125)

AC Adapter 2



Brand Name: Sony / Model Name: Xperia XA1 (G3125)

Battery

