







NTVN-11AC160MIMO-Ant1-5570-5419.6~5470-PASS



NTVN-11AC160MIMO-Ant2-5570-5419.6~5470-PASS





NTVN-11AX20MIMO-Ant1-5180-30~5142-PASS



NTVN-11AX20MIMO-Ant2-5180-30~5142-PASS








NTVN-11AX20MIMO-Ant1-5180-5250.2~5251-PASS



NTVN-11AX20MIMO-Ant2-5180-5250.2~5251-PASS



NTNV-11AX20MIMO-Ant1-5180-5251~5260-PASS



NTNV-11AX20MIMO-Ant2-5180-5251~5260-PASS



NTN-11AX20MIMO-Ant1-5180-5260~5266.7-PASS



NTN-11AX20MIMO-Ant2-5180-5260~5266.7-PASS



NTNV-11AX20MIMO-Ant1-5180-5266.7~26000-PASS



NTNV-11AX20MIMO-Ant2-5180-5266.7~26000-PASS



NTNV-11AX20MIMO-Ant1-5200-30~5142-PASS



NTNV-11AX20MIMO-Ant2-5200-30~5142-PASS





NTVN-11AX20MIMO-Ant1-5200-5250~5250.2-PASS



NTVN-11AX20MIMO-Ant2-5200-5250~5250.2-PASS



NTNV-11AX20MIMO-Ant1-5200-5250.2~5251-PASS



NTNV-11AX20MIMO-Ant2-5200-5250.2~5251-PASS




NTNV-11AX20MIMO-Ant1-5200-5251~5260-PASS



NTNV-11AX20MIMO-Ant2-5200-5251~5260-PASS



NTNV-11AX20MIMO-Ant1-5200-5260~5266.7-PASS




NTNV-11AX20MIMO-Ant2-5200-5260~5266.7-PASS



NTVN-11AX20MIMO-Ant1-5200-5266.7~26000-PASS




NTVN-11AX20MIMO-Ant2-5200-5266.7~26000-PASS





NTNV-11AX20MIMO-Ant1-5220-5142~5150-PASS



NTNV-11AX20MIMO-Ant2-5220-5142~5150-PASS



NTNV-11AX20MIMO-Ant2-5220-5250~5250.2-PASS



NTNV-11AX20MIMO-Ant1-5220-5250~5251-PASS



NTNV-11AX20MIMO-Ant2-5220-5250.2~5251-PASS



NTNV-11AX20MIMO-Ant1-5220-5251~5260-PASS





NTNV-11AX20MIMO-Ant2-5220-5260~5266.7-PASS




NTNV-11AX20MIMO-Ant1-5220-5266.7~26000-PASS



NTVN-11AX20MIMO-Ant2-5220-5266.7~26000-PASS



NTVN-11AX20MIMO-Ant1-5240-30~5142-PASS





NTNV-11AX20MIMO-Ant2-5240-5142~5150-PASS



NTNV-11AX20MIMO-Ant1-5240-5250~5250.2-See table below




NTVN-11AX20MIMO-Ant2-5240-5250~5250.2-See table below



NTVN-11AX20MIMO-Ant1-5240-5250.2~5251-See table below



NTNV-11AX20MIMO-Ant2-5240-5250.2~5251-See table below



NTNV-11AX20MIMO-Ant1-5240-5251~5260-PASS






NTNV-11AX20MIMO-Ant2-5240-5260~5266.7-PASS




NTNV-11AX20MIMO-Ant1-5240-5266.7~26000-PASS









NTNV-11AX20MIMO-Ant2-5260-5233.3~5240-PASS



NTNV-11AX20MIMO-Ant1-5260-5240~5249-PASS





NTNV-11AX20MIMO-Ant2-5260-5249~5249.8-PASS



NTNV-11AX20MIMO-Ant1-5260-5249.8~5250-PASS



NTNV-11AX20MIMO-Ant2-5260-5249.8~5250-PASS



NTNV-11AX20MIMO-Ant1-5260-5350~26000-PASS



NTNV-11AX20MIMO-Ant2-5260-5350~26000-PASS




NTNV-11AX20MIMO-Ant1-5280-30~5233.3-PASS






NTN-11AX20MIMO-Ant2-5280-5233.3~5240-PASS



NTN-11AX20MIMO-Ant1-5280-5240~5249-PASS



NTNV-11AX20MIMO-Ant2-5280-5240~5249-PASS



NTNV-11AX20MIMO-Ant1-5280-5249~5249.8-PASS



NTNV-11AX20MIMO-Ant2-5280-5249~5249.8-PASS



NTNV-11AX20MIMO-Ant1-5280-5249.8~5250-PASS



NTNV-11AX20MIMO-Ant2-5280-5249.8~5250-PASS



NTNV-11AX20MIMO-Ant1-5280-5350~26000-PASS





NTNV-11AX20MIMO-Ant2-5300-30~5233.3-PASS




NTNV-11AX20MIMO-Ant1-5300-5233.3~5240-PASS



NTNV-11AX20MIMO-Ant2-5300-5233.3~5240-PASS



NTNV-11AX20MIMO-Ant1-5300-5240~5249-PASS



NTNV-11AX20MIMO-Ant2-5300-5240~5249-PASS



NTNV-11AX20MIMO-Ant1-5300-5249~5249.8-PASS



NTNV-11AX20MIMO-Ant2-5300-5249~5249.8-PASS



NTNV-11AX20MIMO-Ant1-5300-5249.8~5250-PASS




NTNV-11AX20MIMO-Ant2-5300-5249.8~5250-PASS



NTNV-11AX20MIMO-Ant1-5300-5350~26000-PASS




NTNV-11AX20MIMO-Ant2-5300-5350~26000-PASS



NTNV-11AX20MIMO-Ant1-5320-30~5233.3-PASS



NTNV-11AX20MIMO-Ant2-5320-30~5233.3-PASS




NTNV-11AX20MIMO-Ant1-5320-5233.3~5240-PASS



NTN-11AX20MIMO-Ant2-5320-5233.3~5240-PASS



NTN-11AX20MIMO-Ant1-5320-5240~5249-PASS



NTNV-11AX20MIMO-Ant2-5320-5240~5249-PASS



NTNV-11AX20MIMO-Ant1-5320-5249~5249.8-PASS



NTVN-11AX20MIMO-Ant2-5320-5249~5249.8-PASS



NTVN-11AX20MIMO-Ant1-5320-5249.8~5250-PASS






NTNV-11AX20MIMO-Ant2-5320-5350~26000-PASS




NTNV-11AX20MIMO-Ant1-5500-30~5460-PASS










NTNV-11AX20MIMO-Ant2-5500-5765~26000-PASS



NTNV-11AX20MIMO-Ant1-5580-30~5460-PASS



NTNV-11AX20MIMO-Ant2-5580-30~5460-PASS



NTNV-11AX20MIMO-Ant1-5580-5460~5470-PASS



NTNV-11AX20MIMO-Ant2-5580-5460~5470-PASS



NTNV-11AX20MIMO-Ant1-5580-5745~5765-PASS





NTNV-11AX20MIMO-Ant2-5580-5765~26000-PASS



NTNV-11AX20MIMO-Ant1-5600-30~5460-PASS






NTNV-11AX20MIMO-Ant2-5600-5460~5470-PASS



NTNV-11AX20MIMO-Ant1-5600-5745~5765-PASS



NTNV-11AX20MIMO-Ant2-5600-5745~5765-PASS




NTNV-11AX20MIMO-Ant1-5600-5765~26000-PASS




NTNV-11AX20MIMO-Ant2-5600-5765~26000-PASS



NTNV-11AX20MIMO-Ant1-5700-30~5460-PASS



NTNV-11AX20MIMO-Ant2-5700-30~5460-PASS



NTNV-11AX20MIMO-Ant1-5700-5460~5470-PASS



NTNV-11AX20MIMO-Ant2-5700-5460~5470-PASS



NTNV-11AX20MIMO-Ant1-5700-5745~5765-PASS



NTNV-11AX20MIMO-Ant2-5700-5745~5765-PASS



NTNV-11AX20MIMO-Ant1-5700-5765~26000-PASS



NTVN-11AX20MIMO-Ant2-5700-5765~26000-PASS




NTVN-11AX20MIMO-Ant1-5720-30~5460-PASS




NTNV-11AX20MIMO-Ant2-5720-30~5460-PASS



NTNV-11AX20MIMO-Ant1-5720-5460~5470-PASS







NTNV-11AX20MIMO-Ant2-5720-5765~26000-PASS




NTNV-11AX40MIMO-Ant1-5190-30~5141.6-PASS





NTNV-11AX40MIMO-Ant2-5190-5141.6~5150-PASS



NTNV-11AX40MIMO-Ant1-5190-5250~5251-PASS





NTNV-11AX40MIMO-Ant2-5190-5251~5270-PASS




NTNV-11AX40MIMO-Ant1-5190-5270~5278.4-PASS




NTNV-11AX40MIMO-Ant2-5190-5270~5278.4-PASS



NTNV-11AX40MIMO-Ant1-5190-5278.4~26000-PASS








NTNV-11AX40MIMO-Ant2-5230-5141.6~5150-PASS



NTNV-11AX40MIMO-Ant1-5230-5250~5251-See table below



NTVN-11AX40MIMO-Ant2-5230-5250~5251-See table below



NTVN-11AX40MIMO-Ant1-5230-5251~5270-PASS






NTVN-11AX40MIMO-Ant2-5230-5270~5278.4-PASS



NTVN-11AX40MIMO-Ant1-5230-5278.4~26000-PASS



NTVN-11AX40MIMO-Ant2-5230-5278.4~26000-PASS




NTVN-11AX40MIMO-Ant1-5270-30~5221.6-PASS






NTNV-11AX40MIMO-Ant2-5270-5221.6~5230-PASS



NTNV-11AX40MIMO-Ant1-5270-5230~5249-PASS







NTNV-11AX40MIMO-Ant2-5270-5350~5358.4-PASS



NTNV-11AX40MIMO-Ant1-5270-5358.4~26000-PASS



NTNV-11AX40MIMO-Ant2-5270-5358.4~26000-PASS



NTNV-11AX40MIMO-Ant1-5310-30~5221.6-PASS





NTNV-11AX40MIMO-Ant2-5310-5221.6~5230-PASS



NTNV-11AX40MIMO-Ant1-5310-5230~5249-PASS



NTNV-11AX40MIMO-Ant2-5310-5230~5249-PASS



NTNV-11AX40MIMO-Ant1-5310-5249~5250-PASS



NTNV-11AX40MIMO-Ant2-5310-5249~5250-PASS



NTNV-11AX40MIMO-Ant1-5310-5350~5358.4-PASS



NTNV-11AX40MIMO-Ant2-5310-5358.4-PASS




NTNV-11AX40MIMO-Ant1-5310-5358.4~26000-PASS







NTNV-11AX40MIMO-Ant2-5510-30~5460-PASS



NTNV-11AX40MIMO-Ant1-5510-5460~5470-PASS









NTNV-11AX40MIMO-Ant2-5550-5460~5470-PASS




NTNV-11AX40MIMO-Ant1-5550-5770~26000-PASS



NTNV-11AX40MIMO-Ant2-5550-5770~26000-PASS




NTNV-11AX40MIMO-Ant1-5670-30~5460-PASS



NTNV-11AX40MIMO-Ant2-5670-30~5460-PASS



NTNV-11AX40MIMO-Ant1-5670-5460~5470-PASS





NTNV-11AX40MIMO-Ant2-5670-5770~26000-PASS



NTNV-11AX40MIMO-Ant1-5710-30~5460-PASS






NTNV-11AX40MIMO-Ant2-5710-5460~5470-PASS



NTNV-11AX40MIMO-Ant1-5710-5770~26000-PASS








NTNV-11AX80MIMO-Ant2-5210-5123.2~5150-PASS




NTNV-11AX80MIMO-Ant1-5210-5250~5251-See table below



NTNV-11AX80MIMO-Ant2-5210-5250~5251-See table below



NTNV-11AX80MIMO-Ant1-5210-5251~5290-PASS











NTNV-11AX80MIMO-Ant2-5290-30~5203.3-PASS




NTNV-11AX80MIMO-Ant1-5290-5203.3~5210-PASS



NTNV-11AX80MIMO-Ant2-5290-5203.3~5210-PASS



NTNV-11AX80MIMO-Ant1-5290-5210~5249-See table below



NTNV-11AX80MIMO-Ant2-5290-5210~5249-See table below



NTNV-11AX80MIMO-Ant1-5290-5249~5250-See table below



NTNV-11AX80MIMO-Ant2-5290-5249~5250-See table below



NTNV-11AX80MIMO-Ant1-5290-5350~5376.8-PASS



NTNV-11AX80MIMO-Ant2-5290-5350~5376.8-PASS



NTNV-11AX80MIMO-Ant1-5290-5376.8~26000-PASS







NTNV-11AX80MIMO-Ant2-5530-5460~5469.5-PASS




NTNV-11AX80MIMO-Ant1-5530-5469.5~5470-PASS



NTNV-11AX80MIMO-Ant2-5530-5469.5~5470-PASS



NTNV-11AX80MIMO-Ant1-5530-5770~26000-PASS





NTNV-11AX80MIMO-Ant2-5610-30~5460-PASS



NTNV-11AX80MIMO-Ant1-5610-5460~5469.5-PASS



NTVN-11AX80MIMO-Ant2-5610-5469.5~5469.5-PASS



NTVN-11AX80MIMO-Ant1-5610-5469.5~5470-PASS



NTN-11AX80MIMO-Ant2-5610-5469.5~5470-PASS



NTN-11AX80MIMO-Ant1-5610-5770~26000-PASS








NTNV-11AX80MIMO-Ant2-5690-5460~5469.5-PASS



NTNV-11AX80MIMO-Ant1-5690-5469.5~5470-PASS



NTNV-11AX80MIMO-Ant2-5690-5469.5~5470-PASS




NTNV-11AX80MIMO-Ant1-5690-5770~26000-PASS




NTNV-11AX80MIMO-Ant2-5690-5770~26000-PASS



NTNV-11AX160MIMO-Ant1-5250-30~5099.6-PASS



NTVN-11AX160MIMO-Ant2-5250-30~5099.6-PASS



NTVN-11AX160MIMO-Ant1-5250-5099.6~5150-PASS



NTNV-11AX160MIMO-Ant2-5250-5099.6~5150-PASS



NTNV-11AX160MIMO-Ant1-5250-5350~5400.4-PASS



NTVN-11AX160MIMO-Ant2-5250-5350~5400.4-PASS



NTVN-11AX160MIMO-Ant1-5250-5400.4~26000-PASS



NTV-11AX160MIMO-Ant2-5250-5400.4~26000-PASS



NTV-11AX160MIMO-Ant1-5570-30~5419.6-PASS



NTVN-11AX160MIMO-Ant2-5570-30~5419.6-PASS



NTVN-11AX160MIMO-Ant1-5570-5419.6~5470-PASS



NTVN-11AX160MIMO-Ant2-5570-5419.6~5470-PASS




NTVN-11AX160MIMO-Ant1-5570-5725~26000-PASS






NTNV-11BE20MIMO-Ant2-5180-30~5142-PASS



NTNV-11BE20MIMO-Ant1-5180-5142~5150-PASS



NTNV-11BE20MIMO-Ant2-5180-5142~5150-PASS



NTNV-11BE20MIMO-Ant1-5180-5250~5250.2-PASS





NTNV-11BE20MIMO-Ant2-5180-5250.2~5251-PASS



NTNV-11BE20MIMO-Ant1-5180-5251~5260-PASS



NTNV-11BE20MIMO-Ant2-5180-5251~5260-PASS



NTNV-11BE20MIMO-Ant1-5180-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant2-5180-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant1-5180-5266.7~26000-PASS



NTVN-11BE20MIMO-Ant2-5180-5266.7~26000-PASS



NTVN-11BE20MIMO-Ant1-5200-30~5142-PASS



NTNV-11BE20MIMO-Ant2-5200-30~5142-PASS



NTNV-11BE20MIMO-Ant1-5200-5142~5150-PASS



NTNV-11BE20MIMO-Ant2-5200-5142~5150-PASS



NTNV-11BE20MIMO-Ant1-5200-5250~5250.2-PASS



NTNV-11BE20MIMO-Ant2-5200-5250.2~5250.2-PASS



NTNV-11BE20MIMO-Ant1-5200-5250.2~5251-PASS




NTNV-11BE20MIMO-Ant2-5200-5250.2~5251-PASS



NTNV-11BE20MIMO-Ant1-5200-5251~5260-PASS



NTNV-11BE20MIMO-Ant2-5200-5251~5260-PASS



NTNV-11BE20MIMO-Ant1-5200-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant2-5200-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant1-5200-5266.7~26000-PASS



NTVN-11BE20MIMO-Ant2-5200-5266.7~26000-PASS



NTVN-11BE20MIMO-Ant1-5220-30~5142-PASS





NTNV-11BE20MIMO-Ant2-5220-5142~5150-PASS



NTNV-11BE20MIMO-Ant1-5220-5250~5250.2-PASS





NTNV-11BE20MIMO-Ant2-5220-5250.2~5251-PASS



NTNV-11BE20MIMO-Ant1-5220-5251~5260-PASS




NTNV-11BE20MIMO-Ant2-5220-5251~5260-PASS



NTNV-11BE20MIMO-Ant1-5220-5260~5266.7-PASS



NTVN-11BE20MIMO-Ant2-5220-5260~5266.7-PASS



NTVN-11BE20MIMO-Ant1-5220-5266.7~26000-PASS














NTNV-11BE20MIMO-Ant2-5240-5250.2~5251-See table below



NTNV-11BE20MIMO-Ant1-5240-5251~5260-See table below




NTVN-11BE20MIMO-Ant2-5240-5251~5260-See table below



NTVN-11BE20MIMO-Ant1-5240-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant2-5240-5260~5266.7-PASS



NTNV-11BE20MIMO-Ant1-5240-5266.7~26000-PASS



NTVN-11BE20MIMO-Ant2-5240-5266.7~26000-PASS




NTVN-11BE20MIMO-Ant2-5260-30~5233.3-PASS





NTNV-11BE20MIMO-Ant2-5260-5233.3~5240-PASS



NTNV-11BE20MIMO-Ant1-5260-5240~5249-PASS



NTVN-11BE20MIMO-Ant2-5260-5240~5249-PASS



NTVN-11BE20MIMO-Ant1-5260-5249~5249.8-PASS







NTNV-11BE20MIMO-Ant2-5260-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant1-5260-5350~26000-PASS











NTNV-11BE20MIMO-Ant2-5280-5249~5249.8-PASS



NTNV-11BE20MIMO-Ant1-5280-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant2-5280-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant1-5280-5350~26000-PASS





NTNV-11BE20MIMO-Ant2-5300-30~5233.3-PASS




NTNV-11BE20MIMO-Ant1-5300-5233.3~5240-PASS



NTN-11BE20MIMO-Ant2-5300-5233.3~5240-PASS



NTN-11BE20MIMO-Ant1-5300-5240~5249-PASS




NTNV-11BE20MIMO-Ant2-5300-5240~5249-PASS



NTNV-11BE20MIMO-Ant1-5300-5249~5249.8-PASS



NTNV-11BE20MIMO-Ant2-5300-5249~5249.8-PASS



NTNV-11BE20MIMO-Ant1-5300-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant2-5300-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant1-5300-5350~26000-PASS







NTNV-11BE20MIMO-Ant2-5320-5233.3~5240-PASS



NTNV-11BE20MIMO-Ant1-5320-5240~5249-PASS



NTNV-11BE20MIMO-Ant2-5320-5240~5249-PASS



NTNV-11BE20MIMO-Ant1-5320-5249~5249.8-PASS



NTNV-11BE20MIMO-Ant2-5320-5249~5249.8-PASS




NTNV-11BE20MIMO-Ant1-5320-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant2-5320-5249.8~5250-PASS



NTNV-11BE20MIMO-Ant1-5320-5350~26000-PASS








NTNV-11BE20MIMO-Ant2-5500-5460~5470-PASS



NTNV-11BE20MIMO-Ant1-5500-5745~5765-PASS



NTNV-11BE20MIMO-Ant2-5500-5745~5765-PASS



NTNV-11BE20MIMO-Ant1-5500-5765~26000-PASS



NTNV-11BE20MIMO-Ant2-5500-5765~26000-PASS



NTNV-11BE20MIMO-Ant1-5580-30~5460-PASS



NTNV-11BE20MIMO-Ant2-5580-30~5460-PASS




NTNV-11BE20MIMO-Ant1-5580-5460~5470-PASS



NTNV-11BE20MIMO-Ant2-5580-5460~5470-PASS



NTNV-11BE20MIMO-Ant1-5580-5745~5765-PASS






NTNV-11BE20MIMO-Ant2-5580-5765~26000-PASS



NTNV-11BE20MIMO-Ant1-5600-30~5460-PASS



NTNV-11BE20MIMO-Ant2-5600-30~5460-PASS



NTNV-11BE20MIMO-Ant1-5600-5460~5470-PASS



NTNV-11BE20MIMO-Ant2-5600-5460~5470-PASS




NTNV-11BE20MIMO-Ant1-5600-5745~5765-PASS




NTNV-11BE20MIMO-Ant2-5600-5745~5765-PASS



NTNV-11BE20MIMO-Ant1-5600-5765~26000-PASS










NTNV-11BE20MIMO-Ant2-5700-5745~5765-PASS



NTNV-11BE20MIMO-Ant1-5700-5765~26000-PASS




NTVN-11BE20MIMO-Ant2-5700-5765~26000-PASS



NTVN-11BE20MIMO-Ant1-5720-30~5460-PASS







NTNV-11BE20MIMO-Ant2-5720-5745~5765-PASS




NTNV-11BE20MIMO-Ant1-5720-5765~26000-PASS



NTNV-11BE20MIMO-Ant2-5720-5765~26000-PASS



NTNV-11BE40MIMO-Ant1-5190-30~5141.6-PASS






NTNV-11BE40MIMO-Ant2-5190-5141.6~5150-PASS



NTNV-11BE40MIMO-Ant1-5190-5250~5251-PASS



NTNV-11BE40MIMO-Ant2-5190-5250~5251-PASS



NTNV-11BE40MIMO-Ant1-5190-5251~5270-PASS



NTNV-11BE40MIMO-Ant2-5190-5251~5270-PASS



NTNV-11BE40MIMO-Ant1-5190-5270~5278.4-PASS



NTNV-11BE40MIMO-Ant2-5190-5270~5278.4-PASS



NTNV-11BE40MIMO-Ant1-5190-5278.4~26000-PASS

